


Service Manual



G-Force[®] Q and iQ Series All Capacities

Gorbels[®] Dealer _____

Gorbels[®] Customer Order No. _____

Serial No. _____

Date _____

Month

Year

Index

	Page
Chapter 1 - Safe Hoist Operating Guidelines	1-1
Chapter 2 - Technical Specifications	2-1
Chapter 3 - Installation Procedure	
• Step 1 - Unpacking the G-Force	3-1
• Step 2 - Pre-Assembly / Tools Required	3-1
• Step 3 - Actuator Assembly Installation	3-1
• Step 4 - Coil Cord Installation	3-2
• Step 5 - Handle Installation	3-3
• Step 6 - Electrical Power Connection	3-9
• Step 7 - Initial Power-Up	3-9
• Step 8 - Float Mode and Final Steps	3-10
• Step 9 - Expansion I/O Block Mounting Instructions (Option)	3-12
Chapter 4 - Removal Procedure	4-1
Chapter 5 - Control and Programming	
• Controls Interface Features	5-1
• Program Mode Overview	5-2
• iQ Actuator Input/Output Module Functionality	5-14
• Expansion 8-Point Input/Output Block Functionality	5-15
Chapter 6 - Software Update	6-1
Chapter 7 - Troubleshooting	
• Troubleshooting Procedure	7-1
• Troubleshooting Section I: Functional Failure Table	7-2
• Troubleshooting Section II: System Fault Diagnostics Chart	7-4
• Q-iQ Unit: System, Motion and Feature Command Fault List	7-8
Chapter 8 - Electrical Schematics	8-1
Chapter 9 - Adjustments	
• Limit Switch Adjustment	9-1
• Wire Rope Replacement Adjustment	9-3
• Linear Transducer Adjustment	9-4
• Slack Spring Adjustment	9-5
Chapter 10 - Parts and Assembly	
• Actuator	10-2
• Sliding Handle	10-40
• Pendant Handle	10-53
• Coil Cords	10-67
• G360™	10-74
• PLC Battery	10-80
Chapter 11 - Preventative Maintenance	11-1
Chapter 12 - Recommended Tools & Parts	12-1

Chapter 1 - Safe Hoist Operating Guidelines

General

There is no one single factor that is more important for minimizing the possibility of personal injury to the operator and those working in the area, or damage to property, equipment, or material than being familiar with the equipment and using Safe Operating Practices.

Hoists/trolleys are designed for lifting and transporting of material only. Under no circumstances, either during initial installation or in any other use, should the hoist be used for lifting or transporting personnel.

No operator should be permitted to use the equipment that is not familiar with its operation, is not physically or mentally fit, or has not been schooled in safe operating practices. The misuse of hoists can lead to certain hazards which cannot be protected against by mechanical means; hazards which can only be avoided by the exercise of intelligence, care, and common sense.

Safe Operating Practices also involve a program of periodic inspection and preventative maintenance (covered in a separate section). Part of the operator's training should be an awareness of potential malfunctions/hazards requiring adjustments or repairs, and bringing these to the attention of supervision for corrective action.

Supervision and management also have an important role to play in any safety program by ensuring that a maintenance schedule is adhered to, and that the equipment provided for the operators is suitable for the job intended without violation of one or more of the rules covering safe operating practices and good common sense.

The Safe Operating Practices shown are taken in part from the following publications:

- American National Standard Institute (ANSI)
- Safety Standards for Cranes, Derricks, Hoists
- ANSI B30.2 - Overhead and Gantry Cranes
- ANSI B30.16 - Overhead Hoists

Do's and Don'ts (Safe Operation of Hoists)

The following are Do's and Don'ts for safe operation of overhead hoists. A few minutes spent reading these rules can make an operator aware of dangerous practices to avoid and precautions to take for his own safety and the safety of others. Frequent examinations and periodic inspections of the equipment as well as a conscientious observance of safety rules may save lives as well as time and money.

DON'TS - HOISTS

1. Never lift or transport a load until all personnel are clear and do not transport the load over personnel.
2. Do not allow any unqualified personnel to operate hoist.
3. Never pick up a load beyond the capacity rating appearing on the hoist. Overloading can be caused by jerking as well as by static overload.
4. Never carry personnel on the hook or the load.
5. Do not operate hoist if you are not physically fit.
6. Do not operate hoist to extreme limits of travel of cable without first checking for proper limit switch action.

7. Avoid sharp contact between two hoists or between hoist and end stop.
8. Do not tamper with or adjust any parts of the hoist unless specifically authorized to do so.
9. Never use the load cable as a sling.
10. Do not divert attention from load while operating hoist.
11. Never leave a suspended load unattended.
12. Do not use limit switch(es) for normal operating stop(s). These are safety devices only and should be checked on a regular basis for proper operation.
13. Never operate a hoist that has an inherent or suspected mechanical or electrical defect.
14. Do not use load cable as a ground for welding. Never touch a live welding electrode to the load cable.
15. Do not jog controls unnecessarily. Hoist motors are generally high torque, high slip types. Each start causes an inrush of current greater than the running current and leads to overheating and current failure, or burnout, if continued to excess.
16. Do not operate hoist if load is not centered under hoist.
17. Do not operate hoist if cable is twisted, kinked, or damaged.
18. Do not remove or obscure label.
19. Do not permanently activate operator present sensor.


DO'S - HOISTS

1. Read and follow manufacturer's instruction, installation, and maintenance manuals. When repairing or maintaining a hoist, use only manufacturer's recommended parts and materials.
2. Read and follow all instruction and warning information on or attached to a hoist.
3. Remove the hoist from service and thoroughly inspect and repair, as necessary, if unusual performance or visual defects (such as peculiar noise, jerky operations, travel in improper direction, or obviously damaged parts) are noticed.
4. Establish a regular schedule of inspection and maintain records for all hoists with special attention given to hooks, load cables, brakes, and limit switches.
5. Check operation of brakes for excessive drift.
6. Never lift loads over people, etc.
7. Check for damaged hooks and load cable.
8. Keep load cable clean and well maintained.
9. Check the load cable for improper seating, twisting, kinking, wear, or other defects before operating the hoist.
10. Make sure a load clears neighboring stockpiles, machinery, or other obstructions when raising, lowering, or traveling the load.
11. Center hoist over the load before operating.
12. Avoid swinging of load or load hook when traveling the hoist.
13. Be sure the load attachment is properly seated in the saddle of the hook. Balance load properly before handling. Avoid hook tip loading.
14. Pull in a straight line, so that neither hoist body nor load cable are angled around an object.
15. Take up slack slowly.
16. Know the hand signals for hoisting, cross travel, and crane travel if working with cab-operated hoists or cranes. Operators should accept signals of only those persons authorized to give them.



G-Force® Operational Guidelines

All operators should read the G-Force® Installation and Operation Manual before operating the unit. Please follow the instructions contained in this manual for your safety and for optimum trouble-free operation of your G-Force®.

<p>1</p>  <p>Read & follow all instruction & warning information on or attached to the G-Force®.</p>	<p>2</p>  <p>Check Wire Rope for improper seating, twisting, kinking, wear or defects before operating.</p>	<p>3</p>  <p>Center G-Force® over the load before lifting a load. Do not end or side load.</p>	<p>4</p>  <p>Avoid swinging of load or load hook when traveling with the G-Force®.</p>
<p>5</p>  <p>Check the coil cord for improper seating, twisting, kinking, wear or defects before operating.</p>	<p>6</p>  <p>The operator's hand should not leave the handle grip at any time the G-Force® is in use (excluding Float Mode).</p>	<p>7</p>  <p>Float Mode - Press the G-Force® logo button with only the load weight hanging from unit. Applying additional force will cause unit to drift.</p>	<p>8</p>  <p>The wire rope should never be more than 15° out of vertical while the G-Force® is in use. The G360™ must be level at all times.</p>
<p>9</p>  <p>Do not impact the G-Force® into end stops repeatedly or at a speed faster than a normal walking pace.</p>	<p>10</p>  <p>What is Trolley Saddle? The distance from bottom of wheels to floor.</p> <p>Maximum Trolley Saddle is 14'.</p> <p>Maximum Trolley Saddle for the G-Force® with standard in-line slide handle is 14'. See above drawing for Trolley Saddle definition.</p>	<p>11</p>  <p>The maximum available wire rope travel for the G-Force® is 11'. For H5 duty cycle the maximum working stroke is 8'.</p>	<p>12</p>  <p>Questions about G-Force®? Call your local Gorbel® distributor or Gorbel® Customer Service at (800) 821-0086.</p>

Chapter 2 - Technical Specifications

Series	Q Series	iQ Series	Q Series	iQ Series	Q Series	iQ Series	Q Series	iQ Series
Maximum Capacity (Load & Tool)	1320 lb	1320 lb	660 lb	660 lb	330 lb	330 lb	165 lb	165 lb
	600 kg	600 kg	300 kg	300 kg	150 kg	150 kg	75 kg	75 kg
Maximum Lifting Speed Unloaded	25 ft/min	25 ft/min	50 ft/min	50 ft/min	100 ft/min	100 ft/min	200 ft/min	200 ft/min
	7.47 m/min	7.47 m/min	14.94 m/min	14.94 m/min	30 m/min	30 m/min	61 m/min	61 m/min
Maximum Lifting Speed Fully Loaded	21 ft/min	21 ft/min	42 ft/min	42 ft/min	75 ft/min	75 ft/min	125 ft/min	125 ft/min
	6.40 m/min	6.40 m/min	12.80 m/min	12.80 m/min	23 m/min	23 m/min	38 m/min	38 m/min
Maximum Float Mode (Option) Lifting Speed	19 ft/min	19 ft/min	38 ft/min	38 ft/min	65 ft/min	65 ft/min	103 ft/min	103 ft/min
	5.79	5.79 m/min	11.58 m/min	11.58 m/min	20 m/min	20 m/min	31 m/min	31 m/min
Maximum Lift Range	5.5 ft	5.5 ft	11 ft	11 ft	11 ft	11 ft	11 ft	11 ft
	1.68 m	1.68 m	3.35 m					
Maximum Lift Stroke	5.5 ft	5.5 ft	8 ft	8 ft	8 ft	8 ft	8 ft	8 ft
	1.68 m	1.68 m	2.44 m					
Primary Lift Voltage (VAC)	220 +/- 10%	220 +/- 10%	220 +/- 10%	220 +/- 10%	220 +/- 10%	220 +/- 10%	220 +/- 10%	220 +/- 10%
Maximum Current (Amps)	10	10	10	10	10	10	10	10
Duty Cycle	H5							
Power Available for Tooling	Not Available	24VDC @ 0.5A						
Lifting Media	1/4" dia. 19x7 Preformed Stainless Steel Wire Rope	1/4" dia. 19x7 Preformed Stainless Steel Wire Rope	1/4" dia. 19x7 Preformed Stainless Steel Wire Rope	1/4" dia. 19x7 Preformed Stainless Steel Wire Rope	3/16" dia. 19x7 Preformed Stainless Steel Wire Rope	3/16" dia. 19x7 Preformed Stainless Steel Wire Rope	3/16" dia. 19x7 Preformed Stainless Steel Wire Rope	3/16" dia. 19x7 Preformed Stainless Steel Wire Rope
	6.35mm dia. 19x7 Preformed Stainless Steel Wire Rope	6.35mm dia. 19x7 Preformed Stainless Steel Wire Rope	6.35mm dia. 19x7 Preformed Stainless Steel Wire Rope	6.35mm dia. 19x7 Preformed Stainless Steel Wire Rope	4.76mm dia. 19x7 Preformed Stainless Steel Wire Rope	4.76mm dia. 19x7 Preformed Stainless Steel Wire Rope	4.76mm dia. 19x7 Preformed Stainless Steel Wire Rope	4.76mm dia. 19x7 Preformed Stainless Steel Wire Rope
Operating Temperature Range	41 - 122° F							
	5 - 50° C							
Operating Humidity Range (Non-Condensing)	35 - 90%	35 - 90%	35 - 90%	35 - 90%	35 - 90%	35 - 90%	35 - 90%	35 - 90%
Virtual Limits (Upper Limit, Power Limit, Speed Reduction)	Optional	Standard	Optional	Standard	Optional	Standard	Optional	Standard
Weight Display Accuracy (option with Float Mode)	+/- 1% Rated Capacity*	+/- 1% Rated Capacity*	+/- 1% Rated Capacity					
I/O Actuator								
Number of Inputs, Type	N/A	8, Sinking						
Input Current @ 24 VDC	N/A	6ma	N/A	6ma	N/A	6ma	N/A	6ma
Number of Outputs, Type	N/A	8, FET						
Continuous Current/Channel (Amps)	N/A	0.5	N/A	0.5	N/A	0.5	N/A	0.5
Module Maximum Current (Amps)	N/A	0.5	N/A	0.5	N/A	0.5	N/A	0.5
Handle with I/O Module								
Number of Inputs, Type	N/A	8, Sinking						
Input Current @ 24 VDC	N/A	4ma	N/A	4ma	N/A	4ma	N/A	4ma
Number of Outputs, Type	N/A	8, FET						
Continuous Current/Channel (Amps)	N/A	0.5	N/A	0.5	N/A	0.5	N/A	0.5
Module Maximum Current (Amps)	N/A	0.5	N/A	0.5	N/A	0.5	N/A	0.5

Chapter 3 - Installation Procedure

Step 1 - Unpacking the G-Force®

➔ **TIP:** Packing list can be found in plastic pocket attached to shipping box.

- 1.1 Carefully remove all items from the box. **Important: Save shipping box and all packing materials.**
- 1.2 Verify that all components listed on the packing slip are included.
- 1.3 If any items are missing or were damaged during shipping, please contact Gorbel® Inside Sales immediately at (800) 821-0086 or (585) 924-6262.

Step 2 - Pre-Assembly / Tools Required

- 2.1 Read entire Operator's Manual before beginning installation of the G-Force®.
- 2.2 Tools and materials typically needed to install/assemble a G-Force® are as follows:
 - 5mm Allen wrench
 - 8mm Allen wrench
 - 2.5mm Allen wrench
 - 6mm Allen wrench (1320 lb only)
 - 3mm Allen wrench (1320 lb only)
 - 19mm hex socket
 - Plastic cable tie straps
 - Ladders/man lifts
 - 14mm wrench or hex socket (1320 lb. only)
 - Snap ring pliers (1320 lb. only)

Step 3 - Actuator Assembly Installation

WARNING

DO NOT lift the actuator by grabbing the blue plastic end covers. To lift the actuator, grab the handle slots in the trolley.

- 3.1 The standard G-Force® will come with the wheels pre-assembled to the actuator trolley (**diagram 3A**).

When a Gorbel® G-Force® is to be used on a non-Gorbel® bridge system, a universal adapter trolley is required (**diagram 3B**). **Note:** The customer must provide two (2) hoist trolleys when the unit will run in a non-Gorbel® bridge system.

- 3.2 Ensure the power cord from the actuator is facing the festooning side of the bridge/monorail. Remove the end stop from the bridge and install the G-Force® actuator into the track. Immediately reinstall the end stop. Verify that the G-Force® trolley wheels are correct for the style and capacity track that the unit is being installed on by rolling the actuator assembly along the full length of the bridge to ensure that the travel is smooth throughout.




Diagram 3A. Standard Actuator Assembly.




Diagram 3B. Standard Actuator Assembly with Universal Adapter Trolley.

Step 4 - Coil Cord Installation (Standard In-Line Slide Handle, Remote Mounted Slide Handle and Remote Mounted Pendant Handle)

➡ **TIP:** This step is best completed once the actuator has been installed into the bridge system.

CAUTION

Do not rest the actuator on a hard flat surface with the wear ring and/or coil cord attached. You will damage the coil cord and bend the wear ring bracket which will cause poor performance.

Note: G-Force® units, standard in-line or remote mounted, that are ordered from the factory will be shipped with the coil cord assembled to the actuator wear ring and the coil cord footer, creating the coil cord assembly (**diagrams 4A** and **4B**). In addition, units ordered with air power will have a 1/4" ID nycoil air hose coil cord assembled onto the coil cord assembly (not shown).

- 4.1** Verify the coil cord assembly is correct. There are two coil cord assemblies: standard and double length. The standard coil cord assembly is used on systems with a trolley saddle up to 14' (4.27m) and will measure approximately 8.3" (211.46mm). The double length coil cord assembly is used on systems with a trolley saddle greater than 14' (4.27m) and will measure approximately 16.4" (415.93mm).
- 4.2** Feed the wire rope from the actuator assembly through the center of the coil cord assembly.



Diagram 4A. Standard Coil Cord Assembly.




Diagram 4B. Double Length Coil Cord Assembly.

CAUTION

The connectors on the coil cord are keyed. The connector must be aligned correctly before it threads into place.

- 4.3** Use the actuator assembly hardware to fasten the coil cord assembly to the actuator (**diagram 4C**). Adjust the coil cord in the clamps so that the coil cord connector is conveniently located on the proper side of the actuator assembly.
- Note:** The orientation of the coil cord must be correct so that the connector is located properly (**diagram 4D**).

- 4.4** Thread the coil cord connector into the actuator connector (**diagram 4D**).
- 4.5** Ensure that the coils of the coil cord are centered around the wire rope when properly installed.

- 4.6** Use the 16mm shoulder bolt and M12 jam-nut to retain the coil cord footer to the thimble in the wire rope.

Note: The shoulder bolt and jam-nut will be used to retain the handle or collector in the next step.

- 4.7** If applicable, connect air hose coil cord to supply line from the actuator assembly. The air hose coil cord is provided with two (2) 1/4" NPT male swivel fittings located at both ends of the air hose.

- 4.8** For standard in-line slide handle installation, go to Step 5A, page 3-3.
 For remote mounted slide handle installation, go to Step 5B, page 3-3.
 For suspended pendant handle installation, go to Step 5C, page 3-5.
 For remote mounted pendant handle installation, go to Step 5D, page 3-5.
 For 1320 lb. in-line slide or remote mounted handle installation, go to Step 5E, page 3-7.
 For 1320 lb. suspended pendant handle installation, go to Step 5F, page 3-8.




Diagram 4C. Coil Cord Assembly Installation at the Actuator.
(black center not shown)




Diagram 4D. Coil Cord Assembly Installation (Bottom).

Step 5A - Standard In-Line Slide Handle Installation

5A.1 Ensure the wire rope is still fed through the center of the coil cord. Hold the slide handle just below the coil cord.

5A.2 Center the coil cord footer between the ears of the slide handle swivel. **Note:** Make sure the fin of the coil cord footer is on the opposite side of the slide handle connector.

5A.3 Remove the 16mm shoulder bolt from the coil cord footer and wire rope and allow the coil cord footer and wire rope to slide down into the slide handle swivel.

5A.4 Once the wire rope, coil cord footer and slide handle swivel are aligned, replace the 16mm shoulder bolt, thereby capturing the wire rope, coil cord footer and slide handle (**diagram 5A**).

5A.5 Thread the coil cord connector into the slide handle connector (**diagram 5A**).

5A.6 Thread the M12 jam nut onto the 16mm shoulder bolt.

5A.7 Check that the coils of the coil cord are centered around the wire rope when properly installed.

5A.8 Continue to Step 6 on page 3-9.




Diagram 5A. Slide Handle, Shoulder Bolt and Coil Cord

Step 5B - Remote Mounted Slide Handle Installation

5B.1 Ensure the wire rope is still fed through the center of the coil cord. Hold the G360™ swivel just below the coil cord assembly.

5B.2 Center the coil cord footer between the ears of the G360™ swivel. **Note:** Make sure the fin of the coil cord footer is on the opposite side of the G360™ connector.

5B.3 Remove the 16mm shoulder bolt from the coil cord footer and wire rope and allow the coil cord footer and wire rope to slide down into the G360™ swivel.




Diagram 5B. G360™, Shoulder Bolt and Coil Cord.

Step 5B - Remote Mounted Slide Handle Installation (Continued)

5B.4 Once the wire rope, coil cord footer and G360™ swivel are aligned, replace the 16mm shoulder bolt thereby capturing the wire rope, coil cord footer and G360™ swivel (**diagram 5B**, page 3-3).

5B.5 Thread the coil cord connector into the G360™ connector (**diagram 5B**, page 3-3).

5B.6 Thread M12 jam nut onto the 16mm shoulder bolt.

5B.7 Check that the coils of the coil cord are centered around the wire rope when properly installed.

5B A pilot hole is provided for the locking pin. Attach tooling to G360™ utilizing M16 thread. The tool bolt/rod thread should be beyond pilot hole of shaft when fully engaged. Using a #21 drill bit, drill through the tool bolt/rod thread and out the other side of G360™ shaft. Hammer pin into place thereby locking tooling to G360™ (**diagram 5C**).

5B.9 Assemble the remote mounted slide handle inside the remote mount bracket using the hardware provided (**diagram 5D**).
Note: This step is best completed on a workbench prior to mounting handle to tooling.




Diagram 5C. Tooling Installation.




Diagram 5D. Remote Mounted Slide Handle, Exploded View.

WARNING

Remote mounted G-Force® handles must be mounted at both the top and bottom of the handle assembly. Failure to mount the remote mounted handle at top and bottom can result in poor performance and/or premature component failure.

5B.10 Attach the remote mounted handle with bracket to the tooling. Assure that the mounting arrangement does not affect the operating function of the slide handle.

5B.11 Connect the extension cable from the G360™ to the remote mounted slide handle. Securely clamp the remote mount coil cord extension cable to the tooling as needed.

CAUTION

All cables used in a remote mounted handle configuration must be properly clamped and/or strain-relieved to prevent premature failure of the G-Force® or customer tooling.

CAUTION

Take care to avoid looping excess cable at locations where the loop could catch on foreign objects.

5B.12 Continue to Step 6 on page 3-9.

Step 5C - Suspended Pendant Handle Installation

5C.1 Assure that the coils of the pendant handle coil cord are centered around the pendant handle wire rope.

5C.2 Remove the eyebolt from suspended pendant cable assembly using the threaded connector.

5C.3 Thread the eyebolt into the bottom of the actuator assembly as shown (**diagram 5E**).

5C.4 Reattach the suspended pendant cable assembly to the eyebolt via the threaded connector.

5C.5 Adjust the suspended pendant cable assembly so that there is a service loop in the wiring cable and there is no tension in the wire cable.

5C.6 Thread the cable assembly connector into the actuator connector (**diagram 5E**).

5C.7 Remove the cotter pin and clevis from the wire rope swivel assembly.

5C.8 Reinsert the clevis and cotter pin capturing the wire rope thimble in the swivel assembly (**diagram 5F**).

5C.9 Continue to Step 6 on page 3-9.




Diagram 5E. Assembly of Suspended Pendant Cable Assembly to Bottom of Actuator Assembly.




Diagram 5F. Cotter Pin, Clevis, Wire Rope Swivel Assembly and Wire Rope Thimble.

Step 5D - Remote Mounted Pendant Handle Installation

5D.1 Ensure the wire rope is still fed through the center of the coil cord. Hold the G360™ swivel just below the coil cord.

5D.2 Center the coil cord footer between the ears of the G360™ swivel. **Note:** Make sure the fin of the coil cord footer is on the opposite side of the G360™ connector.

5D.3 Remove the 16mm shoulder bolt from the coil cord footer and wire rope and allow the coil cord footer and wire rope to slide down into the G360™ swivel.

5D.4 Once the wire rope, coil cord footer and G360™ swivel are aligned, replace the 16mm shoulder bolt thereby capturing the wire rope, coil cord footer and G360™ swivel (**diagram 5G**, page 3-6).

Step 5D - Remote Mounted Pendant Handle Installation (Continued)

5D.5 Thread the coil cord connector into the G360™ connector (*diagram 5G*).

5D.6 Thread the M12 jam nut onto the 16mm shoulder bolt.

5D.7 Check that the coils of the coil cord are centered around the wire rope when properly installed.

5D.8 A pilot hole is provided for the locking pin. Attach tooling to G360™ utilizing M16 thread. The tool bolt/rod thread should be beyond pilot hole of shaft when fully engaged. Using a #21 drill bit, drill through the tool bolt/rod thread and out the other side of G360™ shaft. Hammer pin into place thereby locking tooling to G360™ (*diagram 5H*).

5D.9 Attach the pendant handle bracket directly to the tooling. Assure that the mounting arrangement does not affect the operating function of the pendant handle. Note: If necessary, a collar clamp mounting bracket option can be used to attach the pendant handle to the tooling (*diagram 5I*).

5D.10 Connect the extension cable from the G360™ to the remote mounted pendant handle. Securely clamp the remote mount coil cord extension cable to the tooling as needed.




Diagram 5G. G360™, Shoulder Bolt and Coil Cord.




Diagram 5H. Tooling Installation.




Diagram 5I. Remote Mounted Pendant Handle with Collar Clamp Mounting Bracket (Option).

CAUTION

All cables used in a remote mounted handle configuration must be properly clamped and/or strain-relieved to prevent premature failure of the G-Force® or customer tooling.

CAUTION

Take care to avoid looping excess cable at locations where the loop could catch on foreign objects.

5D.11 Continue to Step 6 on page 3-9.

Step 5E - 1320 lb. Inline Slide & Remote Mounted Handle Installation

5E.1 With the actuator hanging from rail or other support structure, thread the free end of the wire rope through the wear ring bracket and use the supplied hardware to attach the bracket to the actuator.

5E.2 Thread the free end of the wire rope through the coil cord assembly so it hangs below the coil cord mounting plate and attach the wear ring bracket using the supplied hardware (**diagram 5J**).

5E.3 Insert Turck connector on coil cord into mating connector on the underside of the actuator.

5E.4 Grab the free end of the wire rope and loop it up towards the underside of the actuator, ensuring there are no twists or kinks in the rope. Feed the U-bolt through the wire rope thimble and insert the U-bolt into the appropriate holes in the reinforcement plate. Using supplied hexnuts, securely tighten U-bolt to the plate (**diagram 5K**).

5E.5 Attach the plate to the underside of the actuator using the supplied cap screws, lockwashers, and spacers as shown and ensure hardware is now completely tightened. (If an air hose is being installed, leave hardware loose for now.)

5E.6 While holding the handle or G360™, loop the pulley through the wire rope and slip the pulley and side spacers down between the plates (**diagram 5L**, page 3-8).

5E.7 Align the holes in the plates with the spacers and the bearings, insert the pulley pin, and install the snap ring on the pulley pin.

5E.8 Using the supplied cap screws and lockwashers, attach the coil cord mounting plate to the top of the handle or G360™.

5E.9 Attach the coil cord Turck connector to the mating connector in the top of the handle or G360™ and use the supplied cap screw to attach the strain relief clamp to the side plate so there is a small service loop at the connector.

5E.10 Continue to Step 6 on page 3-9.




Diagram 5J. Assembly of Wire Rope to 1320 lb. Actuator Assembly.




Diagram 5K. Attaching U-bolt and Reinforcement Plate to Actuator Assembly.

Step 5F - 1320 lb. Suspended Pendant Handle Installation

5F.1 With the actuator hanging from rail or other support structure, thread the free end of the wire rope through the wear ring bracket and use the supplied hardware to attach the bracket to the actuator (**diagram 5J**, page 3-7).

5F.2 Thread the free end of the wire rope through the wear ring and attach the wear ring to the wear ring bracket using the supplied hardware.

5F.3 Grab the free end of the wire rope and loop it up towards the underside of the actuator, ensuring there are no twists or kinks in the rope. Feed the U-bolt through the wire rope thimble and insert the U-bolt into the appropriate holes in the reinforcement plate. Using supplied hexnuts, securely tighten the U-bolt to the plate (**diagram 5K**, page 3-7).

5F.4 Attach the plate to the underside of the actuator using the supplied cap screws, lockwashers and spacers as shown and ensure hardware is completely tightened. (If an air hose is being installed, leave hardware loose for now).

5F.5 Insert eyebolt at the end of the pendant cable into the threaded hole on the reinforcement plate and tighten. Insert Turck connector into mating connector or the underside of the actuator.

5F.6 While holding the G360™, loop the pulley through the wire rope and slip the pulley and side spacers down between the plates (**diagram 5L**).

5F.7 Align the holes in the plates with the spacers and the bearing, insert the pulley pin, and install the snap ring on the pulley pin.

5F.8 Using the supplied cap screws and lockwashers, attach the coil cord mounting plate to the top of the G360™.

5F.9 Continue to Step 6 on page 3-9.




Diagram 5L. Attaching Wire Rope to Pulley.

Step 5G - 1320 lb. Air Hose Assembly Installation (Optional)

5G.1 The air hose assembly comes attached to the wear ring and coil cord mounting plate. Once the handle installation is complete, the air hose should be installed.

5G.2 Remove two of the screws and lockwashers holding the reinforcement plate to the underside of the actuator (leaving the spacers in place) and insert them through the air hose bracket and reattach to the underside of the actuator. Tighten all hardware.

5G.3 At the handle or G360™, insert the male swivel fitting at the end of the air hose into the female end of the elbow in the footer and tighten.

5G.4 Connect the bulkhead fitting on the underside of the actuator to shop air and check for leaks.

Step 6 - Electrical Power Connection

➔ **TIP:** Do not connect main power until all assembly is complete.

Standard

- 6.1 Prior to final wiring, inspect the entire system to ensure that all connections are seated properly and are without kinks or bends. Verify the following connections:
- Coil cord to handle or G360™ collector
 - Coil cord to actuator assembly
 - Extension cables (if included)
- 6.2 Connect a 220 VAC single-phase power source through a disconnect switch (by others) to the festooned power cabling (not provided with G-Force®).

WARNING

The power mains connection to the G-Force® unit is to measure 1 x 220 VAC +/- 10%. Voltages outside this range may result in unexpected motion and/or premature controls failure.

- 6.3 Wire the female receptacle (provided) to the end of the festooned power cable.
- 6.4 After verifying the disconnect switch is turned **OFF**, connect the newly installed receptacle to the male plug at the G-Force®.

Step 7 - Initial Power-Up

- 7.1 Turn on the disconnect switch (by others) to apply power to the G-Force®. When power is detected, "POWER ON" is displayed on the LCD.
- 7.2 Disengage the emergency stop (E-stop) button located on the front face of the handle.
- 7.3 During the system power up the LCD at the handle will display "UNIT POWER-UP".
- 7.4 Once the system is on-line and ready, "LIFT READY" will be displayed on the LCD.
- 7.5
- **Standard Operation - Slide Handle Configuration:** Grasp the handle grip to run the unit up and down. Do this several times to get a feel for the unit. The LCD displays RUN MODE HANDLE.
 - **Standard Operation - Pendant Handle Configuration:** Depress the up and down levers to run the unit up and down. Do this several times to get a feel for the unit. The LCD displays RUN MODE PENDANT.

Note: The LCD backlight will shut off after 10 minutes of inactivity.

➔ **TIP:** The operator should always keep their hand under the operator present sensor on the slide handle while operating the unit in standard mode. If the hand is frequently moved away from the operator present sensor it will result in jerky movement from the unit.

- 7.6 Finally, test the operation of any special tooling that may have been integrated to the G-Force®.

➔ **TIP:** Gorbel, Inc., does not provide integrated tooling for the G-Force®. All tooling related questions should be directed to the tooling manufacturer or supplier.

Step 8 - Float Mode and Final Steps

► **TIP:** Gorbel® Inside Sales is available from 7am to 7pm Eastern Time Monday - Thursday and 7am to 5pm Eastern Time Friday.

8.1 Float Mode may be activated by simply pressing the G-Force® logo button on the left hand side of the handle (*diagram 8A*). Below is a simple exercise to practice if you are not familiar with the Float feature. (This exercise assumes an in-line slide handle is being used).




Diagram 8A. Float Mode Button - Slide Handle.

- A) Grasp the handle grip and lift an object weighing at least 20 lbs. (9 kg) to a comfortable height in front of you.
- B) Let go the of the handle grip.
- C) Press the G-Force® logo button on the handle. **Note:** Do not hold onto the load. Applying an upward or downward force on the handle or load while initiating Float Mode will give the unit a false reading and cause excessive drift.
- D) After Float Mode is initialized, the “blue” LED light will turn on and the handle with payload should not be moving. The LCD will display RUN MODE FLOAT.
- E) Now grasp the load.
- F) To move the load down, put vertical pressure on the load downward, towards the floor. To move the load up, lift up on the load, towards the ceiling. **Note:** The direction and speed of travel is now being controlled by the amount of force that the operator exerts directly onto the load. The higher the force exerted on the load, the faster the unit moves. **Note:** An over-speed detection routine checks if Float Mode reaches 90% of the maximum fully loaded lifting speed and shuts the unit down. It safely limits the maximum speed of travel in Float Mode.
- G) Run the unit up and down several times (at least 20 times in each direction) to assure proper operation. Float Mode should provide a smooth feel.

CAUTION

Actuating the operator present switch while in Float Mode will cause the unit to exit Float.

- H) Repeat this exercise until you become comfortable with Float Mode.

Step 8 - Float Mode and Final Steps (Continued)

WARNING

NEVER remove the load from the G-Force® while still in Float Mode. The control system will interpret the removal of the load as operator intent to lift the load. Therefore, the unit will begin to drift up. The speed of the unit drift directly correlates to the weight that was removed from the unit. The heavier the weight, the faster the unit will travel.

WARNING

In Float Mode, the live load weight CANNOT be increased or decreased because this will cause unwanted motion. Float Mode must be reinitiated each time the weight of the live load is changed.

CAUTION

If external forces are applied to the load while Float Mode is being initiated, the G-Force® will calculate a baseline weight that is higher or lower than the actual weight being lifted. When the external force is removed, the load will begin to drift in the opposite direction of the load that was applied.

- 8.2 The speed, acceleration, and other features of the G-Force® can be adjusted using the Program Menu available at the handle. **See the *Program Mode* section on page 5-2 for complete details on modifying and programming features.**

Step 9 - Expansion I/O Block Mounting Instructions (Option)

► **TIP:** Expansion I/O block mounting instructions only apply to iQ units with an I/O block.

Dimensions




Diagram 9A. Expansion I/O block dimensions (millimeters).




Diagram 9B. Screw fastener drilling template.

Step 9 - Expansion I/O Block Mounting Instructions (Option) (Continued)

Installation

- 9.1** The I/O block can be installed into different locations (e.g. to an aluminum frame, to DIN rail, to a mounting plate, or directly on the machine). The minimum base plate thickness is 1.5 mm and the screw length should thus be selected accordingly. The recommended torque on the M4 screw is of 0.6 Nm.




Diagram 9C. Base plate and screw length selection.

Installation examples:




Diagram 9D. Installation on an aluminum frame, DIN rail or mounting plate.

Chapter 4 - Removal Procedure

If it has been determined that the G-Force® Q or iQ system must be returned to Gorbel or another authorized service location, or if the system is being relocated for some other reason, please follow the guidelines listed below:

1. Locate the original shipping box and materials or use a suitable alternative if necessary. Gorbel can provide a new shipping box upon receipt of a purchase order. Do not ship the unit anywhere strapped to a pallet or inside an empty box without any protection or packing material.
2. Disconnect any tooling or non-Gorbel® accessories including air hose fittings, external electrical switches, harnesses, etc. Do not send any of these items back unless specifically requested by Gorbel® Inside Sales.
3. If possible, before powering off the system and disconnecting the control handle, raise the wire rope assembly to the upper limit.
4. Disconnect the coil cord assembly from both the actuator and the handle or swivel assembly. Pack these components carefully to avoid shipping damage (**diagram 1**).




Diagram 1.

5. If you are returning the system to Gorbel for service, upgrading, etc., mark the box clearly with the RMA (Return Material Authorization) number supplied by Gorbel® Inside Sales (800-821-0086) and include a copy of the RMA in the box whenever possible. Do not send any components back to Gorbel without an RMA.

Chapter 5 - Control and Programming

Controls Interface Features

The jog switch push buttons and communications connector are protected by a cover (**Diagram 1**). To access the jog switch push buttons and communications connector, loosen the M4 screw and slide the shield back towards the wire rope. **Note:** Do not fully unthread the M4 screw. When finished, slide the shield back into place and re-tighten the M4 screw.

Jog Switch Push Buttons: The jog switch buttons allow qualified personnel to replace the wire rope on the unit. To effectively operate the jog switch buttons, all electrical cables must be connected and power on. Depressing the “Up” jog switch button will enable the motor and cause the system to reel the wire rope into the actuator and onto the drum pulley. Depressing the “Down” jog switch button will enable the motor and cause the system to pay out the wire rope from the actuator and off of the main pulley. Jog switch push buttons override all motion control from a handle or tooling.




Diagram 1. Actuator - Controls Interface Display (as viewed from bottom of actuator).

WARNING

The jog switch buttons are for system maintenance and load testing use only and should not be manipulated during normal operation of the G-Force®. Operation of the jog switch buttons during normal operation increases the risk of personal injury to the operator.

Service Mode: This operation mode is similar to the “safe mode” of a PC. In this state all handle motion control and Q & iQ custom features are disabled, all digital outputs are turned off, and only basic jog up, jog down, LCD display and safety program mode are available. It allows a minimum safe operation on a unit with a damaged handle, broken I/O electronics or other damaged peripheral control components that would make it dangerous to run the unit if the component is used. The unit is still inoperative if actuator components such as the drive, motor, or jog switches are damaged. To activate service mode, with the handle E-stop pushbutton released and the LCD screen displaying LIFT READY, press and hold both jog pushbuttons on the actuator for ten seconds. Both the blue and red LEDs flash once per second and the LCD displays SERVICE MODE when the operation mode is ready.

Communications Connector: This connector is the communications port for the G-Force®. With the program kit (option), provided by Gorbel, users may connect to the G-Force® to upload software programs or use the G-Force® Visual Basic program.

Program Mode Overview (Software Version R1.07.0)

Program Mode is used to control and adjust all of the features on the Q and iQ series G-Force®. Before entering Program Mode review the **Program Mode Menu outline, Chart 4, pages 5-7 through 5-11**.




Diagram 2. Slide Handle - G-Force® Logo (Float Mode), MENU and Emergency-Stop Buttons and LEDs.




Diagram 3. Pendant Handle - G-Force® Logo (Float Mode), MENU and Emergency-Stop Buttons and LEDs.

Entering Program Mode (**chart 1, page 5-4**):

1. **Press and Hold** the MENU button (right-hand side of handle) for two seconds to activate Program Mode.
2. After two seconds, release the MENU button. The red and blue LEDs will illuminate and “PROGRAM MODE” will be displayed for one second. Then the first menu will be displayed.
 - Q unit: SPEED MENU (default). **Note:** If the Virtual Limits Package has been ordered, the Virtual Limits Menu (V-LIMITS) will appear first.
 - iQ unit: V-LIMITS MENU
3. Press the MENU button to toggle between menus. The LCD will display the corresponding programmable menus:
 - V-LIMITS MENU - Virtual Limits menu (**option**)
 - SPEED MENU - Lift Speed adjustment
 - RESPONSE MENU - Lift Response (acceleration) adjustment
 - SETTINGS MENU - Programmable Features on both the Q and iQ units
 - SETTINGS MENU 2 - Programmable Features on iQ units only (**iQ only**)
 - LED MENU - Program the LED lights (**iQ only**)
 - SERVICE MENU - Customize and manage maintenance and service features
 - CONFIGUR MENU - Special unit features and hardware configurations
4. Once you have reached the menu you would like to enter, press the G-Force® logo button.
5. The first programmable feature in that menu will be displayed. **Chart 4**, pages 5-7 thru 5-11, displays a full list of all the menus and programmable features under each menu.
6. To move to the second programmable feature press the G-Force® logo button again.
7. **Note:** If the MENU button is pressed after Step 4, the selection is cleared and the LCD displays the next program menu.
8. Once the desired feature is selected wait three seconds.
9. After displaying the feature text for three seconds, the request is executed. The LCD will flash the feature text several times to indicate the command is being executed.
10. After the command is executed, the system returns to standard operation, and the LCD displays “LIFT READY”.

Handle Operation



Make sure to keep fingers clear of the photo sensor area when in program mode. Breaking the photo sensor will drop the unit out of program mode and you will need to start over again.

When making changes in program mode, do not break the beam of the photo sensor until the new setting has been completed. The display must be allowed to flash three times before the handle is gripped. Breaking the sensor beam before the display flashes three times will cancel the change and drop the unit out of program mode and you will have to start over.

When the unit is not in program mode, press and release this button to initiate float mode.

When the unit is in float mode, use this button to select the desired item within the menu by pressing and releasing to advance to the next selection



Press and hold this button for approximately three seconds until the unit enters program mode. Once in program mode, this button is used to select the desired menu. Press and release this button to advance to the next menu. If you happen to accidentally pass by a menu, it will come around again if you continue to press and release this button.

If you stay on a menu item selection for approximately three seconds, the display will blink three times and the change will be made. Keep advancing through the menu items quickly until you are certain of the change you want to make. Otherwise, you may accidentally make an undesired change.





Chart 1. Program Mode Process.




Chart 2. Program Mode Main Menu (Solid Border) and Sub-Menu (Dotted Border) Layouts.

Lockout Feature (*chart 3*)

To prevent tampering in Program Mode, a Lockout Feature is available.

To Lockout Program Mode:

1. Press both the G-Force® logo button and the MENU button simultaneously for five seconds.
2. The LCD will display “LOCKOUT CHECK” while both buttons are being depressed.
3. After five seconds, “PROGRAM LOCKED” will be displayed to confirm the Lockout was successful.

If Program Mode is requested after the Lockout has been enabled, the LEDs will flash twice to indicate Program Mode is not accessible and “PROGRAM LOCKED” will be displayed again.

To Unlock Program Mode:

1. Press both the G-Force® logo button and the MENU button simultaneously for five seconds.
2. The LCD will display “UNLOCK CHECK” while both buttons are being depressed.
3. After five seconds, “PROGRAM UNLOCKED” will be displayed to confirm the Lockout was successful.




Chart 3. Lockout Feature Process.

Safety Program Mode

If the G-Force® has detected a fault or is running in SERVICE MODE, only a limited set of menus are accessible.

For example, if the G-Force® records a fault, when Program Mode is activated the LCD will display “LIMITED PRG MODE” rather than “PROGRAM MODE”. Safety Program Mode can be navigated just as Program Mode would be, however the only menus available are:

- V-LIMITS MENU - Virtual Limits menu (*option*)
- SPEED MENU - Lift Speed adjustment
- RESPONSE MENU - Lift Responsiveness (Acceleration) adjustment
- SERVICE MENU - Customize and manage maintenance and service features

Program Mode	Menu	LCD Text	Feature Description
Virtual Limits (VL) Menu^{*,**,**} (also available for Q unit with Software Package)	V-LIMITS MENU ^{1,2}	UPPER LIMIT	Program the upper virtual limit (load must be at desired position for upper limit).
		LOWER LIMIT	Program the lower virtual limit (load must be at desired position for lower limit).
		LOWER SLOW DN	Program the lower slow down reduction point (load must be at position where slow-down begins when descending).
		UPPER SLOW DN	Program the upper slow down reduction point (load must be at position where slow-down begins when raising load).
		UPPER RESUME	Program the upper speed resume point (load must be at position where system will resume normal speed when raising load).
		VL MENU -RESET!	Reset all programmed virtual limits in this menu.
Lift Speed Setting	SPEED MENU	SPD MENU SPD 10% ~ SPD 100%	Maximum hoist speed selection, [1 ~ 10] correspond to lowest and highest speed.
Lift Responsiveness (Acceleration) Setting	RESPONSE MENU	RESPONSE LOW	Set the lowest handle control response corresponding to about 75% of the highest responsiveness setting.
		RESPONSE MEDIUM	Set the medium handle control response corresponding to about 85% of the highest responsiveness setting.
		RESPONSE HIGH	Set the highest handle control responsiveness setting.
Q & iQ Custom Features	SETTINGS MENU	ZERO WT DISP	Record and tare out the handle weight for weight readout calculation.
		WEIGHT READ ON READ OFF	Toggle between enabling and displaying the load weight. Once enabled, weight is displayed two seconds into standard operation (unit idling).
		DISPLAY METRIC ENGLISH	Toggle the unit of the weight readout display between pounds (English) and kilograms (Metric).
		FM SETUP SUB-MENU	Access Float Mode Configuration Setup Sub-Menu.
		USR OVLD SUB-MENU	User Programmable Overload Setup Sub-Menu.
		SETTINGS -RESET!	Reset above Custom Features, i.e. reset tarred handle weight, weight readout off, and readout display back to English unit.
[SUB-MENU] Float Mode Configuration Setup	FM SETUP SUB-MENU	FM SETTINGS	Startup prompt screen when this sub-menu is accessed.
		ENABLE DISABLE FLOAT MO	Enable or Disable running Float Mode related features, such as Standard Float Mode, Remote-Mount Float Mode Trigger, Dual Float Mode Weights, etc.
		FM ANTI-RECOIL	Float Mode Anti-Recoil Configuration Sub-Menu.
		UNLOAD STOP ON STOP OFF	Optional feature utilizing Anti-Recoil detection. When user sets a weight onto a surface in Float Mode, it is terminated if Anti-Recoil detects an unloading. This can be useful for applications needing a quick Float Mode exit to an idle state to allow user to work on the part. Note: As a result of the extra detection, Float Mode is <u>likely</u> to terminate when the upper limit switch is hit while unit is running at a fast speed. This false detection can be avoided or reduced by running the unit at a low speed.

Chart 4. (continued on pages 5-8 thru 5-11) Program Mode Menu and Selection Settings.

Program Mode	Menu	LCD Text	Feature Description
[SUB-MENU] Float Mode Anti-Recoil Configuration Setup	FM ANTI-RECOIL	OVER FORCE SPEED	Startup screen when this sub-menu is accessed. The correct configured Anti-Recoil detection method is displayed (see next item for details on the detection methods).
		OVER FORCE SPEED	Toggle Anti-Recoil detection method between standard over-speed and over-force detections. Anti-Recoil protects against a dropped weight while running Float Mode causing the unit to speed upward until hitting an object or a push force equivalent to the dropped weight. Over-Speed Detection: Unit terminates Float Mode if speed exceeds maximum Float Mode speed at 90% of unit loaded speed. Over-Force Detection: Unit terminates if user's operating force exceeds the maximum force limit or a dropped weight is detected by evaluating the force profile. Different from Over-Speed Detection, unit can run at the maximum Float Mode speed. a. Maximum force limit defaults at 35 lbs. b. A dropped weight profile assumes the operator has both hands off the weight (tooling) as the unit speeds upward. Detection ability may reducer if user attempts to stop the unit or if the tooling swings heavily. c. If the total lifted weight (e.g. tool and part) is less than the maximum force limit, Over-Speed Detection is applied.
		MX FORCE 15 ~ 45 LBS	Set Anti-Recoil Over-Force Detection maximum force limit between 15 and 45 lbs.
		DEFAULT SETTINGS	Unit reset to the default setup according to the configured detection method. For example, unit configured with Over-Force Detection defaults to 35 lbs. maximum force limit, dropped weight profile checkup and conditional Over-Speed Detection. UNLOAD STOP option is turned off for both methods.
[SUB-MENU] User Programmable Overload Setup	USR OVLD SUB-MENU	USR OVLD SETUP	Startup prompt screen when this sub-menu is accessed. Please activate weight readout while setting an overload limit, to ensure that the load cell is properly calibrated and the desired overload limit is within the acceptable range. Please see WEIGHT READ ON_ under SETTINGS MENU for additional details.
		CHANGE OLVD LMT	Program an overload limit.
		CHANGE OP FORCE	Configure operating force limit for moving a load in air.
		CHANGE SENSITIV	Configure overload detection sensitivity.
		DEFAULT SETTINGS	Apply factory default settings. Overload limit is set as the maximum limit which is 101% of the rated capacity plus 12 lbs to account for a handle weight. The operating force limit is set at 15 lbs and detection sensitivity is set to 5 (High).
Program an Overload Limit	CHANGE OVLD LMT	CHANGE OVLD LMT	Startup prompt screen displaying the programmed overload limit. User Overload feature adjusts the detection and over limit parameters proportional to programmed Overload Limit. The over limit when overload is triggered is at M% above the Overload Limit plus the Operating Force Limit (see CHANGE OP FORCE section for info). An over limit is roughly set at: G-Force®: 120% x Overload Limit + OP FORCE East Arm®: 105% x Overload Limit + OP FORCE
		TARE OVLD LMT	Tare the total weight as Overload Limit. When selected, unit tares the lifted weight supported by the wire rope as the Overload Limit. This value can be monitored through the Weight Readout feature without zeroing the reading (see SETTINGS MENU). For G-Force® and Easy Arm® 165 lb. units, the maximum limit is 175 lbs. For all other capacities, the maximum limit is 101% of the rated capacity plus 12 lbs for a handle weight. The minumum limit is 25% of the rated capacity. A warning is triggered if the tare weight is outside this range. Overload Limit is capped at one of these bounds.
		SET LIMIT LBS NNNN	Set Overload Limit to the selected NNNN lbs limit. TARE OVLD LMT section lists a range of the maximum and minimum limits for Overload Limit. Clicking the G-Force® Logo pushbutton decrements the limit from the maximum down to the minimum, one lb at a time. The button can be pressed and held to decrease the count at a faster rate. Once the minimum value is reached, click the pushbutton to restart from the setup screen; otherwise, the minum limit is applied after the pushbutton is released.

Chart 4. (continued from page 5-7 & continued on pages 5-9 thru 5-11) Program Mode Menu and Selection Settings.

Program Mode	Menu	LCD Text	Feature Description																		
Configure Operating Force Limit for Moving a Load in Air	CHANGE OP FORCE	AT FORCE LBS NNNN	Startup prompt screen displaying the programmed Operating Force Limit. Operator's push and pull force is an extra loading to the system, especially when handle is mounted on the tooling. This sub-menu allows one to set a Force Limit to account for different user's operating force thus reducing chance of false overload detection. The limit should not be set larger than necessary as it reduces detection capability. By default, the limit is set at 15 lbs.																		
		TO FORCE LBS NN	Set Operating Force Limit to between 5 and 25 lbs in 1 lb increments.																		
Configure Overload Detection Sensitivity	CHANGE SENSITIV	AT LEVEL 5 (HIGH) ~ 1 (LOW)	Startup prompt screen displaying the programmed Detection Sensitivity. This feature may falsely detect varying weight as overloaded, for example, on a system with unbalanced or elongated tooling that sways easily during usage, or a less rigid supporting structure that induce much vibration. The sensitivity parameter can be reduced to prevent false detection when operating a load at no greater than the Overload Limit. However, do not reduce the sensitivity unless it is necessary due to actual usage. A reduced sensitivity increases the time to detect a legitimate overload condition that may result in damages or failure to the unit. By default, Detection Sensitivity is set at 5 (HIGH).																		
		TO LEVEL 5 (HIGH) ~ 1 (LOW)	Set Detection Sensitivity to between 5 (HIGH) and 1 (LOW) one level decrements at a time.																		
iQ Features*,**	SETTINGS MENU 2	DUAL FM TOOL WT	(Float Mode feature enabled) Record tooling weight for the Dual Float Mode weights feature.																		
		DUAL FM LOAD WT	(Float Mode feature enabled) Record tooling and load weights for the Dual Float Mode weights feature.																		
		ANTIDROP TOOL WT	Tare tooling weight for anti-drop feature. The minimum difference between unloaded and loaded tool weight is 20 lbs. for G-Force®, 25 lbs. for Easy Arm® and 25 lbs. for G-Jib™.																		
		MENU 2 SET HOME	Program the auto home tracking position (load must be at desired position for the limit).																		
		MENU 2 -RESET!-	Reset above custom features including the dual Float Mode, anti-drop, and auto home features.																		
LED Config Menu*,**: Programs the blue LED as an indicator)	LED MENU	RESET LEDES	Disable any custom feature (e.g. anti-drop) from utilizing the blue LED as an indicator.																		
		ANTI DROP	Enables the blue LED on the control handle to act as an indicator for the anti-drop function. When this function is enabled and the anti-drop output is off (off is typically the grip/clamp state of the tooling), the blue LED will flash until the anti-drop output turns on (on is typically the release state of the tooling).																		
		SLACK ANTIDROP	Set Slack Anti-Drop to use the blue LED for indication identical to ANTI-DROP above. This selection is not available by default because this is a disabled built-in feature.																		
Dual Actuator Configuration Menu*,*** (Dual Actuator option required)	DUAL ACT MENU	MOTION INDEPEND SYNC	Item is only selectable if the dual-actuator system is set to manual configuration, SETUP MANUAL.																		
		SETUP MANUAL AUTO	A dual-actuator system defaults to AUTO configuration, i.e. the system automatically configures the various run mode controls to INDEPEND or SYNC linking. If MANUAL option is selected, user can choose to overwrite some of the controls to a specific mode as programmed through MOTION INDEPEND\SYNC. The breakdowns are as such: <table border="0" style="width: 100%; border-collapse: collapse;"> <tr> <td style="text-align: left;"><u>RUN MODE</u></td> <td style="text-align: center;"><u>AUTO</u></td> <td style="text-align: center;"><u>MANUAL</u></td> </tr> <tr> <td>Jog Switch</td> <td style="text-align: center;">INDEPEND</td> <td style="text-align: center;">SELECTABLE</td> </tr> <tr> <td>Slide Handle</td> <td style="text-align: center;">SYNC</td> <td style="text-align: center;">SELECTABLE</td> </tr> <tr> <td>Pendant Handle</td> <td style="text-align: center;">SYNC</td> <td style="text-align: center;">SELECTABLE</td> </tr> <tr> <td>Float Mode</td> <td style="text-align: center;">INDEPEND</td> <td style="text-align: center;">INDEPEND</td> </tr> <tr> <td>Custom Motion</td> <td style="text-align: center;">SYNC</td> <td style="text-align: center;">SELECTABLE</td> </tr> </table>	<u>RUN MODE</u>	<u>AUTO</u>	<u>MANUAL</u>	Jog Switch	INDEPEND	SELECTABLE	Slide Handle	SYNC	SELECTABLE	Pendant Handle	SYNC	SELECTABLE	Float Mode	INDEPEND	INDEPEND	Custom Motion	SYNC	SELECTABLE
		<u>RUN MODE</u>	<u>AUTO</u>	<u>MANUAL</u>																	
Jog Switch	INDEPEND	SELECTABLE																			
Slide Handle	SYNC	SELECTABLE																			
Pendant Handle	SYNC	SELECTABLE																			
Float Mode	INDEPEND	INDEPEND																			
Custom Motion	SYNC	SELECTABLE																			
SETUP -RESET!-	Default dual-actuator feature settings to SYNC linking mode and AUTO configuration setup.																				
Service Menu: Maintenance and Service Features	SERVICE MENU	SRV MENU UP CYCLE	Program upper limit for the cycle count.																		
		SRV MENU LO CYCLE	Program lower limit for the cycle count.																		

Chart 4. (continued from pages 5-7 & 5-8, and continued on page 5-10 & 5-11) Program Mode Menu and Selection Settings.

Program Mode	Menu	LCD Text	Feature Description
Service Menu: Maintenance and Service Features (Continued)	SERVICE MENU (Continued)	DISPLAY SYS INFO	Enable/disable displaying of usage data. When enabled, text display cycles between system time, run time, cycle counts, and the software version number once per second.
		CLEAR COUNT	Reset cycle count to zero.
		CLEAR RUN TIME	Reset run time to zero.
		SRV WARN OFF	Reset the warning or the time limit of the Maintenance Service Indicator* feature. Does not reset the current run time. Note: The warning can also be reset by selecting CLEAR RUN TIME.
		SRV WARN 500 HRS	Configure the time limit of the Maintenance Service Indicator* feature on I/O point 7 (see diagram F) to 500 hours.
		SRV WARN 1000 HRS	Configure the time limit of the Maintenance Service Indicator* feature on I/O point 7 (see diagram F) to 1000 hours.
		SRV WARN 1500 HRS	Configure the time limit of the Maintenance Service Indicator* feature on I/O point 7 (see diagram F) to 1500 hours.
		CFG MENU ENABLE	When the LCD screen asks to enter a key code, click the Menu button three times followed by another three clicks on the G-Force® Logo button to access the Configuration Menu.
		STANDARD DIAGNOSE	Standard Diagnostic Mode displays all handle pushbuttons, sliding gripper or pendant lever position, load cell weight reading, and limit switches status on the LCD screen.
		LIFT I/O DIAGNOSE	iQ Actuator Input/Output Module Diagnostic Mode displays the status of the eight configurable inputs and outputs on the LCD screen. The inputs statuses are displayed in the first screen followed by those for the outputs. The I/O Point number of the input that measures incoming 24VDC or output that is turned on to provide 24VDC is displayed in each screen as numerical numbers, 1 ~ 8.
		I/O BLK1 DIAGNOSE	[iQ Only] First (Primary) Expansion Input/Output Block Diagnostic Mode displays the status of the eight configurable inputs and outputs on the LCD screen. The inputs statuses are displayed in the first screen followed by those for the outputs. The I/O Point number of the input that measures incoming 24VDC or output that is turned on to provide 24VDC is displayed in each screen as numerical numbers, 1 ~ 8.
		I/O BLK2 DIAGNOSE	[iQ Unit with Custom or Reconfigured Program] Second Expansion Input/Output Block Diagnostic Mode displays the status of the eight configurable inputs and outputs on the LCD screen. The inputs statuses are displayed in the first screen followed by those for the outputs. The I/O Point number of the input that measures incoming 24VDC or output that is turned on to provide 24VDC is displayed in each screen as numerical numbers, 1 ~ 8.
		I/O BLK3 DIAGNOSE	[iQ Unit with Custom or Reconfigured Program] Third Expansion Input/Output Block Diagnostic Mode displays the status of the eight configurable inputs and outputs on the LCD screen. The inputs statuses are displayed in the first screen followed by those for the outputs. The I/O Point number of the input that measures incoming 24VDC or output that is turned on to provide 24VDC is displayed in each screen as numerical numbers, 1 ~ 8.
SRV MENU -RESET!-	Reset all programmed features in this menu such as the upper and lower cycle limits and the service indicator time limit if the feature is available. Does not clear the run time and cycle counts.		
Special Unit Features and Hardware Configurations	CONFIGUR MENU	RECORD CONFIG	Record the current unit system configuration settings such as unit type and capacity setting, factory overload settings, loadcell calibration parameters, virtual limit software package enabling flag for Q unit, burn-in status and all the custom feature setup parameters.
		ZERO LOD BIAS	Set loadcell bias signal with no weight attached to define a "zero" value (requires Float Mode option).
		CALIBRAT LOD COEF	Set loadcell signal slope coefficient with a lifted weight equal to the rated capacity of the unit below the wire rope. Any different lifting weight will result in false calibration and inaccuracy such as weight readout feature (requires Float Mode option). This step must be performed after zero load bias.
		PRESET SUB-MENU	Access predefined sets of Q/iQ feature configurations including factory default setup.

Chart 4. (continued from pages 5-7 thru 5-9 & continued on page 5-11) Program Mode Menu and Selection Settings.

Program Mode	Menu	LCD Text	Feature Description
[SUB-MENU] Preset Feature Configuration List	PRESET SUB-MENU	PRESET 1*	I/O Expansion I/O Block (Assignment for one I/O Anti-Drop) 1 Input - Dual Float Mode 2 Input - Anti-Drop 3 Output - Anti-Drop 4 Input - Auto Home 5 Input - External device control (combine with Actuator I/O Module point 5) 6 Input - External device control (combine with Actuator I/O Module point 6) 7 Output - mimic OPS 8 Output - mimic stack
		PRESET 2*	I/O Expansion I/O Block (Assignment for two I/O Anti-Drop) 1 Input - Dual Float Mode 2 Input - Anti-Drop (Clamp) 3 Input - Anti-Drop (Unclamp) 4 Input - Auto Home 5 Input - External device control (combine with Actuator I/O Module point 5) 6 Input - External device control (combine with Actuator I/O Module point 6) 7 Output - Anti-Drop (Clamp) 8 Output - Anti-Drop (Unclamp)
		PRESET 3*	I/O Expansion I/O Block (Two I/O Anti-Drop & System Switches Output) 1 Input - Dual Float Mode 2 Input - Anti-Drop (Clamp) 3 Input - Anti-Drop (Unclamp) 4 Input - Auto Home 5 Output - Handle Operator Present Sensor Status 6 Output - Slack or Down Travel Limit Switch Status 7 Output - Anti-Drop (Clamp) 8 Output - Anti-Drop (Unclamp) The external device control feature previously on I/O5 and 6 is disabled; therefore its corresponding outputs on Actuator I/O Module I/O points 5 and 6 are disabled as well.
		FACTORY DEFAULT	Reset feature assignments back to factory default equivalent to PRESET 2.

* Indicates this feature is only available on iQ units.

** Additional details are available in the Input/Output Functionality section.

*** This menu is hidden unless the optional feature is purchased and installed.

¹ Two (2) virtual limit sets are available with a standard iQ unit. More virtual limit sets are possible with custom programming.

² The minimum distance between any two Virtual Limits is 1", 1/2", 1/4" and 1/8" for any 75Kg, 150Kg, 300Kg, and 600Kg actuators correspondingly, with the exception that the gap between the Upper and Lower Virtual Limits must be greater than 1". The motion control position accuracy to any Virtual Limit is as follows:

+/- 1/4" for G-Force®, Easy Arm®, G-Jib™ 150Kg; +/- 1/16" for G-Jib™ 300Kg, +/- 1/8" for G-Force® 300Kg, +/- 1/16" for G-Force® 600Kg

Note that the actual total accuracy is motion control accuracy plus any mechanical component accuracy constraints. For example, if mechanical component accuracy is +/- 1/4", the total cumulated accuracy is +/- 1/2" for G-Force® 75Kg unit.

Chart 4. (continued from pages 5-7 thru 5-10) Program Mode Menu and Selection

Active Diagnostic Mode Messages

Button, Switch or Sensor	LCD Display Message
G-Force® Logo Button (Float Mode)	Alternately displays: 1. FLOAT BUTTON 2. WEIGHT <i>NNN</i> LBS (Weight Readout Value) 3. SIGNAL # <i>NNNNN</i> (Actual Load Cell Signal)
Menu Button	MENU BUTTON
Operator Present Switch	Alternately displays: 1. HANDLE SWITCH 2. STROKE <i>NNN</i> MAX% (Handle Position % to Maximum Stroke) 3. SIGNAL # <i>NNNNN</i> (Actual Handle Position Signal)
Handle Controller Auxiliary Input	HANDLE <i>N</i> AUX INPUT (<i>N</i> is the handle number in a multi-handle-controller application, e.g. 1 or 2)
Upper Limit Switch	UP TRAVL LIMIT
Lower Limit or Slack Switch	DN TRAVL LIMIT
Both Limit Switches	2 TRAVL LIMITS
Jog Up Button	JOG UP SWITCH
Jog Down Button	JOG DOWN SWITCH
Both Jog Buttons	BOTH JOG SWITCHES

Chart 5. Standard Diagnostic Mode Messages.

Button, Switch or Sensor	LCD Display Message
G-Force® Logo Button (Float Mode)	Alternately displays: 1. FLOAT BUTTON 2. WEIGHT <i>NNN</i> LBS (Weight Readout Value) 3. SIGNAL # <i>NNNNN</i> (Actual Load Cell Signal)
Menu Button	MENU BUTTON
Operator Present Switch	Alternately displays: 1. HANDLE SWITCH 2. STROKE <i>NNN</i> MAX% (Handle Position % to Maximum Stroke) 3. SIGNAL # <i>NNNNN</i> (Actual Handle Position Signal)
Handle Controller Auxiliary Input	HANDLE <i>N</i> AUX INPUT (<i>N</i> is the handle number in a multi-handle-controller application, e.g. 1 or 2)
Upper Limit Switch Actuator 1 (Leader) Actuator 2 (Follower)	UP1 TRAV LMT UP2 TRAV LMT
Lower Limit or Slack Switch Actuator 1 (Leader) Actuator 2 (Follower)	DN1 TRAV LMT DN2 TRAV LMT
Both Limit Switches Actuator 1 (Leader) Actuator 2 (Follower)	UP1 DN1 TRAV LMT UP2 DN2 TRAV LMT
Jog Up Button Actuator 1 (Leader) Actuator 2 (Follower)	UP1 JOG SWTH UP2 JOG SWTH
Jog Down Button Actuator 1 (Leader) Actuator 2 (Follower)	DN1 JOG SWTH DN2 JOG SWTH
Both Jog Buttons Actuator 1 (Leader) Actuator 2 (Follower)	UP1 DN1 JOG SWTH UP2 DN2 JOG SWTH

Chart 6. Custom Diagnostic Mode for Systems Equipped with Dual-Actuator Feature.

Active Diagnostic Mode Messages (Continued)

I/O Status	LCD Display Message
Any of the eight I/O Points configured as Digital Inputs	INPUTS ----- , or INPUTS 12345678 (Only the Input(s) sensing incoming 24VDC displays its I/O Point number)
Any of the eight I/O Points configured as Digital Outputs	OUTPUTS ----- , or OUTPUTS 12345678 (Only the Output(s) turned on to send 24VDC displays its I/O Point number)

Chart 7. Diagnostic Mode Messages for iQ Actuator Input/Output Module or the Expansion 8-Point Input / Output Block.

Virtual Limits Warnings**WARNINGS**

If the upward speed reduction point is being used to reduce the impact of engaging the load “on the fly” (i.e. catching the load with a hook while the G-Force® is already in motion in the upward direction), care must be taken to ensure the speed reduction takes place before the load is engaged. Please program the Upper Slow Down Reduction point at least half an inch to an inch below the exact point of pick-up.

Note: Setting the upper and lower virtual limits to the same position will cause the unit to not travel in either direction.

iQ Actuator Input/Output Module Functionality

I/O Point	Assigned Function	Description	Settings (see chart 1 for instructions on navigating and setting menu functions)
1	Input - Dual virtual limit sets	When this input is turned on, the G-Force® switches to a second independent set of virtual limits. See chart 3 for instructions on setting each of these limit sets.	Second set of virtual limits is done the same as the standard set but with this input on.
2	Future expansion - no default functionality assigned	Functionality may be assigned via custom programming to meet application requirements. Contact your Gorbel® dealer for more details.	
3	Future expansion - no default functionality assigned	Functionality may be assigned via custom programming to meet application requirements. Contact your Gorbel® dealer for more details.	
4	Future expansion - no default functionality assigned	Functionality may be assigned via custom programming to meet application requirements. Contact your Gorbel® dealer for more details.	
5	Output - External device control (requires optional expansion 8-point input/output block)	This output is controlled by input number 5 on the optional expansion 8-point input/output block. When that input is on, output 5 on the iQ actuator input/output module is on and vice versa.	
6	Output - External device control (requires optional expansion 8-point input/output block)	This output is controlled by input number 6 on the optional expansion 8-point input/output block. When that input is on, output 6 on the iQ actuator input/output module is on and vice versa.	
7	Output - Service indicator	This output turns on when service is required (based on hours of use and set at the factory) and may be used to turn on an external service indicator (supplied by others).	The reset function for this output is in the SERVICE MENU, items CLEAR RUN TIME or SRV WARN OFF.
8	Output - Fault indicator	This output turns on when a command fault or drive fault occurs. It does not turn on due to a command warning.	

Chart 8. iQ Actuator Input/Output Module Standard Functionality.




Diagram 4. Actuator CPU Input/Output Block.

Expansion 8-Point Input/Output Block Functionality

I/O Point	Assigned Function	Description	Settings (see chart 1 for instructions on navigating and setting menu functions)
1	Input - Dual load weight Float Mode*	When the G-Force® is in float mode, this input allows switching from one pre-programmed load weight to another. These two weights must remain fixed; otherwise, some drifting can occur if the weight is different than the programmed value.	The two Float Mode load weights programmed are located in SETTINGS MENU 2 - DUAL TOOL WT and DUAL FM LOAD WT. The desired load weight must be suspended from the G-Force® when performing each setting.
2	Input - Anti-drop feature (Clamp request)	This input is typically wired to a clamp request pushbutton. When the input is on, Output #7 (see I/O Point 7) turns on and Output #8 turns off regardless of the tooling loading state.	See I/O Point 3 Settings description.
3	Input - Anti-drop feature (Unclamp request)	This input is typically wired to an unclamp request pushbutton. When the input is on, Output #8 (see I/O Point 8) turns on only if Anti-Drop algorithm determines the suspended load is at or below the set weight (ANTIDROP TOOL WT). If Output #8 turns on, Output #7 is turned off.	Programming to tare weight is located at SETTINGS MENU 2 - ANTIDROP TOOL WT. The empty tooling (including handle controller and other accessories) without a pickup part must be suspended solely by the wire rope when tarring. The minimum difference between unloaded and loaded tool weight is 20 lbs. for G-Force®, 25 lbs. for Easy Arm®, and 25 lbs. for G-Jib™ products.
4	Input - Auto Home	When this input is toggled (momentarily turned on then off again), the G-Force® automatically travels to the set home position in the vertical travel. Tracking stops when obstruction is detected, i.e. Q/iQ G-Force® stops at 10-25 lbs. depending on unit capacity.	The Auto Home position programming is located at SETTINGS MENU 2 - MENU 2 SET HOME. Move the G-Force® to the desired position in the vertical travel before selecting the position setting in this menu.
5	Input - External device control (used in conjunction with actuator output 5)	This input controls input 5 on the actuator input/output module. When this input is on, output 5 on the iQ actuator input/output module is on and vice versa.	
6	Input - External device control (used in conjunction with actuator output 6)	This input controls input 6 on the actuator input/output module. When this input is on, output 6 on the iQ actuator input/output module is on and vice versa.	
7	Output - Anti-drop feature (Clamp Control)	This output is typically wired to actuate the clamping mechanism of an end effector tooling. It turns on when Input #2 (see I/O Point 2) is on and remains latched on when the input is released. It can be turned off by Input #3 (see I/O Point 3).	See I/O Point 3 Settings description.
8	Output - Anti-drop feature (Unclamp Control)	This output is typically wired to actuate the unclamping mechanism of an end effector tooling. It turns on when Input #3 (see I/O Point 3) is on and the Anti-Drop algorithm determines the suspended load is at or below the set weight (ANTIDROP TOOL WT). If it is not turned on, the input can be held momentarily (do not hold on indefinitely) until the tooling is unloaded then the output is turned on. Once the output turns on, it remains latched on when the input is released. It is always turned off with Input #2 (see I/O Point 2).	See I/O Point 3 Settings description.

* G-Force® must have Float Mode feature enabled for this feature to work.

Chart 9. Expansion 8-Point Input/Output Block.

WARNING

Please be aware that software versions prior to R1.07.0 use I/O block model X67BC7321, while those with R1.07.0 and newer require the X67BC7321-1 model. The model number can be found at the left side of the block when placed in the orientation as shown in the diagram. The running software version can be checked through DISPLAY SYS INFO selection under SERVICE MENU in PROGRAM MODE.




Diagram 5. Handle Input/Output Block.

Chapter 6 - Software Update

Gorbel® G-Force® Q/iQ units are shipped out of the factory with the latest released software. The software will be continuously improved by adding new Q or iQ features, expanded feature capabilities, bug fixes, or even a new product line. When a software update or a standard release version is ready, it can be deployed into an existing unit with the **Gorbel® Q/iQ Update Utility** program. The program can connect to the unit, retrieve and store its current settings, upload the new software version and restore the original settings. This program **MUST BE** used to update the software for the users and followed through properly. Any alternative method may corrupt the unit configuration and result in an inoperable unit.

Gorbel® G-Force Software Update Instructions


The following instructions pertain to running the **Gorbel® Q/iQ Update Utility** for Gorbel® G-Force® units.

Installation


Upon insertion of the CD, the installation program should start automatically. If it does not, navigate to the CD in Windows Explorer and run the program called **GorbelUpdate.msi**.

At this point, if you do not have the .NET 2.0 Framework installed on your computer (this is included with most XP and Vista computers) you will be prompted to download and install this before proceeding.

With the .NET 2.0 Framework installed you will be prompted to install the Gorbel® Q/iQ Update Utility on your computer.



Click the **Next** buttons until the software installation is complete and then click **Close** at the following screen.



Starting the Program

Now that the program is installed, you may run the program from the icon on your desktop.



You may also run the program using the Start Menu from the **Gorbels Inc** group.




Using the Program

On program start-up, you will see a prompt reminding you that at times during the update you may see a pop-up box like the one shown below. This is expected and merely needs to be closed to continue with the update.



Step 1

To begin the software update process, choose the location to save temp files that are created by the program. The program may be left at its default (C:\temp) or click the **Select Folder** button and choose an alternate folder anywhere on the computer.




Step 2

In this step, select the port on the computer that is connected to the G-Force® unit. The program will return an error when attempting to connect to the G-Force® in step 2 if the correct COM port is not chosen.




Step 3

This step begins the software update process by saving the current unit's settings so that they may be restored following the software update. Click the **Retrieve and Store Current Settings** button shown below to start the process. A prompt will appear at this point to ensure that the E-stop button is pressed before proceeding with the retrieval.



After this pop-up window closes, the status of the retrieval may be followed in the gauge below the button and in the **Status and Messages** window at the bottom of the screen.




When the retrieval process is complete, this will be indicated by a green success label next to the progress gauge.




Step 4

This step involves choosing the location of the update file that you need to run for the G-Force® unit. The location of this file may be on the CD that contained the Gorbel® Q/iQ Update Utility, sent separately on a CD or delivered via the internet. In any case, contact Gorbel to ensure that the correct update package is being utilized. After confirmation, select the **PIL** file and click the **Open** button in the file dialog window.




The selected file name will then be displayed in the program window.




Step 5

With the update program selected, it is now time to run the software update. Upon clicking the **Run Q/iQ Software Update** button, the **PVI Transfer** program will open in a separate window. This update can take up to 10-15 minutes, but the program will show the current progress so that status of the update can be monitored. At this time do not make any adjustments to the G-Force® unit or press any buttons in the **PVI Transfer** or **Gorbel® Q/iQ Update Utility** windows.




When the software update is complete, a pop-up box will appear as a reminder to cycle the power of the G-Force® unit before proceeding.



Step 6

For the final step of the update process, the previous settings need to be restored to the unit. Click the **Restore Settings** button and the progress of the restore process will be shown in a gauge beneath the button, as well as in the **Status and Messages** box at the bottom of the program window. You will be prompted to depress the E-stop button before beginning the retrieval process.



After the retrieval process is complete, a green label next to the **Restore Settings** button will indicate success.



At this point, the G-Force® unit should be ready to function using the updated software.

Other Functions

There are three additional buttons at the bottom of the program window that perform additional functions. During the normal update process there should be no reason to use these buttons and are only present for debugging when working in conjunction with Gorbel to address problems that may occur during the update process.


Connection Status

This button informs the user of the connection status of the **Task**, **CPU** and **Service** between the G-Force® unit and the computer.



Disconnect PLC

This button manually disconnects the PLC from the computer that is performing the update.

**PVI Manager Status**

This button informs the user of the PVI manager status. The PVI manager allows the G-Force® to share information with the computer.



Troubleshooting Section I: Functional Failure Table

#	Functional Failure	Possible Cause(s)	Suspect Component(s)	Location (page reference)	Corrective Action
1	Blank handle display <i>Note:</i> The LCD screen will go into screen saver mode after 17 minutes of inactivity.	Handle mother board	Damaged / defective mother board	10-41, 10-57	Replace slide or pendant handle mother board
		No DC power to handle	Blown fuse F7 on main PCB	10-10	Replace F7 fuse on actuator main PCB
		Communication Failure	Handle failure	N/A	Repair or replace handle
			Broken or damaged coil cord or connector	10-65 thru 10-69	Repair or replace coil cord
			Loose connector (any applicable cable connection)	8-3 thru 8-5	Repair or tighten connector
			Incorrect cable	8-3 thru 8-5	Replace cable with correct part
			Drive fault	7-5	Refer to Drive Fault tables
PLC (CPU) failure	10-15	Replace PLC (CPU)			
2	Handle display reads: ##### #####	System network communication to the handle is lost.	Handle mother board	10-41, 10-57	Replace slide or pendant handle mother board
			Any CAN bus cable or connection inside actuator or handle	8-3 thru 8-5	Repair or replace cable
			Coil cord or pendant cable	10-65, 10-69	Repair or replace coil cord or pendant cable
			PLC (CPU) failure	10-15	Replace PLC (CPU)
3	No Actuator LEDs	AC power cable	Damaged or defective power cable	8-4	Repair or replace AC power cable
		Drive power cable	Damaged or defective drive cable	8-3	Replace drive cable
		Handle mother board	Damaged or defective mother board	10-41, 10-57	Replace slide or pendant handle mother board
		DC power	Damaged or defective 24 VDC power supply or wiring	10-15, 8-4	Repair wiring, replace DC power supply
		Drive LED	Damaged or defective LEDs on the ACOPOS drive	10-13, 8-3	Replace the ACOPOS drive
		Cable or connection	Loose or disconnected cable (78608)	8-3	Repair or replace cable assembly
4	Unit will not move up or down with handle	Limit switches	A limit switch is actuated	10-35	Jog the unit off the switch
			A limit switch is broken	10-35	Replace the limit switch
			Switch wiring to mother board is disconnected or broken	8-4	Repair the wiring or connection
		Fault present	Unknown	7-4, 7-8 thru 7-24	Refer to Section II
		Handle failure	Blown fuse (F7)	8-4, 10-10	Replace F7 fuse
			Handle mother board failure	10-41, 10-57	Replace slide or pendant handle mother board
			Handle operator present sensor failure	10-40	Repair or replace operator present sensor
			Broken linear transducer core	10-44	Repair or replace linear transducer core
			Any loose connector	8-4, 8-5	Repair or tighten connections
			CAN bus	8-3 thru 8-5	Repair or replace CAN bus cables
			E-stop switch	10-41, 10-60	Repair or replace E-stop switch
		Coil cord or pendant cable	Mechanical handle failure	N/A	Repair or replace handle
			Broken cable	8-5	Replace cable
			Loose connector	8-5	Retighten connection
		Operator error	Incorrect cable	8-5	Replace with correct cable
			Virtual limits set incorrectly	5-5	Check / reset virtual limits
Cable connection	Loose or disconnected cable (78613)	8-4	Reconnect / retighten cable connection		
ACOPOS Drive Fault	See drive fault # to identify cause, e.g.: • input drive fluctuation • drive overcurrent • drive or motor over-temperature • broken or loose motor cable • broken or loose encoder cable	7-8 thru 7-24	Follow the recommended remedy for each fault		
PLC (CPU) failure	PLC (CPU) locked up in error state	10-15	Replace the PLC (CPU)		

#	Functional Failure	Possible Cause(s)	Suspect Component(s)	Location (page reference)	Corrective Action
5	Unit will not move up or down in Float Mode	Option not installed	Loadcell not installed inside actuator	10-22, 10-23	Contact your Gorbel® distributor for option
			Software not configured	6-1	Reload software
		Loadcell cable	Loadcell cable to main PCB disconnected or damaged	8-4	Reconnect or replace loadcell
			Loadcell is damaged or defective	10-22, 10-23	Replace loadcell
		Loadcell pin	Loadcell pin is damaged / defective	10-22, 10-23	Repair / replace loadcell pin
		Handle pushbutton	Pushbutton or switch is broken	10-42, 10-60	Replace pushbutton or handle mother board
Cable connection	Loose or disconnected cable (78613)	8-4	Repair or replace the cable		
6	Unit only moves in the up direction	Handle failure	Handle mother board failure	10-41, 10-57	Replace slide or pendant handle mother board
			Linear transducer failure	10-41	Repair linear transducer
		Coil cord or pendant cable	Broken conductor	8-5	Repair or replace coil cord or pendant cable
			Actuator wiring	Broken conductor	8-3, 8-4
		Down limit switch	Limit switch failure	10-35	Replace down limit switch
		Operator error	Falsely programmed lower virtual limit, under dual VL setup	5-5	Check / reset virtual limits
Falsely activating a custom feature that stops all downward movement	None		Avoid this condition		
Float Mode: loadcell maximum capacity reached	None		Decrease load		
7	Unit only moves in the down direction	Handle failure	Handle mother board failure	10-41, 10-57	Replace slide or pendant handle mother board
			Linear transducer failure	10-41	Replace linear transducer
		Coil cord or pendant cable	Broken conductor	8-5	Repair or replace coil cord or pendant cable
			Actuator wiring	Broken conductor	8-3, 8-4
		Up limit switch	Limit switch failure	10-35	Replace up limit switch
		Operator error	Falsely programmed upper virtual limit, under dual VL setup	5-5	Check / reset virtual limits
Falsely activating a custom feature that stops all upward movement	None		Avoid this condition		
Float Mode: loadcell maximum capacity reached	None		Decrease load		
8	Load continues to drop after handle is released	Handle linear transducer	Linear transducer failure	10-41	Replace linear transducer
			Linear transducer adjustment	9-4	Adjust linear transducer
		Handle mother PCB	Damaged / defective handle mother board	10-41, 10-57	Replace slide or pendant handle mother board
		Handle operator present sensor	Damaged operator present sensor: falsely keep unit running	10-40	Replace operator present sensor
		Motor brake	Damaged / defective motor brake	10-17, 10-18	Replace motor
Operation	Custom feature: input to Auto Move falsely turned on	None	Avoid this condition		
9	Jog switches not functioning	Actuator PCB	Damaged / defective actuator PCB	10-10	Replace actuator main PCB
		Drive module	Damaged / defective drive module	10-13	Replace ACOPOS drive module
		Module cable	Damaged / defective drive cable	8-3	Replace the cable
		Cable connection	Loose or disconnected cable (78608)	8-4	Replace motor drive cable
10	Unit moves noticeably faster in one direction than the other	Handle linear transducer	Linear transducer failure	10-41	Replace linear transducer
11	Float Mode is no smooth and/or weight readout is inaccurate	Coil cord wear ring is binding inside actuator opening	Coil cord bracket is bent or out of position	10-65 thru 10-68	Replace or reform coil cord bracket

#	Functional Failure	Possible Cause(s)	Suspect Component(s)	Location (page reference)	Corrective Action
12	Constant "E-Stop Engaged" Message	Communication failure	Any communication interruption between the E-stop switch and the servo drive	8-3	Check all applicable connections: handle, coil cord, G360™
		E-stop switch failure	E-stop switch	10-41, 10-60	Replace the E-stop switch
13	"Excessive Pause" Message	Operator present sensor is blocked for more than 60 seconds	<u>Sliding Handle</u> : Operator present sensor	10-40	Clean the sensor and remove any blockage
			<u>Pendant Handle</u> : Either lever	10-53	Look for interference with the levers
14	Air Leaking at Swivel Assembly	O-rings are worn or undersized	O-rings	10-38, 10-73	Replace the o-rings and lubricate with general purpose non-synthetic grease
15	Weight readout is not accurate (within 1%) and/or Float Mode is "jumpy"	Load plate movement is restricted	Coil cord bracket and/or nylon wear ring is out of position	10-65 thru 10-68	Check for bent coil cord bracket or nylon wear ring is not positioned correctly
16	4005 & 7219 Drive Faults	Servo DC Bus voltage is out of spec	AC supply voltage is out of spec: should be between 208 & 242 VAC	2-1, 3-7	Find a suitable AC voltage source
17	501 & 11001 Drive Faults	Slack and upper limit switch are actuated at the same time	Slack and upper limit switch. Usually only occurs with Suspended Pendant applications	10-35	Add weight to the swivel hook, power off the system and power the system back on. Use the down jog button to move the load down away from the upper limit switch.
18	32011, 32189, 6015 Communication Faults	Communication failure	Swivel assembly slip rings	10-76	Clean and lubricants slip rings (Deoxit) or replace if worn excessively

Troubleshooting Section II: System Fault Diagnostics Chart

Under certain conditions, a system fault or warning message may appear on the LCD screen or the G-Force® handle along with either the red or blue LED flashing. The system fault or warning message can be one of the following:

1. Command faults - describes faults detected by the PLC while executing a command that results in a system shutdown with a message displayed on the LCD screen.
2. Command warnings - describes a condition that will allow the system to continue to operate with a message being displayed on the LCD screen until that message is cleared using Program Mode. **Note:** The warning is cleared through Program Mode or cycling the power or E-stop if the warning is not repetitive.
3. ACOPOS Drive fault - describes faults detected in the drive that result in a shutdown and a drive fault message displayed on the LCD screen.

The recovery from these may require the cycling off/on of the E-stop switch or AC power source.

Note: The latter must be done by disconnecting the AC power cord, using an electrical disconnect device or a circuit breaker.

It is also possible that the fault clearance may require a more specific corrective action such as reloading system software (see Chapter 6), replacing the wire rope, checking certain external input/output modules or some other service-related task. If necessary, check with your Gorbel® distributor or contact Gorbel® Inside Sales at 800-821-0086 for assistance.

Q-iQ Unit Fault/Error/Warning Categories

Command Faults

These are faults detected by the PLC while executing a command and will result in unit shutdown with the command fault message on the LCD.

Sub-Category	Fault Examples
1. Unit Configuration Setting	Mismatched configuration settings
2. Supplemental tools	Problem saving configuration settings
3. Hardware ID	Drive not ready to run
4. Control Parameter Database	Digital input or output location outside range
5. Process and Display Mode	A processing or I/O control feature resulted in shutdown
6. Other Status	Both travel limits are triggered during power up
7. Non-Motion Watchdog Timer	A checkup or process causes system to hang up
8. Motion Control	Drive not ready to run
9. Custom Motion Control	Multiple Virtual Limit targets detected
10. Motion Command Watchdog Timer	A Run Mode process causes system to hang up

Command Warnings

Allows unit to continue to operate with warning message on the LCD the whole time until the warning is cleared through processed steps such as clearing the cycle counts through Program Mode.

Sub-Category	Warning Examples
1. Process and Display Mode	Multiple processes controlling LCD displays
2. Other Status	PLC battery low power
3. Non-Motion Watchdog Timer	A checkup or process causes system to hang up
4. Motion Control	Programming Upper and Lower Virtual limit at the same position
5. Custom Motion Control	Multiple features controlling motion commands
6. Motion Command Watchdog Timer	A non-critical Run Mode process causes system to hang up
7. Service Mode	Wire rope replacement
8. Fault Warning	Handle electronics generated fault

ACOPOS Drive Fault

When the ACOPOS drive detects a fault, unit is shutdown with drive fault message displayed on the LCD.

List of Drive Fault Types:

Sub-Category	Description and Examples
1. SPT Drive Command	PLC command to the drive, e.g. E#1 invalid parameter
2. PLC Drive Communication	Communication and information exchange between the PLC and the drive, e.g. E#1004 communication network timeout
3. CAN Communication	CAN communication condition, e.g. E#6015 received data in the CAN network is corrupted
4. CPU Processing	CPU running, e.g. E#1016, CPU doing too much work
5. Drive Error State	Drive in error state (E#4005) and other fault messages
6. Position Encoder	Motor position sensor problem, e.g. E#7045 corrupted sensor data
7. E-Stop Enable Input	E-stop signal integrity, e.g. E#6021 signal is turned off
8. Input Power	Drive line voltage condition, e.g. E#7211 line power low
9. System Setup	Software processing, e.g. E#32131 missing data
10. Motor, Regen, and Junction Temperature	Motor temperature status, e.g. E#9010 motor overheat
11. Motor Drive Over Current	Drive current status, e.g. E#9300 over current
12. Not Handled	All other less common drive faults

Known Drive Fault Error Numbers Corresponding to Each Category:

Sub-Category	Error # History
1. SPT Drive Command	1, 1003, 1017, 1018, 1021
2. PLC Drive Communication	1004, 32011, 32061, 32189
3. CAN Communication	6015, 6016
4. CPU Processing	1016
5. Drive Error State	4005
6. Position Encoder	5034, 7045, 7046
7. E-Stop Enable Input	6021, 6023, 6048
8. Input Power	7211, 7215, 7217, 7219
9. System Setup	32131
10. Motor, Regen, and Junction Temperature	9002, 9010, 9030, 9031, 9040, 9070, 9071, 41011, 41031, 41041, 41070
11. Motor Drive Over Current	9050, 9051, 9060, 9061, 9300, 41051, 41061
12. Not Handled	All others

Multiple drive faults can occur at one time and are displayed serially on the LCD screen. The first displayed drive fault number is often the initial cause that lead to subsequent triggered faults and is thus a good indicator to the true cause. However, this is not always the case as E#4005 (Drive Error State category) always precedes other error numbers that are the cause(s) of the shutdown.

User should identify the fault category corresponding to the drive fault number(s) as a quick reference to the potential type of problem encountered. User may attempt basic troubleshooting checkup or repair. For example, if the fault category is “CAN Communication”, check all the cable wiring and connectors for loose connections. If the fault category is “Motor, Regen, and Junction Temperature”, user can let the unit cool down before reusing the unit.

Another approach may be referencing Troubleshooting Section I: Functional Failure Table for similar failure condition and perform the suggested corrective action(s).

Users should contact their dealer or Gorbel® Inside Sales for additional support and any questions about the encountered problem, corrective action, or replacement parts.

Corrective Action Summary

Use the following table to identify the appropriate corrective action for the specific faulted condition

Fault Category	LCD Error # Displayed	LCD Error Message	Corrective Action
Command Faults	1 - 9, 100 - 105, 110 - 122, 300 - 310	DOWNLOAD PROGRAM	Cycle Power
	200, 201, 203, 204	CHK PLC HARDWARE	Cycle Power
	202, 205, 206	CHK DRIV STATUS	Cycle Power
	1600	EXTD S# NNNN	Cycle E-stop
	0 ~ 9998		Cycle Power
Command Warnings	10400, 10401, 10402, 10403, 11001	CONTACT GORBEL	Cycle Power
	10500	REPLACE BATTERY	Cycle Power
	11000	RELEASE SWITCHES	Service is Required
	11002	RE-PROGM OVERLOAD	Follow Overload Program Instructions
	11003	CHK HNDL HARDWARE	Cycle Power
	11700, 11701	REPLACE WIREROPE	Clear Cycle Count after wire rope replacement
	11800, 11801, 11802	CHK HNDL ELECTRIC	Cycle E-stop
	11803, 11804, 11805	CHK LCD ELECTRIC	Cycle Power
	11806, 11807, 11808	CHK I/O MODULE	Cycle Power
	11000 ~ 65534		Cycle E-stop
Drive Faults	5034, 7045, 7046	ENCODER ERROR	Cycle E-stop Reprogram Position
All Other Drive Faults	1 ~ 64506		Cycle E-stop or Power

LED Chart: The chart below shows the status of LED lights in different states.

ID	Program State	Sub-State	Blue	Red	LCD Text Display
1	Engaged E-stop		Off	Off	Displays "E-STOP ENGAGED". This state can also be used for troubleshooting if the E-stop is turned off intentionally.
2	Programming Mode		On	On	Overwrites fault, warning or service warning messages to allow correction of the cause of the messages. Displays "PROGRAM MODE", various menu screens and selection items. Please see "Program Mode" section for more details.
3	Fault Mode or Drive Fault		Off	On	LCD displays if unit is in command or drive fault, followed by a fault number and a corrective message. Unit is shut down until a corrective action is taken or cycling the E-stop or main AC power.
4	Warning		Off	Fast Flash	LCD displays unit is in warning fault, followed by a fault number and a corrective message. Unit is still allowed to run but warning messages overwrite other normal running messages defined in the latter cases.
5	Service Warning		Fast Flash	Off	Displays warnings for parts replacement recommendations and those that require immediate attention, e.g. wire rope replacement or PLC low battery
6	Service Mode		Slow Flash	Slow Flash	Because SERVICE MODE is meant to run for special diagnostic purposes, it is shown before Service Warnings such as cycle count warnings. Multiple diagnostic messages are likely to be displayed here such as output a live handle connection, pushbutton states (only a special Jog Mode is running), etc.
7	Startup Process	Before Ready Mode	On	On	Displays "UNIT POWER UP". Unit is starting up (power up) and executing necessary settings and self diagnostics.
10.a	Run Mode	Overload	Previous	Slow Flash	Indicates unit is overloaded (factory or user defined) while lifting.
10.b		Still Motion	Previous	Slow Flash	Indicates unit maintains still for an extensive time while running in a Run Mode application such as handle mode, Float Mode, etc.
10.c		Over-Speed	Previous	Slow Flash	Indicates Float Mode control exceeded the over speed limit and the unit is shutting down.
10.d		Handle Mode	Previous	Previous	Displays run mode specific message such as RUN MODE JOG, HANDLE, PENDANT or CUSTOM
		Float Mode	On	Off	Displays run mode specific messages such as "--RECORD-- --DATA--" and RUN MODE FLOAT. The first message indicates when the unit is collecting loadcell data to perform Float Mode.
11.a	Custom Feature #N	Display 1	On	Off	Displays custom feature messages for a custom motion feature (Run Mode) that also requires using LEDs for indication. More information may be found in the Custom Feature description section.
11.b		Display 2	On	On	
11.c		Display 3	Slow Flash	Off	
11.d		Display 4	Off	Slow Flash	
20	Ready Mode		Off	Off	Displays LIFT READY to indicate unit is idling and waiting for response.
20.a	Custom Feature #N	Display 1	On	Off	Displays custom feature messages for a custom feature that also requires using LEDs for indication while the unit is idling (in Ready Mode). More information may be found in the Custom Feature description section.
20.b		Display 2	On	On	
20.c		Display 3	Slow Flash	Off	
20.d		Display 4	Off	Slow Flash	

Q-iQ Unit: System, Motion and Feature Command Fault List (Software Version R1.07.0)

Command Faults - Unit Configuration Setting

Error #1 - ERROR_SERIAL_NUM_OBJ_SIZE_MISMATCH

Description: At startup, the stored PLC serial number in memory does not match the version the lift program uses or it may be corrupted.

Reaction: Lift program terminates processing to prevent running with an unconfigured or potentially faulty PLC unit.

Cause / Remedy: Please contact Gorbel® Inside Sales at 800-821-0086 or 585-924-6262.

Error #2 - ERROR_SERIAL_NUM_OBJ_LOCATE

Description: At startup, the query command to locate the stored PLC serial number is returned with an error.

Reaction: Lift program terminates processing to prevent running with an unconfigured or potentially faulty PLC unit.

Cause / Remedy: Please contact Gorbel® Inside Sales at 800-821-0086 or 585-924-6262.

Error #3 - ERROR_SERIAL_NUM_OBJ_READ

Description: At startup, the query command to retrieve the stored PLC serial number is returned with an error.

Reaction: Lift program terminates processing to prevent running with an unconfigured or potentially faulty PLC unit.

Cause / Remedy: Please contact Gorbel® Inside Sales at 800-821-0086 or 585-924-6262.

Error #4 - ERROR_UNIT_OBJ_SIZE_MISMATCH

Description: At startup, the stored unit-specific configuration variable in memory does not match the version lift program used.

Reaction: Lift program terminates processing to prevent running with an incorrect configuration setup.

Cause / Remedy: Run the Gorbel® supplied installation CD (i.e. Gorbel® G-Force® Q/iQ Software Downloader) and select the "Download Q/iQ Software and Reset to Factory Default Configurations" option to reset any faulty settings. All configuration settings (e.g. if unit is configured for Float Mode) and Q/iQ feature settings (e.g. virtual limit positions) are cleared and reset to default.

Error #5 - ERROR_UNIT_OBJ_LOCATE

Description: At startup, the query command to locate the stored unit-specific configuration variable is returned with an error.

Reaction: Lift program terminates processing to prevent running with an incorrect configuration setup.

Cause / Remedy: Run the Gorbel® supplied installation CD (i.e. Gorbel® G-Force® Q/iQ Software Downloader) and select the "Download Q/iQ Software and Reset to Factory Default Configurations" option to reset any faulty settings. All configuration settings (e.g. if unit is configured for Float Mode) and Q/iQ feature settings (e.g. virtual limit positions) are cleared and reset to default.

Error #6 - ERROR_FACTORY_OBJ_SIZE_MISMATCH

Description: At startup, stored default factory configuration does not match the version lift program used.

Reaction: Lift program terminates processing to prevent running with an incorrect configuration setup.

Cause / Remedy: Run the Gorbel® supplied installation CD (i.e. Gorbel® G-Force® Q/iQ Software Downloader) and select the "Download Q/iQ Software and Reset to Factory Default Configurations" option to reset any faulty settings. All configuration settings (e.g. if unit is configured for Float Mode) and Q/iQ feature settings (e.g. virtual limit positions) are cleared and reset to default.

Error #7 - ERROR_FACTORY_OBJ_LOCATE

Description: At startup, the query command to locate the default factory configuration is returned with an error.

Reaction: Lift program terminates processing to prevent running with an incorrect configuration setup.

Cause / Remedy: Run the Gorbel® supplied installation CD (i.e. Gorbel® G-Force® Q/iQ Software Downloader) and select the "Download Q/iQ Software and Reset to Factory Default Configurations" option to reset any faulty settings. All configuration settings (e.g. if unit is configured for Float Mode) and Q/iQ feature settings (e.g. virtual limit positions) are cleared and reset to default.

Error #8 - ERROR_NO_FACTORY_SETTINGS

Description: At startup, the default factory configuration setting does not exist in memory. This check only takes place when unit-specific configuration cannot be found or a deleted factory setting command is performed.

Reaction: Lift program terminates processing to prevent running with an incorrect configuration setup.

Cause / Remedy: Run the Gorbel® supplied installation CD (i.e. Gorbel® G-Force® Q/iQ Software Downloader) and select the “Download Q/iQ Software and Reset to Factory Default Configurations” option to reset any faulty settings. All configuration settings (e.g. if unit is configured for Float Mode) and Q/iQ feature settings (e.g. virtual limit positions) are cleared and reset to default.

Error #9 - ERROR_UNIT_OBJ_READ

Description: At startup, the retrieval of the stored unit-specific or default factory configuration setting in memory is returned with an error.

Reaction: Lift program terminates processing to prevent running with an incorrect configuration setup.

Cause / Remedy: Run the Gorbel® supplied installation CD (i.e. Gorbel® G-Force® Q/iQ Software Downloader) and select the “Download Q/iQ Software and Reset to Factory Default Configurations” option to reset any faulty settings. All configuration settings (e.g. if unit is configured for Float Mode) and Q/iQ feature settings (e.g. virtual limit positions) are cleared and reset to default.

Command Faults - Supplemental Tools**Error #100 - ERROR_DUMMY_SERIAL_NUM_OBJ_CHECK**

Description: An error has occurred when checking if a temporary PLC serial number variable exists. This fault can only be triggered during the factory setup process or by authorized personnel attempting to record the PLC serial number.

Reaction: Lift program terminates processing to prevent running with an incorrect configuration setup.

Cause / Remedy: Please contact Gorbel® Inside Sales at 800-821-0086 or 585-924-6262.

Error #101 - ERROR_DUMMY_SERIAL_NUM_OBJ_DELETE

Description: An error has occurred while deleting the stored temporary PLC serial number during the factory setup process.

Reaction: Lift program terminates processing to prevent running with an incorrect configuration setup.

Cause / Remedy: Please contact Gorbel® Inside Sales at 800-821-0086 or 585-924-6262.

Error #102 - ERROR_SERIAL_NUM_OBJ_CHECK

Description: An error has occurred while checking if a stored PLC serial number exists.

Reaction: Lift program terminates processing to prevent running with an incorrect configuration setup.

Cause / Remedy: Please contact Gorbel® Inside Sales at 800-821-0086 or 585-924-6262.

Error #103 - ERROR_SERIAL_NUM_OBJ_DELETE

Description: Prior to saving the PLC serial number, the last stored version is deleted and an error is returned while the command is executed.

Reaction: Lift program terminates processing to prevent running with an incorrect configuration setup.

Cause / Remedy: Please contact Gorbel® Inside Sales at 800-821-0086 or 585-924-6262.

Error #104 - ERROR_SERIAL_NUM_OBJ_CREATE_DUMMY

Description: A temporary PLC serial number variable is created prior to saving but an error has occurred while the command is executed.

Reaction: Lift program terminates processing to prevent running with an incorrect configuration setup.

Cause / Remedy: Please contact Gorbel® Inside Sales at 800-821-0086 or 585-924-6262.

Error #105 - ERROR_SERIAL_NUM_OBJ_COPY

Description: While copying the temporary PLC serial number into memory, an error has occurred while the command is executed.

Reaction: Lift program terminates processing to prevent running with an incorrect configuration setup.

Cause / Remedy: Please contact Gorbel® Inside Sales at 800-821-0086 or 585-924-6262.

Error #110 - ERROR_SAVE_UNIT_OBJ_SIZE_MISMATCH

Description: Prior to saving the current unit-specific configuration setting into memory, when checking the last stored version with this version, they are not compatible.

Reaction: Lift program terminates processing to prevent running with an incorrect configuration setup.

Cause / Remedy: Run the Gorbel® supplied installation CD (i.e. Gorbel® G-Force® Q/iQ Software Downloader) and select the “Download Q/iQ Software and Retain Existing Configurations” option to clear the faulty memory and retain the latest configuration settings (e.g. if unit is configured for Float Mode) and Q/iQ feature settings (e.g. virtual limit positions). For custom iQ units, all custom feature settings such as position or weight settings are not retained and are reset to default settings as specified for the unit.

Error #111 - ERROR_SAVE_UNIT_OBJ_CHECK

Description: Prior to saving the current unit-specific configuration setting into memory, an error has occurred when checking if a stored version exists.

Reaction: Lift program terminates processing to prevent running with an incorrect configuration setup.

Cause / Remedy: Run the Gorbel® supplied installation CD (i.e. Gorbel® G-Force® Q/iQ Software Downloader) and select the “Download Q/iQ Software and Retain Existing Configurations” option to clear the faulty memory and retain the latest configuration settings (e.g. if unit is configured for Float Mode) and Q/iQ feature settings (e.g. virtual limit positions). For custom iQ units, all custom feature settings such as position or weight settings are not retained and are reset to default settings as specified for the unit.

Error #112 - ERROR_SAVE_UNIT_OBJ_DELETE

Description: Prior to saving the current unit-specific configuration setting into memory, the last stored version is first deleted. An error has occurred during the delete command.

Reaction: Lift program terminates processing to prevent running with an incorrect configuration setup.

Cause / Remedy: Run the Gorbel® supplied installation CD (i.e. Gorbel® G-Force® Q/iQ Software Downloader) and select the “Download Q/iQ Software and Retain Existing Configurations” option to clear the faulty memory and retain the latest configuration settings (e.g. if unit is configured for Float Mode) and Q/iQ feature settings (e.g. virtual limit positions). For custom iQ units, all custom feature settings such as position or weight settings are not retained and are reset to default settings as specified for the unit.

Error #113 ERROR_SAVE_UNIT_OBJ_FREE

Description: Prior to saving the current unit-specific configuration setting into memory, an error has occurred while determining the available free memory space to store into PLC.

Reaction: Lift program terminates processing to prevent running with an incorrect configuration setup.

Cause / Remedy: Run the Gorbel® supplied installation CD (i.e. Gorbel® G-Force® Q/iQ Software Downloader) and select the “Download Q/iQ Software and Retain Existing Configurations” option to clear the faulty memory and retain the latest configuration settings (e.g. if unit is configured for Float Mode) and Q/iQ feature settings (e.g. virtual limit positions). For custom iQ units, all custom feature settings such as position or weight settings are not retained and are reset to default settings as specified for the unit.

Error #114 - ERROR_SAVE_UNIT_OBJ_CLEAR

Description: Prior to saving the current unit-specific configuration setting into memory, the program found limited memory space available for storage. A clear memory command is executed but an error is returned.

Reaction: Lift program terminates processing to prevent running with an incorrect configuration setup.

Cause / Remedy: Run the Gorbel® supplied installation CD (i.e. Gorbel® G-Force® Q/iQ Software Downloader) and select the “Download Q/iQ Software and Retain Existing Configurations” option to clear the faulty memory and retain the latest configuration settings (e.g. if unit is configured for Float Mode) and Q/iQ feature settings (e.g. virtual limit positions). For custom iQ units, all custom feature settings such as position or weight settings are not retained and are reset to default settings as specified for the unit.

Error #115 - ERROR_SAVE_UNIT_OBJ_STORE

Description: When saving the current unit-specific configuration setting into memory, an error is returned.

Reaction: Lift program terminates processing to prevent running with an incorrect configuration setup.

Cause / Remedy: Run the Gorbel® supplied installation CD (i.e. Gorbel® G-Force® Q/iQ Software Downloader) and select the “Download Q/iQ Software and Retain Existing Configurations” option to clear the faulty memory and retain the latest configuration settings (e.g. if unit is configured for Float Mode) and Q/iQ feature settings (e.g. virtual limit positions). For custom iQ units, all custom feature settings such as position or weight settings are not retained and are reset to default settings as specified for the unit.

Error #120 - ERROR_FACTORY_OBJ_CREATE

Description: An error has occurred when creating a dummy factory configuration variable.

Reaction: Lift program terminates processing to prevent running with an incorrect configuration setup.

Cause / Remedy: Run the Gorbel® supplied installation CD (i.e. Gorbel® G-Force® Q/iQ Software Downloader) and select the “Download Q/iQ Software and Reset to Factory Default Configurations” option to reset any faulty settings. All configuration settings (e.g. if unit is configured for Float Mode) and Q/iQ feature settings (e.g. virtual limit positions) are cleared and reset to default.

Error #121 - ERROR_FACTORY_OBJ_COPY

Description: An error has occurred while copying the dummy factory configuration to be the default factory configuration.

Reaction: Lift program terminates processing to prevent running with an incorrect configuration setup.

Cause / Remedy: Run the Gorbel® supplied installation CD (i.e. Gorbel® G-Force® Q/iQ Software Downloader) and select the “Download Q/iQ Software and Reset to Factory Default Configurations” option to reset any faulty settings. All configuration settings (e.g. if unit is configured for Float Mode) and Q/iQ feature settings (e.g. virtual limit positions) are cleared and reset to default.

Error #122 - ERROR_FACTORY_OBJ_DELETE

Description: An error has occurred while deleting the factory configuration from PLC.

Reaction: N/A

Cause / Remedy: Run the Gorbel® supplied installation CD (i.e. Gorbel® G-Force® Q/iQ Software Downloader) and select the “Download Q/iQ Software and Reset to Factory Default Configurations” option to reset any faulty settings. All configuration settings (e.g. if unit is configured for Float Mode) and Q/iQ feature settings (e.g. virtual limit positions) are cleared and reset to default.

Command Faults - Hardware ID**Error #200 - ERROR_HW_ID_PLC_QUERY**

Description: An error has occurred while identifying the PLC type and connected add-on modules, if any.

Reaction: N/A

Cause / Remedy:

- (a) Check if a PLC model CP470 or CP474 is properly installed. If CP474 is used, check if the other expansion cards such as DO435 are correctly attached.
- (b) Run the Gorbel® supplied installation CD (i.e. Gorbel® G-Force® Q/iQ Software Downloader) and select the “Download Q/iQ Software and Reset to Factory Default Configurations” option to reset any faulty settings. All configuration settings (e.g. if unit is configured for Float Mode) and Q/iQ feature settings (e.g. virtual limit positions) are cleared and reset to default.

Error #201 - ERROR_HW_ID_EXCESS_PLC_MODULE

Description: The PLC has identified more add-on modules than the maximum limit of 5.

Reaction: N/A

Cause / Remedy:

- (a) Check if PLC model CP470 has any add-on modules.
- (b) Check if PLC model CP474 has a DO435 add-on module.
- (c) Reboot the unit.
- (d) Run the Gorbel® supplied installation CD (i.e. Gorbel® G-Force® Q/iQ Software Downloader) and select the “Download Q/iQ Software and Reset to Factory Default Configurations” option to reset any faulty settings. All configuration settings (e.g. if unit is configured for Float Mode) and Q/iQ feature settings (e.g. virtual limit positions) are cleared and reset to default.
- (e) If problem persists, replace the component.

Error #202 - ERROR_HW_ID_DRIVE_NOT_READY

Description: At startup, 10 seconds after power cycling the system, the ACOPOS drive is still not ready for operation.

Reaction: Lift program terminates processing to prevent running with incorrect configuration setup.

Cause / Remedy: PLC is not communicating with the ACOPOS drive due to:

- i. Loose or disconnected communication CAN cable(s) in the system.
- ii. PLC CAN communication component is not working.
- iii. ACOPOS AC110 CAN communication card is not working.
- iv. Interface circuit board has bad CAN cabling connection.

Error #203 - ERROR_HW_MISMATCH_PLC

Description: At startup, found the identified PLC model type does not match any of the known models for this system.

Reaction: Lift program terminates processing to prevent running with an incorrect configuration setup.

Cause / Remedy: Check if the installed PLC controller is of model CP470 or CP474, as labeled on its front cover.

- i. Replace the module if an installation error has indeed occurred.
- ii. Run the Gorbel® supplied installation CD (i.e. Gorbel® G-Force® Q/iQ Software Downloader) and select the “Download Q/iQ Software and Reset to Factory Default Configurations” option to reset any faulty settings. All configuration settings (e.g. if unit is configured for Float Mode) and Q/iQ feature settings (e.g. virtual limit positions) are cleared and reset to default.

Error #204 - ERROR_HW_MISMATCH_PLC_MODULE

Description: At startup, found the identified modules for CP474 PLC model do not match the known modules for this controller.

Reaction: Lift program terminates processing to prevent running with an incorrect configuration setup.

Cause / Remedy:

- (a) Confirm the adapter module AF101 and the digital IO module DO435 are installed with the CP474 controller.
- (b) If AF101 and DO435 modules are present, either one of them can be at fault. Replace as necessary.

Error #205 - ERROR_HW_MISMATCH_DRIVE (OBSOLETE)

Description: At startup, found an unknown ACOPOS drive.

Reaction: N/A

Cause / Remedy: Please contact Gorbel® Inside Sales at 800-821-0086 or 585-924-6262.

Error #206 - ERROR_HW_MISMATCH_DRIVE_MODULE

Description: At startup, found the identified ACOPOS plug-in modules do not match the known models for this system.

Reaction: Lift program terminates processing to prevent running with an incorrect configuration setup.

Cause / Remedy: The designed plug-in modules are AC110, AC122, and AC131. If this error occurs:

- (a) At least one unknown module is installed and should be removed.
- (b) If correct modules are installed, at least one of them cannot be identified, possibly due to a faulty component. Replace as necessary.

Error #207 - ERROR_HW_MOTOR_PAR_SETUP_FAULT

Description: At startup, the configuration of the motor settings of the unit is returned with an error.

Reaction: Lift program terminates processing to prevent running with an incorrect configuration setup.

Cause / Remedy: Run the Gorbel® supplied installation CD (i.e. Gorbel® G-Force® Q/iQ Software Downloader) and select the “Download Q/iQ Software and Reset to Factory Default Configurations” option to reset any faulty settings. All configuration settings (e.g. if unit is configured for Float Mode) and Q/iQ feature settings (e.g. virtual limit positions) are cleared and reset to default.

Error #208 - ERROR_HW_MISMATCH_PLC_VS_SOFTWARE

Description: At startup, found the identified PLC model does not match the installed software version. A Q or iQ software version must be installed into the corresponding PLC type.

Reaction: Lift program terminates processing to prevent running with an incorrect software program.

Cause / Remedy: Check if the installed PLC controller is of model CP470 or CP474, as labeled on its front cover.

- i. Replace the module if an installation error has indeed occurred.
- ii. Run the Gorbel® supplied installation CD (i.e. Gorbel® G-Force® Q/iQ Software Downloader) and re-install the correct software version (Q or iQ) into the PLC. Note: Due to incorrect software installation earlier, the stored feature configurations may be faulty. Therefore, it is also recommended to choose the “Reset Factory Default Configurations” option when installing the updated software. All configuration settings (e.g. if unit is configured for Float Mode) and Q/iQ feature settings (e.g. virtual limit positions) are cleared and reset to default.

Command Faults - Control Parameter Database

Error #300 - ERROR_MACHINE_STYLE_INVALID

Description: At startup, found the stored configuration setting has an invalid machine style (i.e. G-Force®, Easy Arm®, etc.) value.

Reaction: Lift program terminates processing to prevent running with an incorrect configuration setup.

Cause / Remedy: A critical configuration setting of the unit is corrupted and falsely set. Please contact Gorbel® Customer Service at 800-821-0086 or 585-924-6262 for further instruction.

Error #301 - ERROR_MACHINE_EA_VERSION_INVALID

Description: At startup, found the stored configuration setting has an invalid Easy Arm® span and height version value.

Reaction: Lift program terminates processing to prevent running with an incorrect configuration setup.

Cause / Remedy: A critical configuration setting of the unit is corrupted and falsely set. Please contact Gorbel® Customer Service at 800-821-0086 or 585-924-6262 for further instruction.

Error #302 - ERROR_MACHINE_CAPACITY_INVALID

Description: At startup, found the stored configuration setting has an invalid capacity selection value.

Reaction: Lift program terminates processing to prevent running with an incorrect configuration setup.

Cause / Remedy: A critical configuration setting of the unit is corrupted or falsely set. Please contact Gorbel® Customer Service at 800-821-0086 or 585-924-6262 for further instruction.

Error #310 - ERROR_CONTROL_DATABASE_NOT_FOUND

Description: At startup, found the stored configuration setting has an invalid index value to the control setting database.

Reaction: Lift program terminates processing to prevent running with an incorrect configuration setup.

Cause / Remedy: Please contact Gorbel® Customer Service at 800-821-0086 or 585-924-6262.

Error #320 - ERROR_MULTI_FEATURES_PER_UNIT_CONFIGURATION

Description: At startup, found multiple Q/iQ feature configuration settings are set to use the same digital input channel.

Reaction: Lift program terminates processing to prevent running with an incorrect configuration setup.

Cause / Remedy:

- (a) Use the extended error index number to identify which Q/iQ feature contains the faulty setting. Use the VB Configurator program (not yet available as of July 2010) to correct the false setting.
- (b) Run the Gorbel® supplied installation CD (i.e. Gorbel® G-Force® Q/iQ Software Downloader) and select the "Download Q/iQ Software and Reset to Factory Default Configurations" option to reset any faulty settings. All configuration settings (e.g. if unit is configured for Float Mode) and Q/iQ feature settings (e.g. virtual limit positions) are cleared and reset to default.

Error #321 - ERROR_MULTI_FEATURES_PER_OUTPUT_CONFIGURATION

Description: At startup, found multiple Q/iQ feature configuration settings are set to use the same digital output channel.

Reaction: Lift program terminates processing to prevent running with an incorrect configuration setup.

Cause / Remedy:

- (a) Use the extended error index number to identify which Q/iQ feature contains the faulty setting. Use the VB Configurator program (not yet available as of July 2010) to correct the false setting.
- (b) Run the Gorbel® supplied installation CD (i.e. Gorbel® G-Force® Q/iQ Software Downloader) and select the "Download Q/iQ Software and Reset to Factory Default Configurations" option to reset any faulty settings. All configuration settings (e.g. if unit is configured for Float Mode) and Q/iQ feature settings (e.g. virtual limit positions) are cleared and reset to default.

Error #322 - ERROR_INPUT_CONFIGURATION_OUT_OF_BOUND

Description: At startup, found a Q/iQ feature input channel configuration setting is outside the allowable range.

Reaction: Lift program terminates processing to prevent running with an incorrect configuration setup.

Cause / Remedy:

- (a) Use the extended error index number to identify which Q/iQ feature contains the faulty setting. Use the VB Configurator program (not yet available as of July 2010) to correct the false setting.
- (b) Run the Gorbel® supplied installation CD (i.e. Gorbel® G-Force® Q/iQ Software Downloader) and select the "Download Q/iQ Software and Reset to Factory Default Configurations" option to reset any faulty settings. All configuration settings (e.g. if unit is configured for Float Mode) and Q/iQ feature settings (e.g. virtual limit positions) are cleared and reset to default.

Error #323 - ERROR_OUTPUT_CONFIGURATION_OUT_OF_BOUND

Description: At startup, found a Q/iQ feature input channel configuration setting is outside the allowable range.

Reaction: Lift program terminates processing to prevent running with an incorrect configuration setup.

Cause / Remedy:

- (a) Use the extended error index number to identify which Q/iQ feature contains the faulty setting. Use the VB Configurator program (not yet available as of July 2010) to correct the false setting.
- (b) Run the Gorbel® supplied installation CD (i.e. Gorbel® G-Force® Q/iQ Software Downloader) and select the "Download Q/iQ Software and Reset to Factory Default Configurations" option to reset any faulty settings. All configuration settings (e.g. if unit is configured for Float Mode) and Q/iQ feature settings (e.g. virtual limit positions) are cleared and reset to default.

Error #324 - ERROR_FALSE_SETTING_CUS_MULTIPLE_VL_SETS

Description: At startup, found found configuration setting(s) for the multiple virtual limit (VL) sets standard iQ feature. These conditions include:

1. Option A specifies the number of inputs directly linked to a VL set. For example, default standard set (all inputs off), custom set 1 (input 1), custom set 2 (input 2), etc. The value cannot be greater than 4 for more than 5 VL sets. Option B specifies the number of inputs to create a binary indexing format to link to VL set. For example, a value 3 represents 3-digit binary where the first input is the least significant bit and they can index up to a total of 8 VL sets. Option B cannot be greater than 4 for more than 16 VL sets.
2. Option A and B cannot both be zero.
3. Either Option A or B must be non-zero.
4. The starting input channel number must be set.

Reaction: Lift program terminates processing to prevent running with an incorrect configuration setup.

Cause / Remedy:

- (a) Use the extended error index number to identify which Q/iQ feature contains the faulty setting. Use the VB Configurator program (not yet available as of July 2010) to correct the false setting.
- (b) Run the Gorbel® supplied installation CD (i.e. Gorbel® G-Force® Q/iQ Software Downloader) and select the "Download Q/iQ Software and Reset to Factory Default Configurations" option to reset any faulty settings. All configuration settings (e.g. if unit is configured for Float Mode) and Q/iQ feature settings (e.g. virtual limit positions) are cleared and reset to default.

Error #325 - ERROR_DUAL_ACTUATOR_SETTING_ON_Q_UNIT

Description: At startup, found Dual Actuator feature is falsely configured on the Q system. This is an iQ only feature and is not currently available for iQ Easy Arm™ system.

Reaction: Lift program terminates processing to prevent running with an incorrect configuration setup.

Cause / Remedy:

- (a) Contact Gorbel Inc. regarding the purchased unit to determine if a mismatched order, CPU model, or software version has been installed. It may be necessary to send the unit back to Gorbel Inc. for proper reconfiguration.
- (b) Run the Gorbel® supplied installation CD (i.e. Gorbel® G-Force® Q/iQ Software Downloader) and select the "Download Q/iQ Software and Reset to Factory Default Configurations" option to reset any faulty settings. All configuration settings (e.g. if unit is configured for Float Mode) and Q/iQ feature settings (e.g. virtual limit positions) are cleared and reset to default.

Note: Please do not perform this action if the fault is caused by (a).

Error #326 - ERROR_MISSING_INPUT_CHANNEL

Description: At startup, found an iQ feature is misconfigured, specifically a required digital input channel location is missing.

Reaction: Lift program terminates processing to prevent running with an incorrect configuration setup. Handle displays this command fault followed by an extended error index number referencing the iQ feature with the faulty setting.

Cause / Remedy:

- (a) Use the extended error index number to identify which Q/iQ feature contains the faulty setting. Use the VB Configurator program (not yet available as of July 2010) to correct the false setting.
- (b) Run the Gorbel® supplied installation CD (i.e. Gorbel® G-Force® Q/iQ Software Downloader) and select the "Download Q/iQ Software and Reset to Factory Default Configurations" option to reset any faulty settings. All configuration settings (e.g. if unit is configured for Float Mode) and Q/iQ feature settings (e.g. virtual limit positions) are cleared and reset to default.

Error #327 - ERROR_MISSING_OUTPUT_CHANNEL

Description: At startup, found an iQ feature is misconfigured, specifically a required digital output channel location is missing.

Reaction: Lift program terminates processing to prevent running with an incorrect configuration setup. Handle displays this command fault followed by an extended error index number referencing the iQ feature with the faulty setting.

Cause / Remedy:

- (a) Use the extended error index number to identify which Q/iQ feature contains the faulty setting. Use the VB Configurator program (not yet available as of July 2010) to correct the false setting.
- (b) Run the Gorbel® supplied installation CD (i.e. Gorbel® G-Force® Q/iQ Software Downloader) and select the "Download Q/iQ Software and Reset to Factory Default Configurations" option to reset any faulty settings. All configuration settings (e.g. if unit is configured for Float Mode) and Q/iQ feature settings (e.g. virtual limit positions) are cleared and reset to default.

Error #331 - ERROR_X67_1_IO_MASK_SETUP

Description: At startup, unit detects an error while configuring the first X67 spare IO module based on the configuration setting.

Reaction: Lift program terminates processing to prevent running with an incorrect configuration setup.

Cause / Remedy:

- (a) Use the extended error index number to identify which Q/iQ feature contains the faulty setting. Use the VB Configurator program (not yet available as of July 2010) to correct the false setting.
- (b) Run the Gorbel® supplied installation CD (i.e. Gorbel® G-Force® Q/iQ Software Downloader) and select the "Download Q/iQ Software and Reset to Factory Default Configurations" option to reset any faulty settings. All configuration settings (e.g. if unit is configured for Float Mode) and Q/iQ feature settings (e.g. virtual limit positions) are cleared and reset to default.

Error #332 - ERROR_X67_2_IO_MASK_SETUP

Description: At startup, unit detects an error while configuring the second X67 spare IO module based on the configuration setting.

Reaction: Lift program terminates processing to prevent running with an incorrect configuration setup.

Cause / Remedy:

- (a) Use the extended error index number to identify which Q/iQ feature contains the faulty setting. Use the VB Configurator program (not yet available as of July 2010) to correct the false setting.
- (b) Run the Gorbel® supplied installation CD (i.e. Gorbel® G-Force® Q/iQ Software Downloader) and select the "Download Q/iQ Software and Reset to Factory Default Configurations" option to reset any faulty settings. All configuration settings (e.g. if unit is configured for Float Mode) and Q/iQ feature settings (e.g. virtual limit positions) are cleared and reset to default.

Error #333 - ERROR_X67_3_IO_MASK_SETUP

Description: At startup, unit detects an error while configuring the third X67 spare IO module based on the configuration setting.

Reaction: Lift program terminates processing to prevent running with an incorrect configuration setup.

Cause / Remedy:

- (a) Use the extended error index number to identify which Q/iQ feature contains the faulty setting. Use the VB Configurator program (not yet available as of July 2010) to correct the false setting.
- (b) Run the Gorbel® supplied installation CD (i.e. Gorbel® G-Force® Q/iQ Software Downloader) and select the "Download Q/iQ Software and Reset to Factory Default Configurations" option to reset any faulty settings. All configuration settings (e.g. if unit is configured for Float Mode) and Q/iQ feature settings (e.g. virtual limit positions) are cleared and reset to default.

Error #334 - ERROR_X67_4_IO_MASK_SETUP

Description: Not Used

Reaction: Not Used

Cause / Remedy: Not Used

Error #335 - ERROR_X67_5_IO_MASK_SETUP

Description: Not Used

Reaction: Not Used

Cause / Remedy: Not Used

Error #336 - ERROR_X67_6_IO_MASK_SETUP

Description: Not Used

Reaction: Not Used

Cause / Remedy: Not Used

Error #337 - ERROR_X67_7_IO_MASK_SETUP

Description: Not Used

Reaction: Not Used

Cause / Remedy: Not Used

Command Faults - Process and Display Mode**Error #400 - ERROR_PROC_DISP**

Description: General: Process and Display Mode faults

Reaction: Not Used

Cause / Remedy: Not Used

Command Faults - Other Status**Error #500 - ERROR_STATUS**

Description: Starting index to other faults

Reaction: Not Used

Cause / Remedy: Not Used

Error #501 - ERROR_BOTH_TRAVEL_LIMITS_AT_HOMING

Description: At startup, both the upper and lower limit switches, or the upper limit and slack switches, are triggered. This can inhibit the ACOPOS drive from properly setting its position.

Reaction: Lift program terminates processing because the drive cannot properly configure its position.

Cause / Remedy:

- (a) if both the upper and slack switches are engaged, pull down on the wire rope to remove slack and recycle power on the unit.
- (b) Check for any mechanical binding that could engage both the upper and lower limit switches or upper limit and slack switches.
- (c) Check and correct if the limit switch cable is connected to the interface board.
- (d) Check for bad electrical connection or shorted wires from the switches.

Command Faults - Non-Motion Watchdog Timer

Error #600 - ERROR_WATCHDOG_NON_MOTION

Description: At startup, the stored configuration variable in memory does not match the version lift program used.

Reaction: Not Used

Cause / Remedy: Not Used

Command Faults - Motion Control

Error #1000 - ERROR_STARTUP_DRIVE_NOT_READY (OBSOLETE)

Description: Not Used

Reaction: Not Used

Cause / Remedy: Not Used

Error #1001 - ERROR_READY_MODE_CONTROLLER_NOT_READY (OBSOLETE)

Description: Not Used

Reaction: Not Used

Cause / Remedy: Not Used

Command Faults - Custom Motion Control

Error #1100 - ERROR_MULTP_MOTION_REQUEST

Description: Not Used

Reaction: Not Used

Cause / Remedy: Not Used

Error #1101 - ERROR_MORE_THAN_ONE_VL_TARGETS_DETECTED

Description: If multiple virtual limit (VL) set iQ feature is enabled with Option A (see error #324 for more information), only one digital input can turn on at a time to select a VL set. This error is triggered when the unit detects that multiple inputs are turned on at the same time.

Reaction: Lift is shut down to prevent unit from falsely responding to a wrong set.

Cause / Remedy:

- (a) Check for any electrical problem on the switches or devices connected to the input channels to falsely turn on at the same time.
- (b) Check for the electrical connection to the input channels of the lift (DO435 IO block in the actuator or X67 expansion IO module).
- (c) Check for any mechanical setup such that the detection targets to multiple proximity sensors can overlap in any portion of the layout.
- (d) Faulty input channels in the DO435 IO block or X67 expansion IO module.

Command Faults - Motion Command Watchdog Timer

Error #1600 - ERROR_WATCHDOG_RUN_MODE

Description: While running through Jog, Handle, Float or other custom motion, a processing command has taken too long to execute.

Reaction: Lift is shut down if the excessive delay is caused by any problem in the lift.

Cause / Remedy:

- (a) Use the extended error index number to obtain the processing state when excessive delay has occurred.
- (b) Please contact Gorbel® Customer Service at 800-821-0086 or 585-924-6262 regarding this problem and the processing state information.

ACOPOS Drive Faults

Error #9999 - ERROR_ACOPOS_FAULT

Description: ACOPOS drive faults or warnings.

Reaction: Lift is shut down for all drive faults or warnings.

Cause / Remedy: ACOPOS drive fault. Please check the fault number displayed on the LCD screen for additional detail.

Command Warnings

Error #10000 - WARNING_LIFT

Description: Starting index to non-critical warnings.

Reaction: Not Used

Cause / Remedy: Not Used

Command Warnings - Process and Display Mode

Error #10400 - WARN_MULTP_PROCESS_REQUEST (OBSOLETE)

Description: More than two features are attempting to display messages in the LCD at the same time. This is caught when the current running feature is a PROCESS specific feature.

Reaction: Handle LCD displays the warning while unit is allowed to continue to run.

Cause / Remedy: Please contact Gorbel® Customer Service at 800-821-0086 or 585-924-6262.

Error #10401 - WARN_MULTP_DISP_REQUEST (OBSOLETE)

Description: More than two features are attempting to display messages in the LCD at the same time. This is caught when the current running feature is a DISPLAY specific feature.

Reaction: Handle LCD displays the warning while unit is allowed to continue to run.

Cause / Remedy: Please contact Gorbel® Customer Service at 800-821-0086 or 585-924-6262.

Error #10402 - WARN_SET_MESSAGES_MISMATCH_LENGTHS

Description: The first and second line of the LCD text display are not the same length when unit attempts to process the message information.

Reaction: Handle LCD displays the warning while unit is allowed to continue to run.

Cause / Remedy: Please contact Gorbel® Customer Service at 800-821-0086 or 585-924-6262.

Error #10403 - WARN_ADD_MESSAGES_EXCEED_LENGTH

Description: The maximum allowable number of consecutive text messages is exceeded when unit attempts to process the message information.

Reaction: Handle LCD displays the warning while unit is allowed to continue to run.

Cause / Remedy: Please contact Gorbel® Customer Service at 800-821-0086 or 585-924-6262.

Error #10404 - WARN_PROG_ERROR_LOADCELL_COEF

Description: This warning is generated when system attempts to program the load cell coefficient, as commanded through PROGRAM MODE \ CONFIGUR MENU \ CALIBRAT LOD COEF and resulted in an invalid setting number.

Reaction: Handle LCD displays the warning while unit is allowed to continue to run. The invalid coefficient is cleared and all previously programmed weights for Q and iQ features are reset.

Cause / Remedy: Load cell calibration procedure composed of three steps: (1) zero the empty handle and any clevis or hook), (2) pick up a maximum capacity with and set the load cell coefficient, and (3) set unit in stack and set a true zero weight. This error is generated when performing (2). The possible causes can be:

- (a) Step (1) is not correctly performed with an empty handle.
- (b) The pickup weight does not match the rated capacity.
- (c) The programming sequences are not followed correctly.
- (d) Problem with the load cell electronics. This may include a damaged load cell, loose load cell cable connection to the actuator main interface board or to the servo drive.

Error #10405 - WARN_PROG_OVER_RANGE_LOADCELL_BIAS

Description: The sampled minimum load cell signal (bias) is greater than the acceptable range from the *normal bias value* for this unit. The acceptable range of this parameter is empirically determined and selected for different models and capacities.

Reaction: Handle LCD displays the warning while unit is allowed to continue to run. The over-range warning indicates the potential error in programming the parameter without altering the value. The sample value is still retained.

Cause / Remedy: The load cell minimum signal (bias) is sampled during procedure steps (1) and (3) (see Warning #10404). However, the *normal bias value* selected is based on step (3), when the unit is in slack. Therefore, if a handle, tooling, or additional parts are tare in step (1), this warning *will be triggered*. Ignore this warning if it is triggered in step (1). If this warning is triggered while the unit should be in slack, the possible causes can be:

- (a) The unit may appear to be in slack while a loading plate is still exerting pressure to the load cell. This may be due to some binding or drag in the rotary geartrain mechanism. Ensure the unit is in slack such that the rotary geartrain mechanism is pushed back (i.e. push up onto the white plastic wear ring at the bottom of the unit) and the unit cannot move down with a handle controller.
- (b) The metal mounting bracket of the white plastic wear ring onto the geartrain mechanism may be bent such that the wear ring cannot move back far enough and is touching the cast body housing opening prematurely. When the unit is loaded, the wear ring should be situated near the center of the circular opening without contact. The bracket may be bent if it is offset near a particular side significantly. Readjust the bracket or replace it.
- (c) Problem with the load cell electronics. This may include a damaged load cell or loose load cell cable connection to the actuator main interface board or to the servo drive.
- (d) The actuator PCB board which processes the load cell signal may be damaged or out of spec. Replace the PCB board.

Error #10406 - WARN_PROG_OVER_RANGE_LOADCELL_COEF

Description: The sampled maximum load cell signal (coefficient) is greater than the acceptable range from the *normal coefficient value* for this unit. The acceptable range of this parameter is empirically determined and selected for different models and capacities.

Reaction: Handle LCD displays the warning while unit is allowed to continue to run. The over-range warning indicates the potential error in programming the parameter without altering the value. The sample value is still retained.

Cause / Remedy: The load cell maximum signal (coefficient) is sampled during procedure step (2) (see Warning #10404). When this parameter is calibrated, the unit is expected to be loaded with a weight corresponding to the capacity of the unit. The possible causes can be:

- (a) Step (1) of the calibration procedure (see Warning #10404) is not correctly performed.
- (b) The pickup weight does not match the rated capacity.
- (c) The metal mounting bracket of the white plastic wear ring onto the geartrain mechanism may be bent such that the wear ring is pressing against the cast body housing opening. When the unit is loaded, the wear ring should be situated near the center of the circular opening without any contact. Readjust the bracket or replace it.
- (d) Problem with the load cell electronics. This may include a damaged load cell or loose load cell cable connection to the actuator main interface board or to the servo drive.
- (e) The actuator PCB board which processes the load cell signal may be damaged or out of spec. Replace the PCB board.

Error #10407 - WARN_PROG_OVER_RANGE_OVLD_LIMIT (OBSOLETE)

Description: One of the calibrated factory overload settings returned from the overload programming sequence is greater than the acceptable range from the *normal limit value* for this unit. The acceptable range of this parameter is empirically determined and selected for different models and capacities.

Reaction: Handle LCD displays the warning while the unit is allowed to continue to run. The over-range warning indicates the potential error in programming the parameter without altering the value. The sample value is still retained.

Cause / Remedy: The actuator characteristics are profiled such that while no actuators are expected to be identical, the characteristics are expected to be similar within a tolerance range. The possible causes of this warning are:

- (a) The pickup weight does not match the rated capacity.
- (b) The geartrain mechanism may be exerting excessive drag or binding such that the resultant actuator characteristic is significantly different from the tolerance range. Inspect for any mechanical problem and correct it.

Error #10408 - WARN_PROG_OVER_RANGE_OVLD_SHUTDOWN (OBSOLETE)

Description: One of the calibrated factory overload settings returned from the overload programming sequence is greater than the acceptable range from the *normal shutdown value* for this unit. The acceptable range of this parameter is empirically determined and selected for different models and capacities.

Reaction: Handle LCD displays the warning while unit is allowed to continue to run. The over-range warning indicates the potential error in programming the parameter without altering the value. The sample value is still retained.

Cause / Remedy: The actuator characteristics are profiled such that while no actuators are expected to be identical, the characteristics are expected to be similar within a tolerance range. The possible causes of this warning are:

- (a) The pickup weight does not match the rated capacity.
- (b) The geartrain mechanism may be exerting excessive drag or binding such that the resultant actuator characteristic is significantly different from the tolerance range. Inspect for any mechanical problem and correct it.

Command Warnings - Other Status**Error #10500 - WARN_STATUS_PLC_BATTERY_ERROR**

Description: The PLC memory retention battery power level is low or faulty.

Reaction: Handle LCD displays the warning while unit is allowed to continue to run.

Cause / Remedy:

1. Please contact Gorbel® Customer Service at 800-821-0086 or 585-924-6262 for replacement battery. When the battery is replaced, any unsaved configuration or Q/iQ feature settings are lost and revert back to the last saved or factory configured settings. Be sure to follow the instructions prior to taking out the battery.
2. Replace the battery as soon as possible. When the battery power has depleted, any unsaved settings are lost when the power to the unit is recycled and unit uploads the last saved or factory configured settings upon power up.

Error #10501 - WARN_MAX_NUM_RECORDING_REACHED (OBSOLETE)

Description: Not Used

Reaction: Not Used

Cause / Remedy: Not Used

Command Warnings - Non-Motion Watchdog Timer**Error #10600 - WARN_WATCHDOG_NON_MOTION**

Description: Not Used

Reaction: Not Used

Cause / Remedy: Not Used

Command Warnings - Motion Control**Error #11000 - WARN_BOTH_TRAVEL_LIMITS_ENGAGED**

Description: Both the upper and lower travel limit switches are engaged at motion startup (i.e. handle, pendant, float mode, etc.). This warning can only trigger after the unit has powered up and is different from error #501.

Reaction: Motion not started and handle display warning on the LCD.

Cause / Remedy:

- (a) If both the upper and slack switches are engaged, pull down on the wire rope to remove slack and recycle power on the unit.
- (b) Check for any mechanical binding that could engage both the upper and lower limit switches or upper limit and slack switches.
- (c) Check and correct if the limit switch cable is connected to the interface board.
- (d) Check for bad electrical connection or shorted wires from the switches.

Error #11001 - WARN_UNCONTROLLED_MODE_SWITCH

Description: The current running control mode (RUN MODE) is switched to another unexpectedly rather than handled properly such as Float Mode switching to Handle Mode because of grabbing a slide handle. Furthermore, a slide handle or pendant handle sends a unique signal to the PLC to differentiate the handle type. This is further used to check that if a handle is identified as a slide or pendant type but the identifier signal is switched to another type such that a miss-matched handle type is detected.

Reaction: Handle LCD displays the warning while unit is allowed to continue to run.

Cause / Remedy: When a control mode is started, the handle LCD displays the type of RUN MODE the unit is running at, e.g. HANDLE, PENDANT, or FLOAT MODE.

- (a) When the handle controller is used, if the LCD displays correctly its type, i.e. HANDLE or PENDANT, but this error is triggered while the unit is running; or the LCD displays the incorrect type at any time that does not match the actual handle type, the handle motherboard may be damaged and should be replaced.
- (b) For all other cases, please contact Gorbel Inc. to describe the symptoms and if the problem is reoccurring.

Error #11002 - WARN_OVLD_PROGM_NOT_SUCCESSFUL (OBSOLETE)

Description: The automatic overload programming routine is interrupted and is not completed.

Reaction: If programming routine is interrupted in an odd state, the recorded overload setting may be inaccurate and may falsely trigger overload while lifting.

Cause / Remedy: Please re-run the overload programming routine.

Error #11003 - WARN_SLIDE_PENDANT_TYPE_IO_BOTH_OFF

Description: Slide or pendant handle sends a unique signal to the PLC to differentiate the handle type. This error is caught if none of them is received.

Reaction: Unit is stopped with a warning display.

Cause / Remedy: Replace the slide or pendant handle motherboard.

Error #11004 - WARN_UP_DOWN_V_LIMITS_AT_SAME_POSITION

Description: This warning is triggered when both the Upper and Lower Virtual Limits are falsely attempted to be programmed to the same position, which would essentially stop all motion. This is done by checking if the distance gap between these two limits is less than 1". In other words, the Upper and Lower Virtual Limits must be at least 1" apart.

Reaction: Handle LCD displays the warning message and the virtual limit is not programmed.

Cause / Remedy: While this warning attempts to catch and prevent false setup, if it is intentional, move the two virtual limit positions slightly apart and re-program the virtual limit(s).

Error #11005 - WARN_LOADCELL_DROP_BELOW_MINIMUM

Description: This warning is triggered when Float Mode detects load cell signal drops below a minimum level indicating an electronics problem.

Reaction: Handle LCD displays the warning message and Float Mode is terminated.

Cause / Remedy: This fault is typically triggered when the load cell cable or signal wire(s) is disconnected or damaged. Check for:

- (a) loose or damaged load cell cable to the main circuit board in the actuator
- (b) loose or damaged intermedium cable, P/N 78613, to the main circuit board or the load cell analog signal wire(s) on this cable to the drive
- (c) damaged main circuit board for processing the load cell sensor
- (d) damaged load cell sensor

Error #11006 WARN_UO_EXCEED_MAX_CAPACITY

Description: This warning is triggered when User Programmable Overload attempts to tare a weight larger than the maximum limit. The maximum limit is set at 101% of the rated capacity plus 12 lbs to account for the handle weight.

Reaction: The overloaded tare weight is rejected and the maximum limit is used to set up the overload detection parameters.

Cause / Remedy: When TARE OVLD LMT selection from USR OVLD SUB-MENU \ CHANGE OVLD LMT in PROGRAM MODE is selected, unit tares the current lifted weight and applies overload settings proportional to this weight. This warning is triggered when the lifted weight exceeds the maximum limit. To prevent overload limit being set above maximum limit, when this error occurs, the maximum limit is applied instead of the tare value, to generate the corresponding overload detection parameters.

Please activate weight readout, WEIGHT READ ON_ under SETTINGS MENU in PROGRAM MODE, and ensure that the lifted weight does not exceed the maximum limit before selecting TARE OVLD LMT. This warning does not negatively affect system performance because overload parameters are set to the maximum allowable settings. User can cycle the E-stop switch on the handle to clear the warning.

Error #11007 WARN_UO_BELOW_MIN_LIMIT

Description: This warning is triggered when User Programmable Overload attempts to tare a weight less than 25% of the rated capacity.

Reaction: The tare weight is rejected and 25% of the rated capacity is used to set up the overload detection parameters.

Cause / Remedy: When TARE OVLD LMT selection from USR OVLD SUB-MENU \ CHANGE OVLD LMT in PROGRAM MODE is selected, unit tares the current lifted weight and applies overload settings proportional to this weight. This warning is triggered when the lifted weight is below the minimum 25% rated capacity limit. To prevent overload limit being set below the minimum, when this error occurs, the 25% rated capacity value is applied instead of the tare value, to generate the corresponding overload detection parameters.

Please activate weight readout, WEIGHT READ ON_ under SETTINGS MENU in PROGRAM MODE, and ensure that the lifted weight is not below the minimum limit before selecting TARE OVLD LMT. This warning does not negatively affect system performance because overload parameters are set to the minimum allowable settings. User can cycle the E-stop switch on the handle to clear the warning.

Error #11008 WARN_SLIDE_PENDANT_TYPE_OI_MISMATCH

Description: Slide or pendant handle sends a unique signal to the PLC to differentiate the handle type. This error is generated if handle type signal changes from slide to pendant or vice versa while the unit is running.

Reaction: Unit is stopped with a warning display.

Cause / Remedy: Replace the slide or pendant handle mother board.

Command Warnings - Custom Motion Control**Error #11100 - WARN_MULTP_MOTION_REQUEST**

Description: Not Used

Reaction: Not Used

Cause / Remedy: Not Used

Command Warnings - Motion Command Watchdog Timer**Error #11600 - WARN_WATCHDOG_MOTION**

Description: Not Used

Reaction: Not Used

Cause / Remedy: Not Used

Command Warnings - Maintenance Services

Error #11700 - WARN_REPLACE_WIREROPE_RECOMMEND

Description: When cycle count and lower limits are set, cycle count can increment. This warning is triggered if the cycle exceeds 15000 counts.

Reaction: N/A

Cause / Remedy: This is a warning indicator to check wire rope condition under the most severe operating conditions for signs of wear and tear and it can vary based on the actual usage. Please examine the wire rope and replace if necessary. After replacement, activate Program Mode with a handle, browse to SRV MENU, and click to CLEAR COUNT selection to reset the cycle count to 0.

Error #11701 - WARN_REPLACE_WIREROPE_REQUIRED

Description: When cycle count and lower limits are set, cycle count can increment. This warning is triggered if the cycle exceeds 20000 counts.

Reaction: N/A

Cause / Remedy: This is a warning indicator to check wire rope condition under the most severe operating conditions when replacement may be necessary and it can vary based on the actual usage. Please examine the wire rope and replace if necessary. After replacement, activate Program Mode with a handle, browse to SRV MENU, and click to CLEAR COUNT selection to reset the cycle count to 0.

Command Warnings - Fault Warning

Error #11800 - WARN_HANDLE_FAULT_NOT_ACTIVE

Description: Handle digital IO CAN bus controller has triggered a fault and becomes inactive.

Reaction: The digital inputs such as the OPS sensor, Menu and Float pushbuttons are disabled.

Cause / Remedy: A fault, specifically an *inactive node*, can occur if the handle CAN bus controller does not communicate with the PLC correctly and exceeds the allowable wait period of the master node. Reboot the unit with the E-stop to clear the fault if it is not repetitive. Inaccurate communication can result from faulty handle board, noise or data corruption in the CAN communication wires, or any cut wires. Replace the handle, coil cord, actuator interface board, and CAN communication wires in the actuator until the fault is corrected.

Error #11801 - WARN_HANDLE_FAULT_CAN_IO_ALARM

Description: Handle digital IO CAN bus controller has triggered an alarm status. Additional error information may be available following the warning.

Reaction: The digital inputs such as the OPS sensor, Menu and Float pushbuttons are disabled.

Cause / Remedy: A fault, specifically a *CAN bus alarm*, can occur if the CAN controller board does not communicate with the PLC correctly, is in a fault state, falsely removed, configuration memory error, etc. Additional error information may be available after the warning message. Reboot the unit with the E-stop to clear the fault if it is not repetitive. Problem can result from faulty handle board, noise or data corruption in the CAN communication wires, or any cut wires. Replace the handle, coil cord, actuator interface board, and CAN communication wires in the actuator until the fault is corrected.

Error #11802 - WARN_HANDLE_FAULT_BUS_OFF

Description: Handle digital IO CAN bus controller has been turned off unintentionally. If a WARN_HANDLE_FAULT_NOT_ACTIVE warning does not occur together with this, then the bus line is turned off only briefly.

Reaction: The digital inputs such as the OPS sensor, Menu and Float pushbuttons are disabled.

Cause / Remedy: A fault, specifically *bus off exception*, can occur if the handle CAN controller does not communicate with the PLC correctly or at all. Reboot the unit with the E-stop to clear the fault if it is not repetitive. Inaccurate communication can result from faulty handle board, noise or data corruption in the CAN communication wires, or any cut wires. Replace the handle, coil cord, actuator interface board, and CAN communication wires in the actuator until the fault is corrected.

Error #11803 - WARN_LCD_FAULT_NOT_ACTIVE

Description: Handle LCD board CAN bus controller has triggered a fault and becomes inactive.

Reaction: Warning message on this fault may be on screen or by flashing LED. If the board has become inoperative, a factory default warning message may be displayed on the LCD screen.

Cause / Remedy: A fault, specifically an *inactive node*, can occur if the handle LCD board CAN bus controller does not communicate with the PLC correctly and exceeds the allowable wait period of the master node. Reboot the unit with the E-stop to clear the fault if it is not repetitive. Inaccurate communication can result from faulty handle board, noise or data corruption in the CAN communication wires, or any cut wires. Replace the handle, coil cord, actuator interface board, and CAN communication wires in the actuator until the fault is corrected.

Error #11804 - WARN_LCD_FAULT_CAN_IO_ALARM

Description: Handle LCD board CAN bus controller has triggered an alarm status. Additional error information may be available following the warning.

Reaction: Warning message on this fault may be on screen or by flashing LED. If the board has become inoperative, a factory default warning message may be displayed on the LCD screen.

Cause / Remedy: A fault, specifically a *CAN bus alarm*, can occur if the CAN controller board does not communicate with the PLC correctly, is in a fault state, falsely removed, configuration memory error, etc. Additional error information may be available after the warning message. Reboot the unit with the E-stop to clear the fault if it is not repetitive. Problem can result from faulty handle board, noise or data corruption in the CAN communication wires, or any cut wires. Replace the handle, coil cord, actuator interface board, and CAN communication wires in the actuator until the fault is corrected.

Error #11805 - WARN_LCD_FAULT_BUS_OFF

Description: Handle LCD board CAN bus controller has been turned off unintentionally. If a WARN_LCD_FAULT_NOT_ACTIVE warning does not occur together with this, then the bus line is turned off only briefly.

Reaction: Warning message on this fault may be on screen or by flashing LED. If the board has become inoperative, a factory default warning message may be displayed on the LCD screen.

Cause / Remedy: A fault, specifically *bus off exception*, can occur if the handle CAN controller does not communicate with the PLC correctly or at all. Reboot the unit with the E-stop to clear the fault if it is not repetitive. Inaccurate communication can result from faulty handle board, noise or data corruption in the CAN communication wires, or any cut wires. Replace the handle, coil cord, actuator interface board, and CAN communication wires in the actuator until the fault is corrected.

Error #11806 - WARN_SPAREIO_FAULT_NOT_ACTIVE

Description: An X67 spare IO block CAN bus controller connected to the handle has triggered a fault and become inactive.

Reaction: Standard iQ features operating through this spare IO block are either disabled or outputs turned off.

Cause / Remedy: A fault, specifically an *inactive node*, can occur if an X67 spare IO block CAN bus controller does not communicate with the PLC correctly and exceeds the allowable wait period of the master node. Reboot the unit with the E-stop to clear the fault if it is not repetitive. Inaccurate communication can result from faulty handle board, noise or data corruption in the CAN communication wires, or any cut wires. Replace the handle, coil cord, actuator interface board, and CAN communication wires in the actuator until the fault is corrected.

Error #11807 - WARN_SPAREIO_FAULT_CAN_IO_ALARM

Description: An X67 spare IO block CAN bus controller connected to the handle has triggered an alarm status. Additional error information may be available following the warning message.

Reaction: Standard iQ features operating through this spare IO block are either disabled or outputs turned off.

Cause / Remedy: A fault, specifically a *CAN bus alarm*, can occur if the CAN controller board does not communicate with the PLC correctly, is in a fault state, falsely removed, configuration memory error, etc. Additional error information may be available after the warning message. Reboot the unit with the E-stop to clear the fault if it is not repetitive. Problem can result from faulty handle board, noise or data corruption in the CAN communication wires, or any cut wires. It can also be triggered if a channel in the X67 spare IO module is configured as an output but 24Vdc is sent to this channel, for example, due to miss-wiring. Check and correct any wiring into a false channel or false custom feature configuration. Replace the handle, coil cord, actuator interface board, and CAN communication wires in the actuator until the fault is corrected.

Error #11808 - WARN_SPAREIO_FAULT_BUS_OFF

Description: An X67 spare IO block CAN bus controller connected to the handle has been turned off unintentionally. If a WARN_SPAREIO_FAULT_NOT_ACTIVE warning does not occur together with this, then the bus line is turned off only briefly.

Reaction: Standard iQ features operating through this spare IO block are either disabled or outputs turned off.

Cause / Remedy: A fault, specifically *bus off exception*, can occur if the X67 spare IO block CAN controller does not communicate with the PLC correctly or at all. Reboot the unit with the E-stop to clear the fault if it is not repetitive. Inaccurate communication can result from faulty handle board, noise or data corruption in the CAN communication wires, or any cut wires. Replace the handle, coil cord, actuator interface board, and CAN communication wires in the actuator until the fault is corrected.

Error #11809 - WARN_CANIO_FAULT

Description: The CAN bus controller fault checking routine has experienced an error or the detected failed CAN bus board has a node number outside the designed range of the system.

Reaction: N/A

Cause / Remedy: In the system application there is an exception fault checking routine on all CAN bus controller boards if the system is running constantly. This warning occurs if the routine itself experiences a fault such as unconfigured bus, node or even application. User should reboot the unit with the E-stop to clear the fault if it is not repetitive. Similar to other CAN bus controller warnings, replace the handle, coil cord, actuator interface board, and CAN communication wires in the actuator until the fault is corrected. If the problem cannot be resolved, contact Gorbel® Customer Service at 800-821-0086 or 585-924-6262 for further diagnostic and troubleshooting information.

Q-iQ Unit: Command Fault - Extended Error List (Software Version R1.06.3)

Command Fault (E#)	Extended Error (S#)	Description: Command Fault and Extended Fault Supplement Information
320	Ext	Multiple iQ features are configured to use the same digital input channels. Ext is the latter feature that triggers the fault.
321	Ext	Multiple iQ features are configured to use the same digital output channel. Ext is the latter feature that triggers the fault.
322	Ext	An iQ feature input channel is set outside the allowable range. Ext is the feature that triggers the fault.
323	Ext	An iQ feature output channel is set outside the allowable range. Ext is the feature that triggers the fault.
1600	Ext	While executing a Jog, Handle, Float, or other custom motion, a processing command is taking too long to execute. Ext is the state of execution when this error is generated. Please contact Gorbel Inc. with this error number.
331	--	A fault has been triggered while configuring the spare I/O block. Please follow the recommended remedy for this fault such as resetting configurations to factory default.
	65535	System has configured the module and is waiting for confirmation.
	8955	The module is not properly configured, specifically the CAN bus number.
	8956	The module is not properly configured, specifically the CAN node number.
	8976	Missing software module to process the module.
	8978	Missing software module to process the module.
	8979	The module status has become inactive.
100 101 102 103 104 105 120 121 122	--	A fault has been triggered while executing a command to process the stored system configuration or unit serial number in the CPU memory. Please contact Gorbel Inc. with these error numbers.
	20600	Wrong parameter given (NULL pointer)
	20601	Object already present
	20602	Wrong target memory specified
	20603	No memory available for module to be created
	20604	Error installing data object
	20605	Object not found
	20606	Wrong object type (not data object)
	20607	Wrong offset specified
	20608	Wrong length specified
	20609	Data object not found
	20610	Wrong date in SetDate (DatObjChangeDate)
	20611	Incorrect state of the data object
	20612	Error while enabling asynchronous handler (only SG4)
	20613	Module name too long (max. 100 characters)
20614	Error while saving the data object in "Flash" memory	

Command Fault (E#)	Extended Error (S#)	Description: Command Fault and Extended Fault Supplement Information
	--	An alarm fault has been triggered while processing one of the electrical components connected in the communication line, including the handle board, LCD display, spare I/O block, and the overall CAN communication. Please check the specific extended fault description for possible corrective actions. Note: Standard iQ system uses adapter module 1 without any screw-in module whereas adapter module 2 or screw-in module(s) may be used on a custom system setup. The error numbers are listed for completeness whereas certain errors do not apply to some components, e.g. S#16904 cannot occur with E#11804, LCD display.
	4352 ~ 4368	Idle time has passed for designed digital output module 4352 (Adapter module 1); 4368 (Adapter module 2)
	4352 ~ 4368	Output set, even though no output is defined 4608 (Adapter module 1); 4624 (Adapter module 2)
	4864 ~ 4880	Output level incorrect - short circuit on a digital output module 4864 (Adapter module 1); 4880 (Adapter module 2)
	8448 ~ 8467	Idle time has passed for designed analog output module 8448 ~ 8451: Screw-in module 1 ~ 4 on Adapter module 1 8464 ~ 8467: Screw-in module 1 ~ 4 on Adapter module 2
	16384 ~ 16400	Voltage monitoring has found an error 16384 (Adapter module 1); 16400 (Adapter module 2)
	16640 ~ 16656	Error flag for digital input module set (often triggered on spare I/O module) 16640 (Adapter module 1); 16656 (Adapter module 2)
	16896 ~ 16927	Error flag for digital output module set (often triggered on spare I/O module) 16896 (Adapter module 1); 16904 ~ 16911: I/O Channel 1 ~ 8 16912 (Adapter module 2); 16920 ~ 16927: I/O Channel 1 ~ 8
11801	20480	Programming configuration memory ended without error
	20736	Faulty or incorrect parameter in command request
11804	20992	No configuration memory available
	21248	Error when writing to configuration memory
11807	21504	Configuration memory is being written to
		Invalid channel or value
11809	798720 ~ 798739	798720 ~ 798723: Screw-in module 1 ~ 4 on Adapter module 1 798736 ~ 798739: Screw-in module 1 ~ 4 on Adapter module 2
	798976 ~ 798995	Measurement range exceeded (positive direction) 798976 ~ 798979: Screw-in module 1 ~ 4 on Adapter module 1 798992 ~ 798995: Screw-in module 1 ~ 4 on Adapter module 2
	799232 ~ 799251	Measurement range exceeded (negative direction) 799232 ~ 799235: Screw-in module 1 ~ 4 on Adapter module 1 799248 ~ 799251: Screw-in module 1 ~ 4 on Adapter module 2
	799488 ~ 799507	Open connector or sensor open 799488 ~ 799491: Screw-in module 1 ~ 4 on Adapter module 1 799504 ~ 799507: Screw-in module 1 ~ 4 on Adapter module 2
	799744 ~ 799763	Converter error 799744 ~ 799747: Screw-in module 1 ~ 4 on Adapter module 1 799760 ~ 799763: Screw-in module 1 ~ 4 on Adapter module 2
	800000 ~ 800019	Screw-in module removed 800000 ~ 800003: Screw-in module 1 ~ 4 on Adapter module 1 800016 ~ 800019: Screw-in module 1 ~ 4 on Adapter module 2
	800256 ~ 800275	Screw-in module inactive 800256 ~ 800259: Screw-in module 1 ~ 4 on Adapter module 1 800272 ~ 800275: Screw in module 1 ~ 4 on Adapter module 2
	800512 ~ 800531	Screw-in module communication error 800512 ~ 800515: Screw-in module 1 ~ 4 on Adapter module 1 800528 ~ 800531: Screw-in module 1 ~ 4 on Adapter module 2
	800768 ~ 800787	Screw-in module type changed 800768 ~ 800771: Screw-in module 1 ~ 4 on Adapter module 1 800784 ~ 800787: Screw-in module 1 ~ 4 on Adapter module 2

Chapter 8 - Electrical Schematics




Diagram 1. Q-iQ Block.




Diagram 2. Q-iQ System Schematic.





Diagram 3. Cable Interconnect, 474 CPU and Drive.



iQ Actuator Input/Output Module Functionality

I/O Point	Assigned Function	Description	Settings (see chart 1, page 5-3) for instructions on navigating and setting menu functions)
1	Input - Dual virtual limit sets	When this input is turned on, the G-Force® switches to a second independent set of virtual limits. See chart C for instructions on setting each of these limit sets.	Second set of virtual limits is done the same as the standard set but with this input on.
2	Future expansion - no default functionality assigned	Functionality may be assigned via custom programming to meet application requirements. Contact your Gorbel® dealer for more details.	
3	Future expansion - no default functionality assigned	Functionality may be assigned via custom programming to meet application requirements. Contact your Gorbel® dealer for more details.	
4	Future expansion - no default functionality assigned	Functionality may be assigned via custom programming to meet application requirements. Contact your Gorbel® dealer for more details.	
5	Output - External device control (requires optional expansion 8-point input/output block)	This output is controlled by input number 5 on the optional expansion 8-point input/output block. When that input is on, output 5 on the iQ actuator input/output module is on and vice versa.	
6	Output - External device control (requires optional expansion 8-point input/output block)	This output is controlled by input number 6 on the optional expansion 8-point input/output block. When that input is on, output 6 on the iQ actuator input/output module is on and vice versa.	
7	Output - Service indicator	This output turns on when service is required (based on hours of use and set at the factory) and may be used to turn on an external service indicator (supplied by others).	The reset function for this output is in the SERVICE MENU, items CLEAR RUN TIME or SRV WARN OFF.
8	Output - Fault indicator	This output turns on when a command fault or drive fault occurs. It does not turn on due to a command warning.	

Chart 1. iQ Actuator Input/Output Module Standard Functionality.




Diagram 5. Actuator CPU Input/Output Block.

Expansion 8-Point Input/Output Block Functionality

I/O Point	Assigned Function	Description	Settings (see chart 1, page 5-3, for instructions on navigating and setting menu functions)
1	Input - Dual load weight Float Mode*	When the G-Force® is in float mode, this input allows switching from one pre-programmed load weight to another. These two weights must remain fixed; otherwise, some drifting can occur if the weight is different than the programmed value.	The two Float Mode load weights programmed are located in SETTINGS MENU 2 - DUAL TOOL WT and DUAL FM LOAD WT. The desired load weight must be suspended from the G-Force® when performing each setting.
2	Input - Anti-drop feature (Clamp request)	This input is typically wired to a clamp request pushbutton. When the input is on, Output #7 (see I/O Point 7) turns on and Output #8 turns off regardless of the tooling loading state.	See I/O Point 3 Settings description.
3	Output - Anti-drop feature (Unclamp request)	This input is typically wired to an unclamp request pushbutton. When the input is on, Output #8 (see I/O Point 8) turns on only if Anti-Drop algorithm determines the suspended load is at or below the set weight (ANTIDROP TOOL WT). If Output #8 turns on, Output #7 is turned off.	Programming to tare weight is located at SETTINGS MENU 2 - ANTIDROP TOOL WT. The empty tooling (including handle controller and other accessories) without a pickup part must be suspended solely by the wire rope when tarring. The minimum difference between unloaded and loaded tool weight is 20 lbs. for G-Force®, 25 lbs. for Easy Arm®, and 25 lbs. for G-Jib™ products.
4	Input - Auto Home	When this input is toggled (momentarily turned on then off again), the G-Force® automatically travels to the set home position in the vertical travel. Tracking stops when obstruction is detected, i.e. Q/iQ G-Force® stops at 10-25 lbs. depending on unit capacity.	The Auto Home position programming is located at SETTINGS MENU 2 - MENU 2 SET HOME. Move the G-Force® to the desired position in the vertical travel before selecting the position setting in this menu.
5	Input - External device control (used in conjunction with actuator output 5)	This input controls input 5 on the actuator input/output module. When this input is on, output 5 on the iQ actuator input/output module is on and vice versa.	
6	Input - External device control (used in conjunction with actuator output 6)	This input controls input 6 on the actuator input/output module. When this input is on, output 6 on the iQ actuator input/output module is on and vice versa.	
7	Output - Anti-drop feature (Clamp Control)	This output is typically wired to actuate the clamping mechanism of an end effector tooling. It turns on when Input #2 (see I/O Point 2) is on and remains latched on when the input is released. It can be turned off by Input #3 (see I/O Point 3).	See I/O Point 3 Settings description.
8	Output - Anti-drop feature (Unclamp Control)	This output is typically wired to actuate the unclamping mechanism of an end effector tooling. It turns on when Input #3 (see I/O Point 3) is on and the Anti-Drop algorithm determines the suspended load is at or below the set weight (ANTIDROP TOOL WT). If it is not turned on, the input can be held momentarily (do not hold on indefinitely) until the tooling is unloaded then the output is turned on. Once the output turns on, it remains latched on when the input is released. It is always turned off with Input #2 (see I/O Point 2).	See I/O Point 3 Settings description.

Chart 2. Expansion 8-Point Input/Output Block.

* G-Force® must have Float Mode feature enabled for this feature to work.

WARNING

Please be aware that software versions prior to R1.07.0 use I/O block model X67BC7321, while those with R1.07.0 and newer require the X67BC7321-1 model. The model number can be found at the left side of the block when placed in the orientation as shown in the diagram. The running software version can be checked through DISPLAY SYS INFO selection under SERVICE MENU in PROGRAM MODE.





Diagram 6. Handle Input/Output Block.



** RESERVED
 * CABLE ASSY'S 78691 & 78692 MAY BE SUBSTITUTED WITH IDENTICAL ASSY'S 7871 & 7872 WITH 9° DEG CONNECTION

Note: Numbers in Parentheses are Gorbel® Part Numbers

Diagram 7. Q-iQ Handle Configurations.




Diagram 8. Actuator IO, 474 CPU.




Diagram 9. Handle IO Detail, Slide Model.




Diagram 10. Handle IO Detail, Pendant Model.

Note: Numbers in
Parentheses are
Gorbel® Part Numbers

Chapter 9 - Adjustments

Upper and Lower Limit Switch Adjustment

Under normal conditions the Upper and Lower Limit Switches should not require adjustment in the field unless one were to fail and require replacement. These switches are set in the factory during assembly and final testing. There could be situations however that would require a slight adjustment. For example, when replacing a wire rope assembly, the end of the wire rope and the retaining plate must be positioned precisely in order to perform the wire rope replacement properly. If this is not the case then the Lower Limit Switch adjustment may be necessary.

The Limit Switch Assembly is located inside the actuator, on the right side, behind the Gorbel logo on the center casting. You must remove the Front Cover to access this area. Refer to **diagram 1** below.




Diagram 1.

Upper Limit Switch Adjustment

The bottom allen head screw adjusts the upper limit. Use a 5mm allen head wrench to perform the adjustment. Turning the screw clockwise raises the stop point of the wire rope. Counterclockwise lowers the stop point of the wire rope. A full turn is approximately 3 inches of wire rope travel. Refer to **diagram 2** on page 9-2.




Diagram 2.

Lower Limit Switch Adjustment

The lower limit is a default of the wire rope replacement position. When this switch is actuated there should be approximately two full turns of wire rope left on the drum. There is no adjustment for this position. The switch provides protection for the hardware inside the actuator. Refer to **diagram 3** below.




Diagram 3.

Wire Rope Replacement Adjustment for the Lower Limit Switch

In order to determine whether this adjustment needs to be performed you must push the upper allen head screw in until it bottoms out against the body of the Limit Switch Actuator as illustrated in **diagram 4** below and press the Jog Down Button until the drum stops and the Wire Rope Retaining Plate is approximately at the 2-3 o'clock position as shown in **diagram 5** below. If the drum does not reach this position when it stops, turn the upper allen head screw 1/2 turn counterclockwise with a 5 mm allen head wrench. Jog the wire rope up one full turn and repeat the process all over again.

Caution: If the wire rope retaining plate rotates past the 4 o'clock position, release the Jog Down Button immediately or internal damage may occur. Press the Jog Up Button until the drum makes one full rotation and adjust the Lower Limit Switch by turning the upper allen head screw one full turn clockwise.




Diagram 4.




Diagram 5.

Linear Transducer Adjustment

If there is motion (drift) in the system when the Operator Present Sensor is activated and the handle grip is not moved in either direction, the Linear Transducer will need to be adjusted. The adjustment can be monitored by using DIAGNOSTIC MODE in the PROGRAM MENU.

1. Press and hold the MENU button (right side of handle) for two seconds to activate Program Mode.

2. Release MENU button. Both the red and blue LED will illuminate and PROGRAM MODE will be displayed for one second. **Note:** If system is equipped with the Virtual Limits Package the VIRTUAL LIMITS menu will appear first.

3. Press the MENU button to scroll until you reach the SERVICE MENU. Press the G-Force® logo button (left side of the handle) several times until the readout displays SERV MENU ACT DIAG. Wait approximately 2 seconds.

4. DIAG MODE will appear on the display. Block the Operator Present Sensor beam with your hand but do not move the slide portion of the handle at all.

5. HANDLE SWITCH STROKE MAX % will appear on the display with a number. It should be between -3% and 3%.

6. To decrease the number on the display, turn the LT Adjustment Screw counter clockwise. To increase the number on the display, turn the LT Adjustment Screw clockwise. Use a 2mm Allen head wrench for the adjustment. Try increments of one revolution at a time.

7. Recheck the number on the display by blocking and unblocking the OPS at least five times.



Diagram 6.

Slack Spring Adjustment

Slack spring adjustment is necessary if one or more of the following conditions apply:

- When wire rope continues to “pay out” from actuator when end effector (handle, tooling) is being supported and down travel is commanded.
- When slack wire rope deflection exceeds 3 inches when end effector is supported.
- When tooling is added to a G360™ assembly.
- When an air-line coil hose assembly is added between the end effector and actuator.
- When changing from a pendant handle to a slide handle or vice-versa occurs.
- **When chatter or erratic travel down operation occurs when using an unloaded G360¹ or a weighted hook traveling downward from top of travel up limit (spring is too tight).**

¹Unloaded G360™ equipped hoist may encounter this type of operation until tooling is added.

Slack Spring Adjustment Procedure:

1. Use an M3 hex wrench to remove all screws securing the blue rear cover to actuator. Place screws in cover and set aside.
2. Locate slack spring over the motor, next to casting (**diagram 7**). Spring is held in place by a motor bracket on one end and an eyebolt on the other end.
3. Using a 10mm open-end wrench, loosen the nut closest to the “eye” inside on bolt (**diagram 8**).




Diagram 7.




Diagram 8.

4. **If chatter or erratic operation of hoist while traveling down is encountered**, the end effector or tooling on wire rope is not heavy enough to overcome the spring tension. Loosen the outside nut one half turn and test the hoist operation (full stroke up and down) between each half turn adjustment of eyebolt but until chattering is eliminated.

5. All other conditions will require the outside nut to be adjusted by turning clockwise, tightening to increase tension to the slack spring. Before tightening of this nut, be sure there is enough free travel of the eyebolt (inside nut loose).
6. Using the applications' end effector (handle, unloaded end tool), travel downward resting end effector on floor. If rope continues to "pay out" from actuator beyond two seconds after reaching floor, remove hand from handle or release down button (pendant). Turn the outside nut clockwise one half turn tightening it. Test again by traveling up removing handle or tooling from floor and travel down again resting on floor. Continue adjusting and testing this until rope travel stops within two seconds of effector resting (supported) on floor and deflection of rope is 3-4 inches. Tighten inside nut clockwise until "jammed" against sheet metal while keeping eyebolt stationary.
7. Correct slack adjustment occurs when a deflection of the wire rope is 3-4 inches when in slack mode and rope travel stops (**diagram 9**).




Diagram 9.

Chapter 10 - Parts & Assembly

This chapter provides the Gorbel® part numbers for all capacity G-Force® Q and iQ models as well as the removal and replacement instructions for most of the components inside the actuators and control handles.

In most cases the Gorbel® part numbers for all three capacity G-Forces are the same. Where there are differences, separate pages are used to illustrate the differences. All Gorbel® part numbers are shown in parentheses and bold print.


Index

Actuator	10-2
Slide Handle	10-40
Pendant Handle	10-53
Coil Cords	10-67
G360™	10-74
CPU Battery	10-80

CAUTION!

Many of the removal/replacement procedures in this section require AC power to be removed from the actuator. You must disconnect the AC power plug from the AC source in order to do this or use a disconnect, if equipped with one. Using the e-stop button will not accomplish this because it does not interrupt AC power to the actuator.

Removal and Replacement Procedures **ACTUATOR**



Note: Numbers in Parentheses are Gorbel® Part Numbers

G-Force® Actuator Labels.

Capacity	P/N	Capacity	P/N
Q 300 kg	76555	iQ 300 kg	76552
Q 660 lb.	76561	iQ 660 lb.	76558
Q 150 kg	76556	iQ 150 kg	76553
Q 330 lb.	76562	iQ 330 lb.	76559
Q 75 kg	76557	iQ 75 kg	76554
Q 165 lb.	76563	iQ 165 lb.	76560
Q 600 kg Q 1320 lb.	83268	iQ 600 kg iQ 1320 lb.	83268

Procedure 1A - Front Cover Removal

- a. Turn power off by disconnecting AC power to the system.
- b. Remove (4) M5 button head cap screws, BHCS and (4) M5 lockwashers.
- c. Carefully slide front cover away from actuator casting.

Procedure 1B - Front Cover Replacement

- a. Carefully slide front cover over ACOPOS assembly and align four holes with brackets attached to the actuator casting.
- b. Install (4) M5 button head cap screws, BHCS and (4) M5 lockwashers.
- c. Restore AC power to the system.




Diagram 1. Front Cover Removal and Replacement.

Procedure 2A - Rear Cover Removal

- a. Turn power off by disconnecting AC power to the system.
- b. Remove (4) M5 button head cap screws, BHCS and (4) M5 lockwashers.
- c. Carefully slide rear cover away from actuator casting.

Procedure 2B - Rear Cover Replacement

- a. Carefully slide rear cover over motor, CPU and power supply and align holes with the actuator casting.
- b. Install (4) M5 button head cap screws, BHCS and (4) M5 lockwashers.
- c. Restore AC power to the system.






Diagram 2. Rear Cover Removal and Replacement.



Procedure 3A - Wire Rope Assembly Removal

Warning: Wire rope replacement is to be performed by qualified maintenance personnel only.

- a. Make sure the replacement rope is same length and diameter (3/16 or 1/4) as rope currently on actuator unit.
 - i. Ensure there is no load on handle, weighted load hook (pendant) or end effector.
 - ii. If using slow down setting, clear (reset) on handle or pendant handle menu screen. If using virtual limits, clear (reset) on handle or the pendant handle's menu screen.
 - iii. Remove end tool.
 - Slide handle: Using a 19mm socket and ratchet, remove the nut from the handle's socket head shoulder screw, then use an M8 hex wrench and remove (unthread) socket head shoulder screw from handle. This will detach it from wire rope thimble. Set handle down on bench or table to support it and not stretch coil cord.
 - Pendant handle: Remove the weighted hook or end effector from rope removing the clip and pin and set aside.
- b. Using a 3mm hex wrench, remove the (4) button head screws on front cover (two on each side of unit).
- c. Remove front cover from actuator and set aside upward to use as a bowl to hold future parts. **Note:** Be careful not to contact circuit board.
- d. Going in the down direction, unspool rope from drum using jog down button while keeping tension on wire rope with other hand wearing a glove. Continue until lower limit is engaged.
- e. Insert a medium sized screwdriver between the white colored wear ring and the actuator black casting where the wire rope exits the actuator (right side). This will keep the slack switch disengaged while jogging down the remainder of the rope (**diagram 3A**).
- f. Face the unit with circuit board on your left and wire rope on the right.



Diagram 3A.

Insert screwdriver between the white wear ring and the actuator casting where the rope exits the actuator.

Note: The next two steps must be done at the same time.

- g. Using a long screwdriver or hex wrench, reach through front of actuator and locate upper socket head cap screw head facing you underneath the lower limit switch. Fully push the screw in until it cannot move anymore (it is spring loaded). Keep pressure on it (**diagram 3B**).
- h. Using your right hand, press the jog down button while watching the drum rotate two full turns in the clockwise direction. The drum should stop automatically with the wire rope retainer visible in the 3 o'clock position on the drum.





Diagram 3B.


Locate socket head cap screw head and fully push it in until it can not move anymore.

- i. From the limit switches is a gray colored lead that plugs into the circuit board. Its connected location is approximately (2) inches down the right side of the circuit board labeled "limits". Gently pull out the plug lead to disconnect the plug from board (**diagram 3C**).
- j. Using a 3mm hex wrench, remove (4) M5 button head cap screws that fasten the swiveling circuit board bracket to the front support plate. (2) screws are located on the top and (2) are on the bottom of bracket. Set screws in plastic front cover. Swing bracket out towards you and to the left (**diagrams 3D**).
- k. Using 13mm open-end wrench, loosen, but do not remove, the (2) flange nuts and remove reinforcement bracket (**diagram 3E**) (330 lb. (150 kg) and 660 lb. (300 kg) units only).
- l. Using an M5 hex wrench, remove (2) M6 socket head cap screws from the drum gates. Slide the unthreaded gate out towards you. Place gate and hardware in front cover (**diagram 3F**).
- m. Using an M6 hex wrench, remove the (2) M8 socket head cap screws from the rope retainer and slide retainer off of rope end toward you. Set retainer and screws in front cover (**diagram 3G**). **Note:** 165 and 330 lb. units use two 5mm button head cap screws (BHCS).
- n. Grasp wire rope with right hand where it exits actuator. Keep rope from bending while pushing rope upward to unseat the stop sleeve from the anchor channel. If this does not work, use a medium screwdriver (flat) sliding it upward between rope and drum to progressively pry rope out of anchor channel while still pushing up on rope. Remove rope from actuator through opening at bottom once unseated (**diagram 3H**).


**Diagram 3C.**

Gently pull out the grey limit switch wiring lead to disconnect plug from board.


Top




Bottom

**Diagrams 3D.**


Remove four M5 socket head cap screws (two on top, two on bottom) that fasten the swiveling circuit board bracket to the front support plate.

**Diagram 3E.**

Loosen flange nuts to remove reinforcement bracket.

**Diagram 3F.**

Remove two M6 socket head cap screws from the drum gates.

**Diagram 3G.**

Remove M8 socket head cap screws and slide retainer off rope end towards you.

**Diagram 3H.**

Remove rope from actuator through opening at bottom.

Procedure 3B - Wire Rope Assembly Replacement

- a. Insert end of wire rope assembly upward through coil cord bracket with right hand. With left hand, grab free end, and bend rope to form loop, tightly enough to insert loop portion into groove of drum (**diagram 3I**). At this point, free end will project from face of drum by several inches (**diagram 3J**).
- b. By pulling downward with right hand and holding rope in groove with left hand, rope end can then be pulled into recess in drum face (**diagram 3K**).
- c. Make sure retainer plug on end of wire rope is fully seated in recess before replacing rope retainer plate (**diagram 3L**).
- d. Install the rope retainer plate over the rope end and install the (2) M8 socket head cap screws and lockwashers. Torque hardware to fully compress lockwashers.
- e. Ensure that rope is seated in radius channel and install rope gate back in the unit making sure the rope guide (cutout) side is inserted first and the ends are sliding on guide rails freely. Fasten the rope gate assembly together using the previously removed hardware. Torque hardware to compress lockwashers.
- f. Install (slide) the reinforcement bracket studs into channel and tighten the (2) 13mm flange nuts. Next, swing circuit board bracket closed towards plate and fasten to plate using the (4) previously removed socket head cap screws and lockwashers. Torque hardware to compress lockwashers.
- g. Plug limit switch lead into circuit board “limits” receptacle making sure retention tab on plug is facing you.
- h. Using a clean cotton cloth wrapped around rope loosely near actuator entrance, pull down on rope and press jog up button allowing rope to pass through cloth cleaning it as it is being wrapped onto the drum. Continue loading rope onto drum using jog button until (3) drum revolutions are completed.
- i. Remove screwdriver from between actuator and wear ring.
- j. Install front cover onto actuator making sure all (4) screws are aligned with tabs before threading.
- k. If using coil cord, make sure rope is inserted down through the middle of the coils.
- l. Attach wire rope to handle, weighted hook, or end effector in reverse order of disassembly.
- m. Reset virtual limits and/or slow down settings.




Diagram 3I.

Form loop in wire rope and insert loop portion into groove of drum.




Diagram 3J.

Free end of wire rope projects from face of drum by several inches.




Diagram 3K.

Pull wire rope end into recess of drum face.




Diagram 3L.


Retainer plug on end of wire rope should be fully seated in recess.

Procedure 4A - Electrical Shield Removal

- a. Turn power off by disconnecting AC power to the system.
- b. Remove front cover. Refer to Procedure 1A.
- c. Remove (3) M3 socket head cap screws, SHCS and M3 lockwashers.
- d. Remove (3) shield standoffs.
- e. Remove electrical shield.

Procedure 4B - Electrical Shield Replacement

- a. Position the electrical shield and align (1) shield standoff with the corresponding hole in the actuator main PCB.
- b. Install (1) M3 socket head cap screw, SHCS and M3 lockwasher. Do not tighten hardware completely.
- c. Install the other (2) shield standoffs, M3 socket head cap screws, SHCS and M3 lockwashers.
- d. Tighten all hardware carefully to avoid damaging the electrical shield.
- e. Install the front cover. Refer to Procedure 1B.
- f. Restore AC power to the system.

**Diagram 4.** *Electrical Shield Removal and Replacement.*

Procedure 5A - Main PCB Removal

- Turn off power by disconnecting AC power to the system.
- Remove front cover. Refer to Procedure 1A.
- Remove electrical shield. Refer to Procedure 4A.
- Unplug cable assemblies from J1 through J14 on main PCB. Note the color coding for cable assemblies that connect to J6, J7 and J8.
- Remove (2) M3 socket head cap screws, SHCS and M3 lockwashers.

Note: Use caution when handling the main PCB to avoid any damage.

Procedure 5B - Main PCB Replacement

- Install (2) M3 socket head cap screws, SHCS and M3 lockwashers.
- Connect cable assemblies to J1 through J14 on the main PCB. Check the color coding for J6, J7 and J8.
- Install the electrical shield. Refer to Procedure 4B.
- Install the front cover. Refer to Procedure 1B.
- Restore AC power to the system.




Diagram 5. Main PCB Removal and Replacement.

Procedure 6A - Cooling Fan Removal

- a. Turn power off by disconnecting AC power to the system.
- b. Remove rear cover. Refer to Procedure 2A.
- c. Unplug connector from cable assembly.
- d. Remove (4) M4 button head cap screws, BHCS and M4 lockwashers and remove cooling fan.

Procedure 6B - Cooling Fan Replacement

- a. Position cooling fan on underside of CPU / power supply mounting bracket.
- b. Install (4) M4 button head cap screws, BHCS and M4 lockwashers.
- c. Connect cable assembly.
- d. Install rear cover. Refer to Procedure 2B.
- e. Restore AC power to the system.




Diagram 6. Cooling Fan Removal and Replacement.

Procedure 7A - ACOPOS Support Bracket & ACOPOS Servo Drive Removal

Note: *If only the ACOPOS servo drive needs to be removed, it will not be necessary to perform all the following steps. Perform steps a, b, e, f, g and j only.*

- a. Turn power off by disconnecting AC power to the system.
- b. Remove front cover. Refer to Procedure 1A.
- c. Remove electrical shield. Refer to Procedure 4A.
- d. Remove main PCB. Refer to Procedure 5A.
- e. Remove (2) M5 button head cap screws, BHCS and M5 lockwashers from top portion of PCB / ACOPOS support bracket.
- f. Remove (2) M5 button head cap screws, BHCS and M5 lockwashers from lower portion of support bracket.
- g. Disconnect all external cable assemblies from the ACOPOS drive.
- h. Remove (2) M6 nylock nuts from hinge pins.
- i. Lift PCB / ACOPOS support bracket with ACOPOS drive still attached off hinge bracket.
- j. Separate the ACOPOS servo drive from the PCB / ACOPOS support bracket assembly by removing the (2) M6 nylock nuts from the underside of the upper portion of the PCB / ACOPOS support bracket assembly.

Procedure 7B - ACOPOS Support Bracket & ACOPOS Servo Drive Replacement

- a. Attach ACOPOS servo drive to PCB / ACOPOS support bracket with the (2) M6 nylock nuts.
- b. Position PCB / ACOPOS support bracket with ACOPOS servo drive attached onto hinge bracket and install (2) M6 nylock nuts.
- c. Swing ACOPOS assembly into its normal operating position and install all the cable assemblies to the ACOPOS servo drive.
- d. Install (2) M5 button head cap screws, BHCS and M5 lockwashers into top portion of PCB / ACOPOS support bracket.
- e. Install (2) M5 button head cap screws, BHCS and M5 lockwashers into lower portion of PCB / ACOPOS support bracket.
- f. Install main PCB. Refer to Procedure 5B.
- g. Install electrical shield. Refer to Procedure 4B.
- h. Install front cover. Refer to Procedure 1B.
- i. Restore AC power to the system.




Diagram 7. ACOPOS and Support Bracket Removal and Replacement.

Procedure 8A - CPU Assembly Removal

- Turn power off by disconnecting AC power to the system.
- Remove rear cover. Refer to Procedure 2A.
- Disconnect (3) cable assemblies from the CPU.
- If this is an iQ model it may be necessary to disconnect any I/O wiring from the I/O module.
- Remove (2) Phillips head screws and lift CPU off mounting bracket.

Procedure 8B - CPU Assembly Replacement

- Position CPU on mounting bracket.
- Install (2) Phillips head screws.
- Connect (3) cable assemblies to CPU and any I/O wiring, if necessary.
- Reinstall rear cover. Refer to Procedure 2B.
- Restore AC power to the system.




Diagram 8. CPU Assembly Removal and Replacement.

Procedure 9A - Power Supply Removal

- Turn power off by disconnecting AC power to the system.
- Remove rear cover. Refer to Procedure 2A.
- Disconnect input and output wiring from the power supply.
- Remove (3) M4 socket head cap screws, SHCS and (3) M4 lockwashers from bottom of power supply.
- Slide power supply out of CPU / power supply mounting bracket.

Procedure 9B - Power Supply Replacement

- Position power supply inside the CPU / power supply mounting bracket.
- Install (3) M4 socket head cap screws, SHCS and (3) M4 lockwashers into bottom of power supply.
- Connect input and output wiring. Refer to System Schematic if necessary.
- Reinstall rear cover. Refer to Procedure 2B.
- Restore AC power to the system.





Diagram 9. Power Supply Removal and Replacement.

Procedure 10A - CPU / Power Supply Mounting Bracket Removal

- a. Turn power off by disconnecting AC power to the system.
- b. Remove rear cover. Refer to Procedure 2A.
- c. Remove CPU assembly. Refer to Procedure 8A.
- d. Remove power supply. Refer to Procedure 9A.
- e. Disconnect slack spring.
- f. Free any wiring harnesses required.
- g. Remove (6) M5 socket head cap screws, SHCS and (6) M5 lockwashers.

Procedure 10B - CPU / Power Supply Mounting Bracket Replacement

- a. Position CPU / power supply mounting bracket against actuator casting.
- b. Install (6) M5 socket head cap screws, SHCS and (6) M5 lockwashers.
- c. Reconnect slack spring.
- d. Reinstall power supply. Refer to Procedure 9B.
- e. Reinstall CPU assembly. Refer to Procedure 8B.
- f. Reposition any wiring harnesses as required.
- g. Reinstall rear cover. Refer to Procedure 2B.
- h. Restore AC power to the system.

**Diagram 10.** CPU/Power Supply Mounting Bracket Removal and Replacement.

Procedure 11A - Motor Set Removal

- a. Turn power off by disconnecting AC power to the system.
- b. Remove rear cover. Refer to Procedure 2A.
- c. Remove resolver and motor power cables from motor set.
- d. Disconnect slack spring from slack spring bracket.
- e. Remove (4) M6 socket head cap screws, SHCS and (4) M6 lockwashers from motor set.
- f. Carefully pry motor set away from gearbox assembly.

Procedure 11B. Motor Set Replacement

- a. Align key on motor set shaft with gearbox assembly and push motor set into gearbox assembly with mounting holes properly aligned.
- b. Position slack spring bracket on left side of motor set and secure motor set with (4) M6 socket head cap screws, SHCS and (4) M6 lockwashers. **Note:** Do not tighten hardware completely until all (4) screws have been installed and are hand tight.
- c. Connect slack spring to slack spring bracket.
- d. Connect resolver and motor power cables to motor set.
- e. Reinstall rear cover. Refer to Procedure 2B.
- f. Restore AC power to the system.




Diagram 11A. 165 lb. (75 kg) Motor Set Removal and Replacement.




Diagram 11B. 330 and 660 lb. (150 and 300 kg) Motor Set Removal and Replacement.

Procedure 12A - End Support Frame Removal

- a. Turn power off by disconnecting AC power to the system.
- b. Remove front cover. Refer to Procedure 1A.
- c. Remove ACOPOS support bracket with electrical shield, main PCB and ACOPOS servo drive still attached. Disconnect all cable assemblies from the main PCB and ACOPOS drive as required. Refer to Procedure 7A.
- d. Remove (7) M5 socket head cap screws, SHCS and (7) M5 lockwashers from end support frame.

Procedure 12B - End Support Frame Replacement

- a. Align the end support frame with the holes in the actuator casting and install (7) M5 socket head cap screws, SHCS and (7) M5 lockwashers.
- b. Install the ACOPOS support bracket with electrical shield, main PCB and ACOPOS servo drive. Connect all cable assemblies to the main PCB and ACOPOS drive. Refer to Procedure 7B.
- c. Install the front cover. Refer to Procedure 1B.
- d. Restore AC power to the system.




Diagram 12A. 165 and 330 lb. (75 and 150 kg) End Support Frame Removal and Replacement.




Diagram 12B. 660 lb. (300 kg) End Support Frame Removal and Replacement.

Procedure 13A - Load Cell Removal

- a. Turn power off by disconnecting AC power to the system.
- b. Remove front cover. Refer to Procedure 1A.
- c. Remove rear cover. Refer to Procedure 2A.
- d. Disconnect load cell cable from J4 on the main PCB and open cable clamp to free cable and connector for removal.
- e. Remove the M12 hex head cap screw, HHCS and M12 lockwasher that secures the load cell to the main middle section through the opening towards the rear of the main middle section. **Note:** *Be careful not to damage any wiring as you pull the load cell cable through the main middle section since there is other wiring present.*
- f. Remove the load cell pin from the load cell as required.

Procedure 13B - Load Cell Replacement

- a. Install the load cell actuation pin and into the bottom of the load cell.
- b. Position the load cell with the pin attached in place from the rear of the main middle section.
- c. Install the M12 hex head cap screw, HHCS and M12 lockwasher that secure the load cell to the main middle section.
- d. Connect the load cell cable connector J4 on the main PCB and secure the cable with the corresponding clamp.
- e. Install the front cover. Refer to Procedure 1B.
- f. Install the rear cover. Refer to Procedure 2B.
- g. Restore AC power to the system

Note: *If you are replacing the load cell, you will have to perform specific load cell diagnostic procedures described in the Configuration Menu. Contact Gorbel® Customer Service Support for assistance.*




Diagram 13A. 165 lb. (75 kg) Q and iQ Load Cell Removal and Replacement.





Diagram 13B. 330 lb. (150 kg) and 660 lb. (300 kg) Q and iQ Load Cell Removal and Replacement.


Note: Numbers in Parentheses are Gorbel® Part Numbers



Note: C.H.1 is either of 2 holes off center.
C.H.2 is center hole with slot to edge.


Trolley Components for 2000 Series Steel or Aluminum Track.

Note: Numbers in Parentheses are Gorbel® Part Numbers




Note: C.H.1 is either of 2 holes off center.
C.H.2 is center hole with slot to edge.


Trolley Components for 1000 Series Steel or Aluminum Track.




Trolley Components for 500 Series Steel Track.



Trolley Components for 500 Series Aluminum Track.




Trolley Components for 250 Series Aluminum Track.




Universal Trolley Adapter.

Note: Numbers in Parentheses are Gorbel® Part Numbers



Load Plate Brace.

Note: Numbers in Parentheses are Gorbel® Part Numbers



Load Plate Brace.

Note: 165 lb. (75 kg) models do not use this component.

Procedure 14A - Drum Gate Removal

- a. Turn power off by disconnecting AC power to the system.
- b. Remove the front cover. Refer to Procedure 1A.
- c. Remove the (4) M5 button head cap screws, BHCS and (4) M5 lockwashers that secure the PCB / ACOPOS support bracket assembly to the end support frame.
- d. Disconnect limit switch cable assembly from main PCB in order to swing the ACOPOS drive assembly into the open position for access to the drum gate area.
- e. Loosen the (2) M8 nylock nuts and remove the load plate brace if your unit is a 330 or 660 lb. (150 or 300 kg) model.
- f. Remove the (2) M6 socket head cap screws, SHCS and (2) M6 lockwashers from the drum gate and slide the drum gate off the load plate.

Procedure 14B - Drum Gate Replacement

- a. Slide the drum gate into position on the load plate and install the (2) M6 socket head cap screws, SHCS and (2) M6 lockwashers.
- b. Position the load plate brace if equipped with one and tighten the (2) M8 nylock nuts.
- c. Swing the ACOPOS drive assembly into the closed position and connect the limit switch cable assembly to the main PCB.
- d. Install the (4) M5 button head cap screws, BHCS and (4) M5 lockwashers that secure the PCB / ACOPOS support bracket assembly to the end support frame.
- e. Install the front cover. Refer to Procedure 1B.
- f. Restore AC power to the system.




Diagram 14A. 165 lb. (75 kg) and 330 lb. (150 kg) Clearance Drum Gate Removal and Replacement.




Diagram 14B. 165 lb. (75 kg) and 330 lb. (150 kg) Clearance Drum Gate Removal and Replacement.




Diagram 14C. 660 lb. (300 kg) Clearance Drum Gate Removal and Replacement.

Procedure 15A - Drum Cover and Drum Cover Band Removal

- a. Turn power off by disconnecting AC power to the system.
- b. Remove front cover. Refer to Procedure 1A.
- c. Remove ACOPOS support bracket with electrical shield, main PCB and ACOPOS servo drive still attached. Disconnect only cable assemblies from the main PCB as necessary. Refer to Procedure 7A.
- d. Remove end support frame. Refer to Procedure 12A.
- e. Remove the drum gate. Refer to Procedure 14A.

Note: Use caution during the next step. The drum cover band will be in tension.

- f. Remove the (2) M6 socket head cap screws, SHCS and (2) M6 lockwashers that secure the drum cover band to the load plate.
- g. Slide both the drum cover band and drum cover off the drum pulley.

Procedure 15B - Drum Cover and Drum Cover Band Replacement

- a. Position the drum cover band inside the drum cover and slide the assembly over the drum pulley.
- b. Install the (2) M6 socket head cap screws, SHCS and (2) M6 lockwashers for the drum cover band into the load plate.
- c. Install the drum gate. Refer to Procedure 14B.
- d. Install the end support frame. Refer to Procedure 12B.
- e. Install the ACOPOS support bracket with electrical shield, main PCB and ACOPOS servo drive still attached. Connect all cable assemblies to the main PCB. Refer to Procedure 7B.
- f. Install the front cover. Refer to Procedure 1B.
- g. Restore power to the system.




Diagram 15A. 165 lb. (75 kg) and 330 lb. (150 kg) Drum Cover and Band Removal and Replacement.




Diagram 15B. 660 lb. (300 kg) Drum Cover and Band Removal and Replacement.

Procedure 16A - Limit Switch Assembly Removal

- a. Turn power off by disconnecting AC power to the system.
- b. Remove front cover. Refer to Procedure 1A.
- c. Disconnect the limit switch cable assembly from the main PCB (J11).
- d. Remove the access plug from the main middle section.
- e. Remove the M6 button head cap screw, BHCS and M6 lockwasher from the outside end of the limit SWITCH assembly.
- f. Remove the limit SWITCH assembly from the load plate inside the main middle section.

Procedure 16B - Limit Switch Assembly Replacement

- a. Position the limit switch assembly on the load plate by locating it on the inside M6 button head cap screw, BHCS. The lower projection of the slide must be engaged in recess in threaded gate.
- b. Install the M6 button head cap screw, BHCS and M6 lockwasher on the outside end of the limit switch assembly.
- c. Connect the limit switch cable assembly to the main PCB (J11).
- d. Install the access plug into the main middle section.
- e. Install the front cover. Refer to Procedure 1B.
- f. Restore AC power to the system.




Diagram 16A. 165 lb. (75 kg) and 330 lb. (150 kg) Limit Switch Assembly Removal and Replacement.







Diagram 16B. 660 lb. (300 kg) Limit Switch Assembly Removal and Replacement.




165 lb. (75 kg)




330 lb. (150 kg)




330 lb. (150 kg)




660 lb. (300 kg)




660 lb. (300 kg)




660 lb. (300 kg)




1320 lb. (600 kg) Reeved G-Force® Reinforcement Plate Assembly.



1320 lb. (600 kg) Reeved G-Force® Coil Cord Assembly.



1320 lb. (600 kg) Reeved G-Force Pulley Assembly.



1320 lb. (600 kg) Reeved G-Force® Swivel Assembly.

Removal and Replacement Procedures

SLIDING HANDLE

Procedure 1A. Swivel Sub Assembly Removal:

Note: This procedure assumes the Coil Cord and Wire Rope assemblies have been removed prior to performing any repairs on the Sliding Handle itself. Refer to the system installation procedures in Chapter 3 for specific instructions regarding Coil Cord and Wire Rope removal.

- a. Remove the M16 custom hex head cap screw, HHCS and M16 Belleville washer from the top of the swivel assembly.
- b. Slide the swivel assembly off the top of the handle shaft.

Procedure 1B. Swivel Sub Assembly Replacement:

- a. Slide the swivel assembly onto the top of the handle shaft.
- b. Install the M16 custom hex head cap screw, HHCS and M16 Belleville washer onto the top of the handle shaft.




Diagram 1. In-Line Slide Handle Swivel Sub Assembly Removal and Replacement.

Procedure 2A. Remote Mount Cap Sub Assembly Removal

Note: This procedure assumes the handle has already been removed from a remote mount bracket or similar mounting device.

- Remove M16 hex head cap screw, HHCS, flatwasher and lockwasher from the top of the handle assembly.
- Slide the remote mount cap off the handle shaft. Note the orientation of the internal electrical connector located below the remote mount cap.

Procedure 2B. Remote Mount Cap Sub Assembly Replacement

- Slide the remote mount cap onto the handle shaft. Note the orientation of the internal electrical connector located below the remote mount cap.
- Position the handle assembly into the remote mount bracket (if applicable) and install M16 hex head cap screw, HHCS, flatwasher and lockwasher onto the top of the handle assembly.




Diagram 2. Remote Mounted Sliding Handle Remote Mount Cap Sub Assembly Removal and Replacement.

Procedure 3A. Housing Sub Assembly Removal

- Remove swivel sub assembly or remote mount cap assembly. Refer to Procedure 1A or 2A accordingly.
- Remove air extension output and O-ring if equipped with this option.
- Remove snap ring and any shim washers.
- Carefully slide the housing sub assembly off the handle shaft.

Note: Be careful to not damage the LVDT sub assembly when removing the housing assembly.

Procedure 3B. Housing Sub Assembly Replacement

- Carefully slide the housing sub assembly onto the handle shaft.

Note: Be careful to not damage the LVDT sub assembly when replacing the housing sub assembly.
- Replace either the swivel sub assembly or remote mount cap sub assembly accordingly. Refer to Procedure 1B or 2B.
- Replace snap ring, washers, and air extensions (if applicable).




Diagram 3. Housing Sub-Assembly Removal and Replacement.

Procedure 4A. Housing Sub Assembly Disassembly

Note: This procedure is applicable to both Q and iQ handle assemblies.

- Remove the swivel sub assembly or remote mount cap sub assembly. Refer to Procedure 1A or 2A accordingly.
- Remove the housing sub assembly. Refer to Procedure 3A.
- Remove (4) M5 socket head cap screws, SHCS and (4) M5 flatwashers.
- Separate the handle top sub assembly from the handle bottom. Use caution, the ribbon cable and ground wire will still be connected.
- All the sub assembly internal components can be removed or replaced using the exploded view drawings as a reference.

Procedure 4B. Housing Sub Assembly Reassembly

- All the sub assembly internal components can be removed or replaced using the exploded view drawings as a reference.
- Once all the internal components have been positioned properly, slide the handle bumper in place on the handle bottom and join the handle top sub assembly with the handle bottom. Make sure the ribbon cable and ground wire are connected properly.
- Install the (4) M5 socket head cap screws, SHCS and (4) M5 flatwashers.
- Install the housing sub assembly and swivel or remote cap sub assemblies as required. Refer to Procedures 3B and 1B or 2B.




Diagram 4A. Housing Sub-Assembly Assembly and Disassembly.




Diagram 4B. Housing Sub-Assembly Assembly and Disassembly.

Procedure 5A. LVDT Sub Assembly Removal

- a. Remove the swivel or remote mount cap sub assembly. Refer to Procedure 1A or 2A.
- b. Remove the housing sub assembly. Refer to Procedure 3A.
- c. Access the LVDT adjustment screw from the opening below the upper portion of the handle grip assembly. Turn the screw clockwise until the LVDT is clear of the grip assembly.

Note: *Keep track of the approximate number of turns required to remove the assembly. It will help approximate the starting position for the replacement process.*

Procedure 5B. LVDT Sub Assembly Replacement

- a. Insert the LVDT sub assembly into the top opening in the upper portion of the handle grip assembly. Turn the screw counterclockwise from the bottom until the LVDT sub assembly is positioned close to its original position.

Note: *The fine adjustment can be done using a diagnostic procedure after the handle is completely reassembled and power is applied to the system. Refer to Chapter 5 (SERVICE MENU - SRV MENU ACT DIAG) for this diagnostic.*

- b. Replace the housing sub assembly. Refer to Procedure 3B.
- c. Replace the swivel or remote mount cap sub assembly. Refer to Procedure 1B or 2B.




Diagram 5. Handle Transducer Sub Assembly Removal and Replacement.

Procedure 6A. Handle Grip and Shaft Assembly Disassembly

- a. Remove the spring pin from the hex jam nut and handle shaft.
- b. Remove the hex ham nut from the handle shaft.
- c. Slide the spring sleeve up over the top portion of the handle shaft.
- d. Slide the first bearing sleeve up over the top portion of the handle shaft.
- e. Slide the compression spring up over the top portion of the handle shaft.
- f. Slide the second bearing sleeve up over the top portion of the handle shaft.
- g. Slide the grip assembly off the top portion of the handle shaft.

Note: *There are a total of (12) ball bearings seated in (3) separate grooves in the handle shaft. These are normally coated with grease and should remain in place however they can fall out if the amount of grease has decreased over time.*

Procedure 6B. Handle Grip and Shaft Assembly Reassembly

- a. Install the grip assembly over the top portion of the handle shaft and position the grip assembly so that the ball bearings can be installed into the grooves of the handle shaft from the top of the grip assembly.
- b. Slide the second bearing sleeve down over the top portion of the handle shaft.
- c. Slide the compression spring down over the top portion of the handle shaft.
- d. Slide the first bearing sleeve down over the top portion of the handle shaft.
- e. Slide the spring sleeve down over the top portion of the handle shaft to the hex jam nut.
- f. Install the hex ham nut from the handle shaft.
- g. Install the spring pin into the hex jam nut and handle shaft.

Note: Numbers in
Parentheses are
Gorbel® Part Numbers







Diagram 6. Handle Grip and Shaft Assembly and Disassembly.




Remote Mounted Slide Handle Bracket.




In-Line Slide Handle Control Bracket.




Single Auxiliary Control Pilot Valve Kit for Slide Handle.



Auxiliary Control Pilot Valve Kit.



Auxiliary Electric Switch with Bracket.



Single Electric Switch Assembly for Slide Handle.

Removal & Replacement Procedures

PENDANT HANDLE

Note: The following procedures assume any electrical or support cables have been disconnected prior to performing any repairs on the Pendant Handle itself.

Procedure 1A. Top Guard Removal

- a. Remove the (4) M6 button head cap screws, BHCS and (4) M6 lockwashers.
- b. Slide the top guard off the top portion of the pendant handle.

Procedure 1B. Top Guard Replacement

- a. Position the top guard on the top portion of the pendant handle.
- b. Install the (4) M6 button head cap screws, BHCS and (4) M6 lockwashers.




Diagram 1. *Top Guard Removal and Replacement.*

Procedure 2A. Side Guard Removal

- a. Remove the (2) M6 button head cap screws, BHCS and (2) M6 lockwashers from each side of the pendant handle.
- b. Remove the (2) side guards from the pendant handle.

Procedure 2B. Side Guard Replacement

- a. Position the (2) side guards on each side of the pendant handle.
- b. Install the (2) M6 button head cap screws, BHCS and (2) M6 lockwashers on each side of the pendant handle.




Diagram 2. Side Guard Removal and Replacement.

Procedure 3A. Lever Shaft Removal

- a. Remove either side guard. Refer to Procedure 2A.
- b. Slide the lever shaft through each lever.

Procedure 3B. Lever Shaft Replacement

- a. Position both levers and slide the lever shaft through both levers.
- b. Install the side guard using the (2) M6 button head cap screws, BHCS and (2) M6 lockwashers.




Diagram 3. *Lever Shaft Removal and Replacement.*

Procedure 4A. Lever Removal

- a. Remove either side guard. Refer to Procedure 2A.
- b. Remove the lever shaft. Refer to Procedure 3A.
- c. Remove both levers from the pendant handle.

Procedure 4B. Lever Replacement

- a. Position both levers on the pendant handle.
- b. Install the lever shaft. Refer to Procedure 3B.
- c. Install the side guard. Refer to Procedure 2B.




Diagram 4. Lever Removal and Replacement.

Procedure 5A. Handle Base Bracket Removal

- a. Disconnect handle base bracket from clamp collar or tooling if necessary.
- b. Remove (2) M6 button head cap screws, BHCS and (2) M6 lockwashers.

Procedure 5B. Handle Base Bracket Replacement

- a. Install (2) M6 button head cap screws, BHCS and (2) M6 lockwashers.
- b. Reattach the handle base bracket to clamp collar or tooling if necessary.




Diagram 5. Handle Base Bracket Removal and Replacement.

Procedure 6A. Rear Cover Removal

- a. Remove handle base bracket. Refer to Procedure 5A.
- b. Remove the (6) M3 button head cap screws, BHCS and (6) M3 lockwashers that secure the rear cover.
- c. Remove rear cover and rear cover gasket.

Procedure 6B. Rear Cover Replacement

- a. Position rear cover gasket and rear cover on pendant handle assembly.
- b. Install the (6) M3 button head cap screws, BHCS and (6) M3 lockwashers that secure the rear cover.
- c. Install handle base bracket. Refer to Procedure 5B.





Diagram 6. *Rear Cover Removal and Replacement.*

Procedure 7A. Pendant Mother and Pendant Daughter Board Removal

- a. Remove handle base bracket. Refer to Procedure 5A.
- b. Remove the rear cover. Refer to Procedure 6A.
- c. Remove the **external nuts from the pendant daughter board.**
- d. Remove the (2) M3 button head cap screws, BHCS and (2) M3 starwashers from the pendant mother board.
- e. Slide the pendant mother and daughter boards out from the pendant handle body.

Procedure 7B. Pendant Mother and Pendant Daughter Board Replacement

- a. Slide the pendant mother and daughter boards into the pendant handle body.
- b. Install the (2) M3 button head cap screws, BHCS and (2) M3 starwashers to secure the pendant mother board inside the pendant handle body.
- c. Install the **external nuts on the pendant daughter board.**
- d. Install the rear cover and rear cover gasket. Refer to Procedure 6B.
- e. Install the handle base bracket. Refer to Procedure 5B.


**Diagram 7.** Pendant Mother and Daughter Board Removal and Replacement.

Procedure 8A. Plunger Assembly Removal

- a. Remove either side guard. Refer to Procedure 2A.
- b. Remove the lever shaft. Refer to Procedure 3A.
- c. Remove both levers. Refer to Procedure 4A.
- d. Remove the M4 button head cap screw, BHCS and M4 large OD washer.
- e. Slide both plunger assemblies out of pendant handle housing.
- f. Remove the plunger springs from plunger assemblies.
- g. Remove the plunger tips from plunger assemblies.

Procedure 8B. Plunger Assembly Replacement

- a. Install the plunger tips into the plunger assemblies.
- b. Install the plunger springs into the pendant handle housing.
- c. Install both plunger assemblies into the pendant handle housing.
- d. Install the M4 button head cap screw, BHCS and M4 large OD washer to secure the plunger assemblies in the pendant handle housing.
- e. Install both levers. Refer to Procedure 4B.
- f. Install the lever shaft. Refer to Procedure 3B.
- g. Install the side guard. Refer to Procedure 2B.

**Diagram 8.** *Plunger Assembly Removal and Replacement.*

Procedure 9A. Faceplate and Face Seal Removal

- a. Remove the (10) M2 Phillips screws, PHMS and (10) M2 lockwashers from the faceplate.
- b. Remove the faceplate and face seal from the pendant handle housing.

Procedure 9B. Faceplate and Face Seal Replacement

- a. Install the faceplate and face seal into the pendant handle housing.
- b. Install the (10) M2 Phillips screws, PHMS and (10) M2 lockwashers for the faceplate.




Diagram 9. Faceplate and Face Seal Removal and Replacement.

Procedure 10A. E-Stop Assembly and Pushbutton Removal

- a. Remove the faceplate and face seal. Refer to Procedure 9A.
- b. Remove the (2) pushbutton shafts from the pendant handle housing.

Note: The E-stop button assembly is removed and installed from the inside of the housing. There are two parts that make up the E-stop assembly. The switch part is disconnected from the inside first. The pushbutton is then held in place by a nut that needs to be removed from the inside.

Procedure 10B. E-Stop Assembly and Pushbutton Replacement

- a. Install the (2) pushbutton shafts into the pendant handle housing.
- b. Install the faceplate and face seal. Refer to Procedure 9B.







Diagram 10. E-Stop Assembly, Pushbutton and Light Tube Removal and Replacement.




Single Valve Option - Right Side.




Single Valve Option - Left Side.




Single Valve Option - Right and Left Sides.




Electric Switch Options - Right Side.




Electric Switch Option - Left Side.



Electric Switch Option - Both Sides.



Electric Switch Right Side, Valve Left Side.



Electric Switch Left Side, Valve Right Side.

Removal & Replacement Procedures

COIL CORDS

Procedure 1. Standard Coil Cord Assembly (G-FORCE.COILCORD.ASSEMBLY)




Diagram 1. 660 lb. (300 kg) Standard Length Coil Cord Assembly.

G-FORCE.COILCORD.ASSEMBLY

For replacement of entire Coil Cord Assembly use part name: G-FORCE.COILCORD.ASSEMBLY.




Diagram 2. 165 lb. (75 kg) and 330 lb. (150 kg) Standard Length Coil Cord Assembly.

G-FORCE.COILCORD.ASSEMBLY

For replacement of entire Coil Cord Assembly use part name: G-FORCE.COILCORD.ASSEMBLY.

Procedure 2. Double Length Coil Cord Assembly (G-FORCE.COILCORD.EXT.ASSEMBLY)




Diagram 3. 660 lb. (300 kg) Double Length Coil Cord Assembly.

G-FORCE.COILCORD.EXT.ASSEMBLY

For replacement of entire Coil Cord Assembly use part name:
G-FORCE.COILCORD.EXT.ASSEMBLY.

Note: Numbers in
Parentheses are
Gorbel® Part Numbers





Diagram 4. 165 lb. (75 kg) and 330 lb. (150 kg) Double Length Coil Cord Assembly.

G-FORCE.COILCORD.EXT.ASSEMBLY

For replacement of entire Coil Cord Assembly use part name:

G-FORCE.COILCORD.EXT.ASSEMBLY.



Pendant Cable (Electrical Portion Only).

G-FORCE.PENDANT.CABLE

For replacement of entire Cable Assembly use part name:
G-FORCE.PENDANT.CABLE.

Procedure 3. Standard Air Hose Assembly (G-FORCE.AIRHOSE.ASEMBLY)




Diagram 5. *Standard Air Hose Assembly.*

G-FORCE.AIRHOSE.ASEMBLY

For replacement of entire Airhose Assembly use part name: G-FORCE.AIRHOSE.ASEMBLY.

Procedure 4. Extended Length Air Hose Assembly (G-FORCE.AIRHOSE.EXT.ASSEMBLY)




Diagram 6. Extended Length Air Hose Assembly.

G-FORCE.AIRHOSE.EXT.ASSEMBLY

For replacement of entire Airhose Assembly use part name: G-FORCE.AIRHOSE.EXT.ASSEMBLY.

Removal & Replacement Procedures

G360™

Procedure 1A. G360™ Disassembly Procedure

- a. Remove M16 x 2 MM hex head cap screw, HHCS and M16 Belleville washer from G360™ assembly. Note the orientation of the Belleville washer; concave side down.
- b. Slide the swivel sub-assembly off the collector shaft.

Note: Set aside the swivel sub assembly with the PCBs facing upward to avoid damaging them.

- c. Remove output connector nut from the slip ring PCB.
- d. Remove the (2) M2 Phillips head machine screws, PHMS that secure the slip ring PCB to the collector shaft.
- e. Remove the air extension and nylon washer from collector shaft.
- f. Remove (3) M3 socket head cap screws, SHCS and (3) M3 lockwashers from the collector shaft and slide the collector shaft out of the cover.

Procedure 1B. G360™ Reassembly Procedure

- a. Slide the collector shaft into the cover and secure it using the (3) M3 socket head cap screws and (3) M3 lockwashers. Note the alignment of the output connector to the cover opening.
- b. Install the air extension and nylon washer into the collector shaft.
- c. Assemble the slip ring PCB to the collector shaft with (2) M2 Phillips head machine screws, PHMS.
- d. Install the output connector nut on the slip ring PCB.
- e. Slide the swivel sub-assembly onto the collector shaft. Carefully align connectors using the alignment grooves in the cover.
- f. Install the M16 x 2 MM hex head cap screw, HHCS and M16 Belleville washer onto the G360™ assembly. Note the orientation of the Belleville washer; concave side down.




Diagram 1A. G360™ with Air Assembly and Disassembly.




Diagram 1B. Standard G360™ Assembly and Disassembly.

Procedure 2A. Swivel Sub Assembly Disassembly Procedure

- a. Remove the swivel sub assembly from the G360™ assembly. Refer to Procedure 1A.
- b. Remove the C-ring from the swivel sub assembly.
- c. Remove the Delrin spacer washer from the swivel sub assembly.
- d. Remove the secondary slip ring PCB from the swivel casting. Be very careful to not deform the contacts on the PCB.
- e. Remove the primary slip ring PCB from the swivel by removing the input connector nut, (3) M2 Phillips head machine screws, PHMS, (4) nylon Phillips head machine screws, PHMS, and (12) flatwashers from the swivel casting.
- f. Remove the bearing from the swivel casting if necessary. **Note:** *This bearing is pressed into the swivel casting.*

Procedure 2B. Swivel Sub Assembly Reassembly Procedure

- a. Press the bearing into the swivel casting.
- b. Install the primary slip ring PCB into the swivel casting by installing the input connector nut, (3) M2 Phillips head machine screws, PHMS, (4) nylon Phillips head machine screws, PHMS, and (12) flatwashers.
- c. Install the secondary slip ring PCB into the swivel casting. Be very careful to not deform the contacts on the PCB.
- d. Install the Delrin spacer washer onto the swivel sub assembly.
- e. Install the C-ring onto the swivel sub assembly. Check to see that the assembly moves freely.
- f. Install the swivel sub assembly into the G360™ assembly. Refer to Procedure 1B.





Diagram 2. Swivel Sub Assembly Disassembly and Reassembly.



Suspended Pendant Swivel Assembly.

Removal & Replacement Procedures


CPU BATTERY

Procedure 1. (Optional) Retain Q-iQ Custom Feature Settings

Q-iQ custom feature settings like the programmed weight of the handle (tooling) for zeroing the weight readout on the handle LCD display, programmed positions like the virtual limits, etc. are temporarily stored in the PLC memory powered by the PLC battery. As a result, these memories are cleared and reset to default when the battery is replaced. Users can reprogram these features to use them again.

If available, an alternative to reprogramming the features is to use the **Gorbel® Q-iQ Update Utility**. Use this utility to save the settings onto a PC, then follow Procedure 2 to replace the battery. Use the utility again to upload the settings from the PC back into the PLC. After a power reboot, the unit will be back online as before.


Choose the “Replace PLC Battery” option in the utility program as shown below. More information can be found in Chapter 6 - Software Update in this manual.



Procedure 2. CPU Battery Replacement


These procedures should be followed if the unit experiences a Command Warning #10500, if the PLC memory retention battery power level is low or faulty, or if instructed to by a Gorbel® Customer Service Representative.

- a. Typically, battery replacement resets all configuration and features settings back to default unless memory retention procedures are performed prior to the replacement. Please check the **Software Update** chapter for information on using the “Replace PLC Battery” option to record the settings. Skip this step if not available.
- b. If the previous step cannot be performed, please reference the **Program Mode Overview** section for accessing the configuration menu (LCD display: CONFIGUR MENU) if available (accessibility may not be available on order units). Choose RECORD CONFIG selection to save the latest configuration settings into nonvolatile memory. Feature settings will not be recorded. Skip this step if not available.
- c. Turn power off using the external circuit breaker device.
- d. Follow Actuator Procedure 2A on page 10-4 to remove the rear cover.
- e. Locate the battery cover of the CPU.




- f. Touch the mounting rail or ground connection (not the power supply!) in order to discharge any electrostatic charge from your body.

- g. Remove the cover from the lithium battery holder using a screwdriver.



- h. Remove the battery from the holder by pulling the removal strip (don't use insulated tools because of the risk of short circuiting). The battery should not be held by its edges. **Insulated** tweezers may also be used for removing the battery.



- i. Insert the new battery with correct polarity. The removal strip should be pulled to the right of the battery holder and the “+” side of the battery should be facing left. In order to be able to remove the battery again in the future, the removal strip **must** be on the right side of the battery.



- j. Now wrap the end of the removal strip over the top of the battery and insert it underneath the battery so that it does not protrude from the battery holder.
- k. Replace cover. Insert the lower edge of the cover in the battery holder opening. Press the upper end of the cover home firmly.

Note: *Lithium batteries are considered hazardous waste. Used batteries should be disposed of accordingly.*

Chapter 11 - Preventative Maintenance

G-Force® Model Q and iQ Recommended Preventative Maintenance




Diagram 1. *G-Force® with Suspended Pendant Handle.*

Refer to Diagram 1 for the approximate location of the components listed by numbers 1 through 19 on the following pages. The procedures are divided into four specific intervals; daily, monthly, quarterly and yearly. You may find it necessary to increase the frequency based on equipment use and environmental conditions in your facility.

Federal, state and local codes may require inspection and maintenance checks more often. Please check federal, state and local code manuals in your area.

Note:

iQ model show with in-line slide handle. See illustrations below for alternate configurations.



Remote Sliding Handle

* tooling by others



Remote Pendant Handle

* tooling by others



Suspended Pendant Handle

Daily Checks


These are quick visual checks that do not require any tools.

- 1. Wire Rope:** Look for any obvious external defects, damage or excessive wear. Check the lower end where it attaches to the Handle, Swivel Assembly or tooling (by others) for signs of damage or excessive wear.
- 2. Coil Cord:** Look for any obvious external defects or damaged caused by the Wire Rope or other external causes. Make sure all the Coil Cord Clamps are in place.
- 3. Air Hose (if equipped):** Look for any obvious external damage or wear caused by the Wire Rope or other external causes. Make sure the Air Hose is secured properly with the correct clamps.
- 4. Load Hook and/or tooling (by others):** Check that the Load Hook is secured properly to the handle or swivel. Make sure lock washers are compressed completely and any other associated hardware is secure.


Monthly Tasks

Tools may be required, as well as a clean dry cloth and compressed air.



- 5. Slack Switch Adjustment:** Using the Handle, lower the Wire Rope until it goes slack. There should be no additional movement downward once it is slack. If the Wire Rope continues to pay out, stop immediately and refer to Chapter 9 of this manual to perform the Slack Switch Adjustment. Check the Coil Cord and Air Hose Clamps on the Wear Ring to insure the Wear Ring is moving freely inside the Actuator opening.



SLACK
ADJUSTMENT
HARDWARE



WEAR RING



6. **Wire Rope:** Expose any much of the Wire Rope as possible and wipe it off with a clean dry cloth. Use the Jog Buttons to pay out as much of the Wire Rope as possible.



7. **Operator Present Sensor (sliding handle only):** Use a gentle puff of compressed air or a soft cloth to clean the sensor. Do not apply any pressure to the lens or do anything that may scratch it.

OPERATOR PRESENT SENSOR

NOTE: PHOTO ENHANCED TO SHOW LOCATION OF SENSOR. RED BEAM WILL NOT BE VISIBLE DURING NORMAL OPERATION.



8. **Handle I/O Connections (both handles):** Check connections at handle (if equipped). Wipe off any oil or other contamination from either Handle at this time. Clean the LCD screen as well.



I/O
CONNECTION
PORTS



LCD
SCREENS



Quarterly Tasks

Tools, compressed air and specific lubricants are required.

9. Limit Switch Assembly Actuator: Check for excessive wear and for proper position with the Drum Gate.

Refer to Chapter 10 for removal and replacement procedures.

10. Drum Gate: Remove and look for excessive wear.

Refer to Chapter 10 for removal and replacement procedures.


11. Air Swivel Assembly (if equipped) O-Rings: These should be replaced if worn or damaged. Apply a thin coating of non-synthetic general purpose grease.

Refer to Chapter 10 for removal and replacement procedures.

12. Swivel Assembly Slip Rings: Check for wear. Wipe clean with soft dry cloth and apply a thin layer of DeoxIT. This also applies to the independent G360™.

Refer to Chapter 10 for removal and replacement procedures.

LIMIT SWITCH
ASSEMBLY
ACTUATOR



DRUM GATE



O-RINGS
(2)




SLIP
RINGS


Yearly Tasks

Tools, compressed air and specific lubricants are required.

13. Internal and External Electrical Connectors: This includes Coil Cord, Swivel Assembly and Main pwb connectors. Check each connector carefully. Some are secured with hardware, some are quick disconnect type.




- 14. Servo Drive Heat Sink:** Clean this area only if the operating environment is especially dusty. Use compressed air and safety glasses.



- 15. Cooling Fan (if equipped):** Clean this area if it appears to be dirty. Use compressed air and safety glasses.



- 16. Sliding Handle:** The ball bearings on the slide mechanism should be lubricated with white lithium grease. Use the grease sparingly and wipe any excess off immediately.



- 17. Linear Transducer Position:** Check the Linear Transducer by using the Diagnostic Menu as described in Chapter 9. Adjust only if necessary.



- 18. Trolley Wheels:** Check for excessive wear and/or contamination.



- 19. Crane or supporting structure:** Check for wear or excessive contamination inside the bridge. Check lock washers and other hardware for proper tightness.



Wire Rope Inspection

1. Frequent Inspection

The operator or other designated person should visually inspect all ropes at the start of each shift. These visual observations should be concerned with discovering gross damage, such as listed below, which may be an immediate hazard:

- distortion of the rope such as kinking, crushing, unstranding, birdcaging, main strand displacement, or core protrusion;
- general corrosion;
- broken or cut strands;
- number, distribution, and type of visible broken wires (see next section on rope replacement).

When such damage is discovered, the rope shall either be removed from service or given an inspection as detailed in the next section.

2. Periodic Inspection

The inspection frequency shall be determined by a qualified person and shall be based on such factors as expected rope life as determined by experience on the particular installation or similar installations; severity of environment; percentage to capacity lifts; frequency rates of operation; and exposure to shock loads. Inspections need not be at equal calendar intervals and should be more frequent as the rope approaches the end of its useful life.

A designated person shall perform periodic inspections. This inspection shall cover the entire length of rope. The individual outer wires in the strands of the rope shall be visible to this person during the inspection. Any deterioration resulting in appreciable loss of original strength, such as described below, shall be noted, and determination shall be made as to whether further use of the rope would constitute a hazard.

- points listed in previous section on frequent inspection;
- reduction of rope diameter below nominal diameter due to loss of core support, internal or external corrosion, or wear of outside wires;
- severely corroded or broken wires at end connections;
- severely corroded, cracked, bent, worn, or improperly applied end connections.

Special care should be taken when inspecting sections of rapid deterioration, such as the following:

- sections in contact with saddles, equalizer sheaves, or other sheaves where rope travel is limited;
- sections of rope at or near terminal ends where corroded or broken wires may protrude;
- sections subject to reverse bends;
- sections of rope that are normally hidden during visual inspection, such as parts passing over sheaves.

Wire Rope Maintenance

1. Rope should be stored to prevent damage, contamination, and deterioration.
2. Rope shall be unreeled or uncoiled in a manner to avoid kinking of or inducing a twist in the rope.
3. Before cutting rope, means shall be used to prevent unlaying of the strands.
4. During installation, care should be observed to avoid dragging of the rope in dirt or around objects that will scrape, nick, crush, or induce sharp bends.

CAUTION

Rope should be maintained in a well-lubricated condition. Gorbel recommends using chain and cable penetrating oil for lubrication. Lubricant applied as part of a maintenance program shall be compatible with the original lubricant (PreLube 6). Lubricant applied shall be of the type that does not hinder visual inspection. Immediately after inspection, lubricant shall be applied before rope is returned to service. Those sections of rope that are located over sheaves or otherwise hidden during inspection and maintenance procedures require special attention when lubricating ropes. The object of rope lubrication is to reduce internal friction and to prevent corrosion.

Wire Rope Replacement Criteria

1. No precise rules can be given for determination of the exact time for rope replacement since many factors are involved. Once a rope reaches any one of the specified removal criteria, it may be allowed to operate to the end of the work shift, based on the judgment of a qualified person. The rope shall be replaced after that work shift, at the end of the day, or at the latest time prior to the equipment being used by the next work shift.
2. Removal criteria for the rope replacement shall be as follows:
 - in running ropes, any visible broken wires (**diagram 3**);
 - wear of one-third the original diameter of outside individual wires;
 - kinking, crushing, birdcaging, or any other damage resulting in distortion of the rope structure;
 - evidence of heat damage from any cause;
 - reductions from nominal diameter greater than 1/64" (.4 mm) for 1/4" (6.35 mm) diameter rope.
3. Broken wire removal criteria applies to wire rope operating on steel sheaves and drums. However, results of internal testing have shown that rope replacement follows the same criteria regardless of sheave or drum material.
4. Attention shall be given to end connections. Upon development of any broken wires adjacent to an end connection, the rope should be reterminated or replaced. Reterminating shall not be attempted if the resulting rope length will be insufficient for proper operation.
5. Replacement rope and connections shall have strength rating at least as great as the original rope and connection furnished by the hoist manufacturer. A rope manufacturer, or a qualified person shall specify any deviation from the original size, grade, or construction.




Diagram 3. 19x7 Preformed Wire Rope Composition.

Chapter 12 - Recommended Tools and Parts

Tool Name	Sizes
Metric Allen Wrenches (T-Type, 230mm long are preferred)	2mm, 2.5mm, 3mm, 4mm, 5mm, 6mm, 8mm, 10mm
Metric Sockets (Drive sizes are typically 1/4 and 3/8 inch depending on socket size)	5.5mm, 7mm, 8mm, 10mm, 19mm
Ratchet Handles and Extensions	User preference
Metric Combination Wrenches (10mm should be ratcheting type)	10mm, 17mm, 19mm, 24mm
Lock Ring Pliers	small and medium sizes
Screwdrivers (flat and Phillips)	smaller precision type
Long Nose Pliers	8 inch is typical

Spare Parts Kits	Gorbel® Part Number
Basic Kit	Contact Inside Sales for specific part numbers and applications
Hardware Kit	Contact Inside Sales for specific part numbers and applications
Swivel Kit	Contact Inside Sales for specific part numbers and applications